




INSTRUCTIONS HANDBOOK

STAR COMPACT 60
STAR COMPACT 120

MW
MACHINERY WORLD



PROMAG
LE MACCHINE PER IL GELATO



This handbook may not be reprinted, transferred, registered, recorded in a retrieval system, nor translated in other languages unless otherwise previously agreed in writing with **PROMAG**. The purchaser has been left with the power to reprint it for his own office use. This handbook was realized and checked with utmost care in order to give information as much reliable as possible. **PROMAG** reserves the right to make changes and revisions whenever deemed necessary and without being bound to previously notify it to the purchaser.

Tel. (051) 6505358 - Fax (051) 6505253

Via Emilia, 45A - 40011 Anzola Emilia (Bologna) - Italy

PROMAGALIS.p.A.

INDEX

SECT. FOREWORD

FOREWORD V
INSTRUCTIONS HANDBOOK V
PURPOSE V
HANDBOOK STRUCTURE V
ADDITIONAL DOCUMENTATION V
SAFETY VI
STAFF QUALIFICATION VI
CONVENTIONAL SYMBOLS VII
WARNINGS VIII

SECTION 1 - RECEIVING, MOVING UNPACKING

SECTION INDEX 1
1.1 RECEPTION 2
 1.1.1 LIFTING PACKED MACHINES 2
 1.1.2 FORBIDDEN MATERIAL HANDLING EQUIPMENT 3
1.2 UNPACKING 3
1.3 STORING THE MACHINE 5
1.4 DISPOSAL OF PACKING STUFFS 5

SECTION 2 - GENERAL INFORMATION

SECTION INDEX 1
2.1 GENERAL DATA 2
 2.1.1 MANUFACTURER'S IDENTIFICATION DATA 2
 2.1.2 USER'S/CLIENT'S IDENTIFICATION DATA 2
 2.1.3 INFORMATION ABOUT SERVICE 2
 2.1.4 INFORMATION TO THE USER 2
2.2 INFORMATION ABOUT THE MACHINE 3
 2.2.1 GENERAL INFORMATION 3
 2.2.2 GROUPS LOCATION 3
 2.2.3 MACHINE LAYOUT 4
 2.2.4 TECHNICAL FEATURES 4
2.3 INTENDED USE 4
2.4 NOISE 4

SECTION 3 - INSTALLATION

3.1 ROOM NECESSARY TO THE MACHINE USE 2
 3.1.1 LOCATION 2
3.2 MACHINES WITH AIRCOOLED CONDENSER 2
3.3 WATER CONNECTION 3
3.4 ELECTRIC CONNECTION 3
 3.4.1 REPLACING A POWER CABLE 3
3.5 CLEANOUT 4
3.6 REFILLING 4
3.7 MACHINE TESTING 4

SECTION 4 - INSTRUCTIONS FOR USE

4.1 MACHINE SAFETY WARNINGS 2

4.2 MACHINE CONFIGURATION 2

4.3 CONTROLS 3

4.3.1 CONTROL PANEL 3

4.3.2 COMMON FUNCTIONS 3

4.4 PRELIMINARY OPERATIONS, WASH AND STERILIZATION 5

4.4.1 CLEANOUT 5

4.4.2 STERILIZATION 6

4.4.3 HYGIENE 6

4.5 MACHINE STARTING 7

4.5.1 USE OF MIX DISPENSING SPIGOT 7

SECTION 5 - SAFETY DEVICES

5.1 MACHINE SAFETY DEVICES 2

SECTION 6 - CLEANING, DISASSEMBLING AND REASSEMBLING PARTS IN CONTACT WITH THE PRODUCT

6.1 PERIODICAL CLEANOUT 2

6.2 PARTS DISASSEMBLY 2

6.2.1 DISASSEMBLING PRODUCT DISPENSING SPIGOT 2

6.2.2 DISASSEMBLING THE TANK COVER 3

6.2.3 DISASSEMBLING THE BEATER 4

6.3 STERILIZATION 5

6.4 HYGIENE 5

SECTION 7 - MAINTENANCE

7.1 SERVICING TYPOLOGY 2

7.2 CLEANING THE CONDENSER 3

7.3 ORDERING SPARE PARTS 3

7.4 SPARE PARTS EQUIPMENT 4

SECTION 8 - TROUBLESHOOT GUIDE

8 TROUBLESHOOT GUIDE 2

FOREWORD

INSTRUCTIONS HANDBOOK

Editing this handbook, community directions on safety standards as well as on free circulation of industrial products within E.C. (R.E.C. Council direction 89/392 and subsequent, known as "Machines Direction") were taken into due account.

PURPOSE

This handbook was edited while taking needs of machine users into due account. Topics relevant to a correct use of the machine have been analyzed in order to keep unchanged in the long run quality features characterizing **PROMAG** machines throughout the world. A significant part of this handbook refers to the conditions necessary to the machine use and to the necessary behaviour during cleanout as well as routine and special maintenance. Nevertheless, this handbook cannot meet in details all demands; in case of doubts or failing information, please apply to:

PROMAG ALIS.p.A - Via Emilia, 45A - 40011 Anzola Emilia (Bologna) - Italy
(051)6505330 - Fax (051)6505331

Tel.

HANDBOOK STRUCTURE

This handbook is structurilized in sections, chapters and subchapters in order to consult it more easily.

Section

A section is the part of handbook identifying a specific topic referred to a machine part.

Chapter

A chapter is that part of section describing a group or concept relevant to a machine part..

Subchapter

It is that part of a chapter detailing the specific component of a machine part.

It is necessary that each person involved in the machine running reads and clearly understands those parts of the handbook of own concern, and particularly:

- The Operator must have a look at chapters concerning the machine start-up and the operation of machine groups.
- A skilled technician employed in installation, maintenance, repair, etc., must read all parts of this handbook.

ADDITIONAL DOCUMENTATION

Along with an instruction manual, each machine is also supplied complete with further documentation:

- **Machine equipment:** A list of spare parts delivered together with the machine for its maintenance.
- **Wiring diagram:** A diagram of wiring connections put into the machine.

ATTENTION!

Before operating the machine, carefully read this handbook.

Also carefully safety instructions





SAFETY

When using industrial equipment and plants, one must be aware of the fact that drive mechanisms (rotary motion), high voltage components, as well as parts subject to high temperatures, may cause serious damages to persons and things.

Who is in charge of plant safety must be on the look-out that

- An incorrect use or handling is avoided.
- Safety devices are neither removed nor tampered.
- The machine is regularly serviced.
- Only original spare parts to be used especially as far as those components with safety functions are concerned (ex.: protection microswitches, thermostats).

To achieve the above, the following is necessary:

- At working place an instruction manual relevant to the machine should be available.
- Such documentation must be carefully read and regulations must consequently be followed.
- Only must adequately skilled personnel be assigned to electrical equipment.

QUALIFICATION OF THE STAFF

Staff attached to the machine can be distinguished according to training and responsibility as follows:

OPERATOR

- A person who has not necessarily a high technical knowledge, just trained for ordinary operation of the machine, such as: startup, stop, filling, basic maintenance (cleanout, simple blocking, instrumentation checkings, etc.).

SKILLED ENGINEER


- A person engaged on more complicated operations of installation, maintenance, repairs, etc.

IMPORTANT!

One must be on the look-out that the staff does not carry out any operation outside its own sphere of knowledge and responsibility.

NOTE:

According to the standard at present in force, a **SKILLED ENGINEER** is who, thanks to training, experience and education,
 - knowledge of rules, prescriptions and interventions on accident prevention,
 - knowledge of machine operating conditions,
 is able to realize and avoid any danger and has also been allowed by the person in charge of plant safety to carry out all kinds of interventions.



CONVENTIONAL SYMBOLS

ATTENTION: ELECTRIC SHOCK DANGER

The staff involved is warned that the inobservance of safety rules in carrying out the operation described may cause an electric shock.



ATTENTION: GENERAL DANGER

The staff involved is warned that the operation described may do harm if not carried out in the observance of safety rules.



NOTE

It points out significant information for the staff involved.



WARNINGS

The staff involved is warned that the inobservance of information may cause a loss of data and damages to the machine.



MACHINE OPERATOR

It deals with an unskilled person, who has no specific competences and can only carry out easy functions, such as the machine operation by means of controls available on push-button panel, and filling and drain of products used during production.



MAINTENANCE ENGINEER

He is a skilled engineer for operation of the machine under regular conditions; he is able to carry out interventions on mechanical parts and all regulations, as well as maintenance and repairs. He is qualified for interventions on electrical and freezing plants.




PROMAG ENGINEER

It deals with a skilled engineer the manufacturer puts at clients' disposal for complicated interventions and particular conditions or anyhow in accordance with agreements taken with the machine's user.




PROTECTIONS

This symbol placed by description side means that the operator must use personal protections against an implicit risk of accident.



- When installing the machine, insert a differential magnetothermal protection switch on all poles of the line, adequately sized to the absorption power shown on machine data plate and with contact opening of 3 mm at least.
- Never put your hands into the machine, alike during production and cleaning operations.
- Before carrying out any maintenance operation, make sure that the machine is in "STOP" position and main switch has been cut out.
- It is forbidden to wash the machine by means of a bolt of water under pressure.
- It is forbidden to remove panels in order to reach the machine inside before disconnecting the machine.
- **PROMAG** is not responsible for any accident that might happen during operation, cleaning and/or servicing of its units, if this warning has not been fully complied with.




WARNING

RECEIVING, MOVING, UNPACKING

SECTION INDEX

1.1	RECEPTION	2
	1.1.1 LIFTING PACKED MACHINES	2
	1.1.2 FORBIDDEN MATERIAL HANDLING EQUIPMENT	3
1.2	UNPACKING	3
1.3	STORING THE MACHINE	5
1.4	DISPOSAL OF PACKING STUFFS	5



To lift the packing, insert lift forks into the space between pallet feet, so as to balance the machine weight and consequently packing barycenter.

1.1 LIFTING PACKED MACHINES

- Before unpacking the machine, check that packing shows no external damages due to collisions during transportation.
- An external damage could mean the machine itself is damaged: in this case, immediately apply to insurance company and leave everything as it was on reception.

1.1 RECEPTION



1.1.2 FORBIDDEN MATERIAL HANDLING EQUIPMENT

Material handling equipment not in compliance with following safety characteristics must never be used:

- Lifting capacity lower than machine weight
- Unsuitable construction features of the lift (ex.: too short forks)
- Construction features altered by use
- Unconforming ropes and cables
- Worn ropes or cables.



1.2 UNPACKING

There are two types of packing: wooden type or in corrugated board.


Walls of a wooden packing are nailed and the machine is fastened by means of stay bolts connecting machine frame bottom to packing wooden base.

A wooden packing can be opened by means of proper tools; it is recommended to protect exposed parts, such as hands with gloves, against wood splinters.

- Remove nails starting from the upper part until the machine still fastened to the pallet (board) is left uncovered.
- Remove protection film wrapping the machine.
- Check that the machine has not been damaged during transportation.




ATTENTION!
 Inside the machine you will find an instructions handbook; it is necessary to carefully read it before operating the machine.




Act with utmost care, as you may hurt yourselves when cutting the straps, if they are not strongly held during this operation.

Board packing is externally closed by three steel straps. The machine is secured through other straps at the inside. This packing can be opened with snips.



1.3 STORING THE MACHINE

The machine must be stored in a dry and damp-free place. Before storing the machine, wrap it in a cloth in order to protect it against dust and else.



IMPORTANT:

When storing a packed machine, never place a crate on another.



1.4 DISPOSAL OF PACKING STUFFS

When opening the packing crate, divide packing stuffs per type and get rid of them according to laws in force in the machine installation country.



SECTION 2

GENERAL INFORMATION

SECTION INDEX

2.1	GENERAL DATA	2
2.1.1	MANUFACTURER'S IDENTIFICATION DATA	2
2.1.2	USER'S/CLIENT'S IDENTIFICATION DATA	2
2.1.3	INFORMATION ABOUT SERVICE	2
2.1.4	INFORMATION TO THE USER	2
2.2	INFORMATION ABOUT THE MACHINE	3
2.2.1	GENERAL INFORMATION	3
2.2.2	GROUPS LOCATION	3
2.2.3	MACHINE LAYOUT	4
2.2.4	TECHNICAL FEATURES	4
2.3	INTENDED USE	4
2.4	NOISE	4

PROMAG

2.2 INFORMATION ABOUT THE MACHINE

2.2.1 GENERAL INFORMATION

The machines **STARCOMPACT** are ice cream mix ageing vats.

An electronic microprocessor steadily controls the working cycle.

An alphanumerical display gives messages, as well as audible and visual signals on each cycle stage.

Aging is an important mix working phase because thickening, emulsifying and stabilizing agents can bind together with fat fractions.


Time taken to such binding processes is a minimum of 4 hours to a maximum of 12 hours.

PROMAG recommends to always use high quality ingredients for the preparation of confectionery products, in order to satisfy your customers, even the hardest-to-please ones. Any saving made to the prejudice of quality will surely turn into a loss much bigger than the saving itself.

Bearing in mind the above statements, please take heed of the following suggestions:

- Choose high quality natural ingredients or buy semifinished products from reliable companies.
- Closely follow instructions given by your supplier .
- Do not alter your supplier's recipes, by adding, for instance, water or sugar.
- Taste your products before serving and start selling only if entirely satisfactory.
- Make sure your staff always keeps the machine clean.
- Have your machine serviced always by companies authorized by **PROMAG**.

2.2.2 GROUPS LOCATION



Caption:

Ref.1 Tank cover
Ref.2 Control panel
Ref.3 Dispensing spigot

Sound levels, ambient background noises included, are indicated. Machine noise level is below 70dB (A).

2.4 NOISE

This machine has been designed for its use in places which are not subject to explosion-proof standards; its use is thus bound to conforming places and normal atmosphere.

- Voltage: ±10%
- Min. air temperature: 10°C
- Max. air temperature: 43°C
- Max air relative humidity: 85%

2.2.1 "General information" within operational ranges herebelow reported: STARCOMPACT models must only be used in conformity with descriptions given in paragraph

2.3 INTENDED USE


Performances features are at a room temperature of 25°C

* Other voltages and cycles are available.

MODEL	Tank capacity			Tank min. level		Tank max. level		Electric power		Productio per cycle		Condenser		Net/gross weight
	litres	litres	litres	litres	litres	volt	Hz	ph	litres	litres	kg	kg		
STAR COMPACT 120	120	40	120	220	50	1	120	Air	145/175					
STAR COMPACT 60	60	20	60	220	50	1	60	Air	100/130					

2.2.4 TECHNICAL FEATURES

MODEL	Dimensions		
	Width (W) mm.	Depth (D) mm.	Height (H) mm.
STAR COMPACT 120	640	835	1065
STAR COMPACT 60	389	835	1065



NOTE: Dimensions herebelow reported may change depending on type of condensation.

2.2.3 MACHINE LAYOUT




SECTION 3

INSTALLATION

SECTION INDEX

3.1 ROOM NECESSARY TO THE MACHINE USE	2
3.1.1 LOCATION	2
3.2 MACHINES WITH AIRCOOLED CONDENSER	2
3.3 WATER CONNECTION FOR WASH	3
3.4 ELECTRIC CONNECTION	3
3.4.1 REPLACING A POWER CABLE	3
3.5 CLEANOUT	4
3.6 REFILLING	4
3.7 MACHINE TESTING	4


PROMAG



CAUTION!
An insufficient air circulation of the machine affects its operation and output capacity.


Machines with aircooled condenser must be installed no closer than 50 cm to any wall in order to allow free air circulation around the condenser.

3.2 MACHINES WITH AIRCOOLED CONDENSER



For an easy movement, the machine has been provided with castors having mechanical locks which, once engaged, lock the castors and so keep the machine standstill.

3.1.1 MACHINE LOCATION




The machine must be installed in such a way that air can freely circulate all around. Room for the approach to the machine must be left free in order to enable the operator to act without constraint and also to immediately leave the working area, if need be. The minimum approach room to the working area should be at least 150 cm.

3.1 ROOM NECESSARY TO THE MACHINE USE



3.3 WATER CONNECTION FOR WASH

The machines have been provided with a separate inlet water pipe, which is placed beneath the machine lower surface and must be used for washing water connection. Only has drinking water to be connected to this pipe which is marked as per plate shown herebelow.



To make cleanout easy, we recommend to connect warm water used in your laboratory directly to wash pipe, installing a shut-off valve.

3.4 ELECTRICAL CONNECTION

Before connecting the machine to the mains, check that the voltage is the same as the one stated on its plate. Between the machine and the mains, insert a magnetothermic differential sectioning switch properly dimensioned to the input required, and having a contact opening of 3 mm, at least.

The machines are delivered complete with a power cable (a 5-wire cable by threephased machines and a 3-wire cable by siglephased machines); blue wire must be connected to the neutral one.

IMPORTANT

Yellow/green ground wire must be connected to a good ground plate.


3.4.1 REPLACING POWER SUPPLY CABLE

Should the main cable of the machine be damaged, it needs to be replaced immediately through a cable with similar features.

Replacement shall be carried out by skilled technicians, only.

CAUTION!

For a less wear of the shaft, always keep the yellow cover (pos. 236) inserted.



A postproduction test of the machine is carried out at PROMAG premises; operation and output functionality of the machine are thoroughly tested. Machine test at end user's must be carried out by skilled technicians or by one of PROMAG engineers. After the machine positioning and correct connections, also carry out all operations necessary to functional check and test of the machine.

3.7 MACHINE TESTING



Motor installed in the machine is of the type with lubrication for life; no action of checking/ replacing or topping up is necessary. Gas filling necessary to the cooling system is carried out at PROMAG works during machine postproduction testing; new machines do not require topping-up or refilling. If a gas addition happens to be made, this must be carried out by skilled technicians, only, who can find out trouble origin.

3.6 REFILLING

CAUTION!
Do not use either solvents, or alcohol and detergents that may damage the machine parts and contaminate parts coming into contact with product.

Eliminate dust from machine, as well as the protective material the machine was stewed with. Use just water and, if need be, add a soap-based mild detergent with a soft cloth.


3.5 CLEANOUT



INSTRUCTIONS FOR USE

SECTION INDEX

4.1 MACHINE SAFETY WARNINGS	2
4.2 MACHINE CONFIGURATION	2
4.3 CONTROLS	3
4.3.1 CONTROL PANEL	3
4.3.2 COMMON FUNCTIONS	2
4.4 PRELIMINARY OPERATIONS, WASH AND STERILIZATION	6
4.4.1 CLEANOUT	6
4.4.2 STERILIZATION	7
4.4.3 HYGIENE	7
4.5 MACHINE STARTING	9
4.5.1 USE OF MIX DISPENSING TAP	9




The machine consists of a transmission of movement for beater assembly and a dry cooling system with air-cooled condenser. The product is prepared by pouring the mix into the tank and starting the aging cycle, while referring to minimum and maximum quantities mentioned in paragraph 2.2.4 "Technical features".

4.2 MACHINE CONFIGURATION

To achieve the above, the following is necessary:

- At working place an instruction manual relevant to the machine should be available.
- Such documentation must be carefully read and regulations must consequently be followed.
- Only must adequately skilled personnel be assigned to electrical equipment.



When using industrial equipment and plants, one must be aware of the fact that drive mechanisms (rotary motion), high voltage components, as well as parts subject to high temperatures may cause serious damages to persons and things.

Who is in charge of plant safety must be on the look-out that

- an incorrect use or handling is avoided
- Safety devices are neither removed nor tampered
- The machine is regularly serviced
- Only are original spare parts to be used especially as far as those components with safety functions are concerned (ex.: protection microswitches, thermal relays).




4.1 MACHINE SAFETY WARNINGS


4.3 CONTROLS

4.3.1 CONTROL PANEL

For a correct use of push-buttons on the electronic keyboard, press on the symbol or anyway in the middle of the push-button itself.



4.3.2 COMMON FUNCTIONS




Function insert light indicator

When a light indicator lights on, it indicates the insert of the function corresponding with the symbol by side of light indicator itself.




Display (pos. 570)

This digital display gives a series of messages when machine is turned on and during its use. It normally indicates the real and current temperature of the mix inside the tank.



STOP/RESET key


When STOP function is inserted, the relevant red light is on. The STOP key stops any other function and it is the mode the machine sets at when you turn it on.



TAP WATER (for cleaning after dispensing the mix)

Tap water inlet is enabled from any function. To deliver water, it is enough to press TAP WATER just once; inlet will automatically end after a time that can be set between 1/10 second and 9 seconds.

For time programming, see paragraph COOLING.



IMPORTANT: The machine is provided with an automatic water block device and after 3 minutes it stops water inlet and returns to STOP position.

Tank water inlet ends by pressing STOP key



water inside the tank. During water delivery, the display shows the real temperature of The latter is however deactivated on pressing WASH WATER key. active.

WATER INLET key or while TAP WATER inlet is still



This function can be activated with machine at STOP, by pressing light. The function insert is indicated by lighting on of relevant warning

WASH WATER



Pressing STOP is another way to leave programming mode. programmed original operation. and remains on permanently, so indicating the return to the If no key is pressed for about 3 seconds, cooling led stops blinking repeatedly.



second and a maximum of 9 seconds by pressing TAP WATER relevant led; such time can be modified within a minimum of 1/10 you program tap water inlet time; this will be indicated by blinking of Pressing COOLING for the second time, while still blinking,



+6°C. To change storage temperature press TAP WATER until the display will show the new value, which can be changed +2°C to




about 3 seconds while this function is active; relevant led blinks and the display indicates the storage temperature set (usually +4°C).

temperature, it is necessary to keep down COOLING key temperature, As soon as the temperature raises by 2°C as to the temperature set, compressor and beater start again in order to bring the temperature back to its programmed value. If you wish to change the storage back to its programmed value. If you wish to change the storage

beater are cut out. If the temperature remains within the desired range, compressor and display indicates the real mix temperature. During cooling process, beater and compressor are connected and the (it can be programmed 2 to 6°C).

The function insert is indicated by lighting on of its warning light and cooling keeps on running up to reaching a preset storage temperature

COOLING




4.4 PRELIMINARY OPERATIONS, WASH AND STERILIZATION


Before starting the machine for the first time, it is necessary to clean its components thoroughly and then also sterilize all parts in contact with the product.

IMPORTANT


Cleanout and sterilization must be carried out at the end of every working day, as a habit and with utmost care, in order to guarantee high quality and the observance of all healthy rules.

4.4.1 CLEANOUT

- With machine not operating and STOP light  on, make sure that the mix dispensing tap is closed.

- Let water necessary to wash in, by pressing SHOWER key .

- Leave water inside the tank.

- Press "STOP"  ..

- Drain all water from the tank through the dispensing tap.

- Open the tank cover. Remove the beater (see disassembling instructions Sect. 6) by slightly pulling it upwards and minding not to damage it.

- Wash all parts in water.

- Also wash inside tank walls and tank cover.

- Disassemble the tap (see disassembling instructions Section 6), thoroughly wash and remount.

- Reassemble all disassembled parts after lubricating ORs with a film of edible fat, such as GELILUBE.



Mildew and bacteria grow rapidly in mix fat contents. To eliminate them, it is necessary to wash and clean all parts in contact with the mix, as described above.

Stainless steel and plastic materials, as well as rubber used in the construction of these parts, and also their particular shapes and design make cleanout easy, but cannot prevent proliferation of mildew and bacteria if not properly cleaned.

4.4.3 HYGIENE

CAUTION
Do not touch sterilized parts with hands, napkins, or else.

CAUTION
Before using the machine again, thoroughly rinse with just water, in order to remove residues of sterilizing solution.

With machine not operating, after removing the beater and the cover, and checking that the dispensing spigot is closed, fill the tank with a NON CORROSIVE sterilizing solution.

Drain the sterilizing solution through the dispensing tap.

4.4.2 STERILIZATION






4.5 MACHINE STARTING

After washing, sterilizing and thoroughly rinsing the machine right before its use, as per our previous descriptions, pour mix into the tank according to the desired quantity but also respecting minimum and maximum quantities reported in the table (sect. 2, page 4); the tank is provided with an internal graduation which indicates the approximate mix contents.


Before filling the tank with mix, make sure that the dispensing tap is perfectly closed.

Note: A non perfectly closed tank cover will not allow the machine operation.

You can start the machine, now.

The machine working cycle starts by selecting STOP  position.

Press COOLING key



4.5.1 USE OF MIX DISPENSING TAP

In order to dispense the mix, it is necessary to turn the white tap knob anticlockwise, all to the leftside.

Closing

To close the dispensing tap, turn the knob all to the rightside, to closing position.

Vertical text on the left margin, possibly a page number or index.

Main body of the document containing several paragraphs of text, which is mostly illegible due to extreme blurriness.

SECTION 5

SAFETY DEVICES

SECTION INDEX

5.1	MACHINE SAFETY DEVICES	2
-----	------------------------------	---

PROMAG

5.1 MACHINE SAFETY DEVICES

STARCOMPACT are provided with a series of safety devices for the sake of machine and operator's safety.

CAUTION!

PROMAG is not responsible for any damage to people and/or things caused by changes on machine or tamperings on devices provided for the operator's and machine safety

The tripping of each safety device comes up to an alarm on control panel display. Please find herebelow a list of above mentioned ALARMS:

P1 TANK COVER OPEN

Whenever the tank cover is opened while the machine is running, the machine stops immediately and will only restart after closing the tank cover (automatic reset 2 seconds after closing).

P4 "TEI" TEMPERATURE SENSOR

Check the temperature sensor which must be interrupted anyway on the cable of the sensor itself (wire broken or element in sensor bulb disconnected) or under short circuit (on connector or on the element of sensor bulb).
This alarm also takes place when the sensor is disconnected from the terminal board in the wiring box.

Connect the wire or replace the sensor, if need be.

P7 PRESSURE SWITCH ALARM


When this alarm occurs, the machine stops immediately; therefore make sure that nothing is obstructing water flow to the condenser (by watercooled machines) or that the cooling fan works properly (by aircooled machines).
Anyway, call an expert engineer.



CLEANING, DISASSEMBLING AND REASSEMBLING PARTS IN CONTACT WITH PRODUCT

SECTION INDEX

6.1	PERIODICAL CLEANOUT	2
6.2	PARTS DISASSEMBLY	2
6.2.1	DISASSEMBLING PRODUCT DISPENSING TAP	2
6.2.2	DISASSEMBLING THE TANK COVER	3
6.2.3	DISASSEMBLING THE BEATER	4
6.3	STERILIZATION	5
6.4	HYGIENE	5



- Disassemble the tap knob pos. 450, by turning it anticlockwise.
- Disassemble then all other parts of the tap.
- Wash all parts in water using the special brush you can find in the accessories kit.
- Reassemble, keeping in mind to lubricate all ORs previously removed with the edible fat provided.

6.2.1 DISASSEMBLING THE PRODUCT DISPENSING TAP

6.2 PARTS DISASSEMBLY

- Press STOP
- Drain all water from the tank through the product dispensing tap.
- Disassemble the machine parts, as described in previous paragraphs.
- Wash all parts in water.
- Reassemble all parts while lubricating all ORs with a film of edible fat, such as GELLILUBE.




- Make sure that the mix tap is closed, let then water in, according to quantity necessary



6.1 PERIODICAL CLEANOUT

Cleanout and sterilization must be carried out at the end of every working day as a habit and with utmost care in order to guarantee quality of production in the respect of all hygienic rules.

IMPORTANT



DISASSEMBLING THE TANK COVER

NOTE:



The machine is provided with a safety device on its cover; every time you lift the cover while the machine is running, the machine will stop.


- Tank cover pos. 250 is completely removable.
- Place the cover vertically; deeply push on cover until its pin comes out.
- Withdraw the tank cover by lifting it vertically and pushing forward on the fixed hinges 253-254.

NOTE:

One can also remove just the cover by taking it out from fastening hinges which will remain fastened to the machine.

Wash the whole thoroughly and reassemble.





The beater is correctly reassembled when the spline on the beater shaft pos. 313 perfectly agrees with the one of drive shaft pos.161.

CAUTION!



- Wash the beater parts;
- Reassemble all parts previously disassembled, following the reverse procedure.

Act and handle with utmost care, as a fall to the ground might damage the beater.

WARNING

- Withdraw the beater vertically by pulling it slightly upwards and minding not to damage its blades;
- Remove plug pos. 154;

6.2.3 DISASSEMBLING THE BEATER



6.3 STERILIZATION

With machine not operating, after reassembling beater and cover and checking that tap pos. 505 is closed, fill the tank with a NON CORROSIVE sterilizing solution.

CAUTION

Too a long running in "BEATING" position with empty tank or just filled with water and sterilizing solution, brings about a quick wear of the beater.

Drain all sterilizing solution by opening the dispensing tap.

CAUTION

Before starting again with production, rinse thoroughly with just water, in order to remove any residue of sterilizing solution.

CAUTION

Do not touch the sterilized parts with hands, napkins, or else.

6.4 HYGIENE

Mix fat contents are ideal fields for proliferation of mildew and bacteria. To eliminate them, parts in contact with mixes and creams must thoroughly be washed and cleaned. Stainless steel materials as well as plastic and rubber ones used for the construction of these parts and their particular design make cleaning easy, but cannot prevent the growth of mildew and bacteria if not properly cleaned.



[The main body of the document contains extremely faint and illegible text, likely bleed-through from the reverse side of the page. The text is too light to transcribe accurately.]

SECTION 7

MAINTENANCE

SECTION INDEX

7.1 SERVICING TYPOLOGY	2
7.2 CLEANING THE CONDENSER	3
7.3 ORDERING SPARE PARTS	3
7.4 SPARE PARTS EQUIPMENT	4

PROMAG

7.1 SERVICING TYPOLOGY

ATTENTION

Any servicing operation requiring the opening of machine panels must be carried out with machine set at stop and disconnected from main switch!

Cleaning and lubricating moving parts is forbidden!

Repairs of electrical and freezing plants must be carried out by skilled engineers!

Operations necessary to a proper machine running are such that most of servicing is completed during production cycle.
Servicing operations, such as cleaning of parts in contact with the product, replacing of stuffing box, disassembling of beater assembly are to be carried out at the end of a working day, so as to speed up servicing operations required.

Herebelow you can find a list of routine servicing operations:

- **Cleanout of beater assembly**
At the end of a working day
- **Cleanout of panels**
To be carried out daily with neutral soap, seeing to it that no cleansing solution reaches the beater assembly at its inside.
- **Cleanout and sterilization**
At the end of every working day, according to procedures described in section 6.

WARNING


Never use abrasive sponges to clean machine and its parts, as you might scratch their surfaces.



7.2 CLEANING THE CONDENSER

Clean the air condenser, periodically, in order to remove dust and impurities that may hinder air circulation.

Use a brush with long bristles or a bolt of compressed air.



ATTENTION!


When using compressed air, put on personal protections in order to avoid accidents; put on protective glasses!

CAUTION

Never use sharp metal objects to clean the condenser; good working of the freezing plant mostly depends on condenser cleanout.


7.3 ORDERING SPARE PARTS

In the event of breaking or wear of one or more parts, request the new ones directly to the local Distributor, who will provide repair and replacement through original **PROMAG** spare parts.



PROMAG

7.4 SPAREPARTSEQUIPMENT



Q.ty	Description	Position Nr
Nr 1	OR extractor	72
Nr 1	ring nut 121.D15/000.4	78
Nr 3	Rubber pipe fitting 3/4 FxD, 16	287
Nr 1	Rubber pipe fitting 144.D15/000.4	287A
Nr 3	Pipe fitting gasket	352
Nr 1	Gasket 131.D15/000.S	352A
Nr 1	Brush D 30x640	772
Nr 1	Gelilube tube	830
Nr 1	Cleaning brush	840
Nr 2	OR	1225

TROUBLESHOOT GUIDE

SECTION INDEX


8.1	TROUBLESHOOT GUIDE	2
-----	--------------------------	---

8.1 TROUBLESHOOT GUIDE

Trouble	Possible cause	Advised cures
Machine does not turn on	Supply mains	Check the supply mains
Keyboard does not turn on	Connection cable	Check connection, connector keyboard/card and cable
	Fuse on secondary circuit of transformer is burnt	Replace the fuse (F2A)
	8-pin connector is disconnected	Connect 8-pin connector
	CPU	Replace CPU
Keyboard does not accept a function button	Keyboard	Replace the keyboard Call after-sale service
Keyboard is completely off and no function starts when pressing its keys.	Eprom not installed or installed from wrong side Keyboard and/or CPU	Install Eprom correctly Replace keyboard and/or CPU
Icing inside the tank	Product does not exchange properly	Check sensors setting
Heating does not start (resistances not activated)	Faulty sensor Resistance disconnected	Using pasteurization key, check, from beating, temperatures of TEC and TEV sensors. Replace the sensor not to scale With machine off, check the resistance in Ohm at the terminals of heating elements. If there is no resistance in ohm, it is necessary to replace the spigot body.



PROMAG
LE MACCHINE PER IL GIULIATO



STARCOMPACT 60

LISTA DI RICAMBI
LIST OF SPARE PARTS
LISTE DES PIÈCES DE RECHANGE
ERSATZTEIL - LISTE
LISTA DE REPUESTOS

Come consultare il MANUALE PARTI DI RICAMBIO:

Il Manuale Parti di Ricambio è costituito da Tavole grafiche e da Tabelle.

Tavole grafiche:

Le tavole riportano il disegno esplosivo dei gruppi principali della macchina.

La suddivisione delle tavole è identificata nella TAV.0.

Ogni particolare di ricambio è identificato da un numero di posizione, i numeri di posizione posti in un riquadro identificano i particolari di ricambio consigliati.

Tabelle:

Le tabelle riportano i Numeri di Posizione, la Descrizione ed il Codice del particolare.

Nel caso in cui lo stesso numero di posizione sia riportato più volte, ma associato a codici differenti, è necessario, all'atto dell'ordine, specificare la matricola della macchina in possesso del cliente, al fine di identificare il codice del particolare da fornire.

Per ordinare uno o più particolari di ricambio identificare sulla TAV.0 la tavola in cui è rappresentato il gruppo macchina in cui è presente il particolare, identificare quindi sulla tavola il particolare ed il relativo numero di posizione, quindi ricercare sulle tabelle il numero di posizione ed il corrispondente codice.

How to consult the SPARE PARTS MANUAL:

The Spare Parts Manual is made up of Drawing Plates and Tables.

Drawing Plates:

The plates contain the exploded views of the main units comprising the machine.

The subdivision of the plates is listed on "TAV.0".

Each spare parts item is identified by a position number, position numbers found in a box indicate the spare parts items recommended.

Tables:

The tables list the Position numbers, Descriptions and the Codes for items.

When the same position number appears more than once, but is also associated with different codes, specify the serial number of the customer's machine when ordering for the purpose of identifying the code for the item to be supplied.

To order one or more spare part items, identify the plate on "TAV.0" representing the machine unit on which the item is located. Locate the item on the plate and the corresponding position number as well. Then use the position number to locate the corresponding code on the table.

Comment consulter le LIVRET DES PIÈCES DÉTACHÉES:

Le livret des Pièces Détachées se compose de Planches et de Tableaux.

Planches:

Les planches illustrent la vue éclatée des groupes principaux de la machine.

La "TAV.0" illustre la subdivision des différentes planches.

Chaque pièce détachée est identifiée par un numéro de repère; les numéros de repère en encadré identifient les pièces détachées conseillées.

Tableaux:

Les tableaux indiquent les Numéros de repère, la Désignation des pièces et les Codes des pièces en question.

Si la même numéro de repère indique plusieurs fois mais qu'il est associé à des codes différents, lors de la commande il faut préciser le numéro de série de la machine; cela permettra d'identifier le code de la pièce à fournir.

Pour commander une ou plusieurs pièces détachées, repérer sur la "TAV.0" la planche représentant le groupe dont fait partie la pièce. Ensuite identifier la pièce en question sur la planche ainsi que son numéro de repère, puis rechercher sur les tableaux le numéro de repère et le code y relatif.

Hinweise für die Konsultation des ERSATZTEILHANDBUCHES

Das Ersatzteillhandbuch besteht aus graphischen Abbildungen und Tabellen.

Graphische Abbildungen:

Die Abbildungen umfassen die Detailzeichnung der Hauptaggregate der Maschine

Die Aufgliederung der Abbildungen ist in "TAV. 0" angegeben.

Jedes Ersatzteildetail ist mit einer Positionsnummer identifiziert; die eingetragenen Positionsnummern identifizieren die empfohlenen Ersatzteildetails.

Tabellen:

In den Tabellen sind die Positionsnummern, die Beschreibung und der Code des Teils aufgelistet.

Ist dieselbe Positionsnummer mehrmals in Zusammenhang mit anderen Code angegeben, muß bei der Bestellung die Maschinennummer angegeben werden, um den Code des zu liefernden Ersatzteils ausfindig machen zu können.

Um eines oder mehrere Ersatzteile zu bestellen, anhand der "TAV.0" die Abb. feststellen, in der das Maschinenelement dargestellt ist. Für das Teil bestimmt ist, anhand dieser Abb. dann das Ersatzteil und die entspr. Positionsnummer identifizieren und schließlich in den Tabellen die Positionsnummer und den entspr. Code suchen.

COMO CONSULTAR EL MANUAL DE PIEZAS DE REPUESTO

El Manual Piezas de Repuesto está formado por Tablas gráficas y por Cuadros

Tablas gráficas

Las tablas indican el dibujo expuesto individualmente en todos sus particulares (tridimensional) de los grupos principales de la máquina

La subdivisión de las tablas está identificada en la "TAV. 0".

Cada pieza de repuesto se identifica por un número de posición, los números de posición colocados en un recuadro identifican las piezas de repuesto aconsejadas.

Cuadros

Los Cuadros indican los Números de Posición, la Descripción y el Código de la pieza.

En el caso de que el mismo número de posición esté indicado más de una vez, pero asociado a códigos diferentes, es necesario, en el momento del pedido, especificar la matrícula de la máquina que posee el cliente, con el fin de identificar el código de la pieza que hay que suministrar.

Al hacer el pedido de una o más piezas de repuesto, identificar en la "TAV. 0" la tabla en la que está representado el grupo máquina en donde se halla la pieza, por consiguiente identificar en la tabla la pieza y el relativo número de posición, después buscar en los cuadros el número de posición y el correspondiente código.



PROMAG
LE MASCHINE FÜR ALLE ANW.

STARCOMPACT 60

Codice Macchina - Machine Code: 840817020
Ed.09/99

Pos.	Cod.	Descrizione	Description	Description	Bezeichnung	Descrizione
019	131160660	CONDENSATORE ARIA CONTARDO	AIR CONDENSER	CONDENSATEUR A AIR	LUFT KONDENSATOR	CONDENSADOR AIRE
031	177110350	VALVOLA MEMBRANA SILIC.BIANCO	VALVE	SOUPE	VENTIL	VALVULA
055	171195040	ATTACCO TUBO GOMMA	CONNECTION	CONNEXION	ANCHLUSS	CONEXION
072	193010040	ESTRATTORE OR	O-RING EXTRACTOR	EXTRACTEUR DE JOINTS	O-RING AUSHEBER	EXTRACTOR
091	175100590	SPINA ALBERO AGITAZIONE	PIN	CHEVILLE	STIFT	CHAVETA
102	158185130	GHIERA ATTACCO RAPIDO	RING NUT	COLLIER DE SERRAGE	SICHERUNGSRING	ABRAZADERA
102A	158175030	GHIERA ATTACCO TUBO GOMMA	RING NUT	COLLIER DE SERRAGE	SICHERUNGSRING	ABRAZADERA
139	173115380	ROS.PIANA 6 18 1,5 A2	WASHER	RONDELLE	SCHEIBE	ARANDELA
139A	173125130	ROS.PIANA 12 62 3 GOMMA	WASHER	RONDELLE	SCHEIBE	ARANDELA
159	155101680	ALBERO TRASMISSIONE MOTO	DRIVE SHAFT	ARBRE DE TRANSMISSION	ANTRIEBSWELLE	ARBOL DE TRANSMISION
161	529410305	BOCCOLA MB 08.12 DU/B	BUSHING	BAGUE	BUCHSE	CASQUILLO
161A	529410307	BOCCOLA MB 14.20 DU/B	BUSHING	BAGUE	BUCHSE	CASQUILLO
161B	157120190	BOCCOLA COLLEG.ALBERO E MOTORE	BUSHING	BAGUE	BUCHSE	CASQUILLO
161C	157135150	BOCCOLA SUPPORTO DOCCETTA	BUSHING	BAGUE	BUCHSE	CASQUILLO
162	155103280	ALBERO VENTOLA AGITAZIONE	MIX TANK AGITATOR	AGITATEUR CUVE	RUEHRWERKSBEHAELTE R	AGITADOR MEZCLA EN CUBA
163	164130920	GUIDA ALBERO AGITATORE	AGITATOR SHAFT HOUSING	GUIDE ARBRE	WELLENFUERUNGSMANT EL	GUIA ARBOL
168	561182122	C.UNITE H.CAE9460TF 220240501	COMPRESSOR	COMPRESSEUR	KOMPRESSOR	COMPRESOR
170	551310179	M.VENTILATORE 34W 220/50/60/1	FAN MOTOR	MOTEUR VENTILATEUR	VENTILATOR MOTOR	MOTOR VENTILADOR
176	133119210	VENTOLA D.250	FAN BLADE MOTOR	HELICE MOTEUR VENTILATEUR	VENTILATORFLUEGEL	VENTILADOR
177	583100148	PRESS.DANF.CC20W 29/20 060F1130	PRESSURE SWITCH	PRESSOSTAT	DRUCKWAECHTER	PRESOSTATO
186	192111940	DECALC.FRONTALE	FRONT PANEL DECAL	DECALCOMANIE	ABZIEHBILD	CALCOMANIA





PROMAG
LE MASCHINE FÜR ALLE MASCHINEN


STARCOMPACT 60


Codice Macchina - Machine Code: 840817020
Ed.09/99


Pos.	Cod.	Descrizione	Description	Description	Bezeichnung	Description
425	581300303	ELETTROV.ELBI TIPO 340-9000 220V	WATER SOLENOID VALVE	ELECTROVANNE A EAU	MAGNETVENTIL	ELECTROVALVULA AGUA
433	178100260	MOLLA C I 1,3 15 40 3,68	SPRING	RESSORT	FEDER	RESORTE
447	155130320	ASTA	TAP ROD	LEVIER ROBINET	HAHNSTIFT	VARILLA GRIFO
450	173105280	POMELLO RUBINETTO	FAUCET KNOB	POMMEAU ROBINET	HAHN Griff	BOTON DE GRIFO
459	177110370	VALVOLA CHIUSURA RUBINETTO	CLOSING TAP VALVE	SOUPAPE FERMETURE ROBINET	HAHN ABSPERRVENTIL	VALVULA DE CIERRE DE GRIF
500	558420033	RIDUTT.TR10 1:30 GAVAGNI	GEAR BOX	REDUCTEUR	GETRIEBE	REDUCTOR
575	573800573	PULSANT.MOD.PSK (AGE) SENZA PAN.	PUSH-BUTTON PANEL	CLAVIER	TASTATUR	CAJA DE PULSADORES
600	558420153	MR.MTR 10 1:30 CL.F 22050601	REDUCTION GEAR BOX	MOTO-REDUCTEUR	MOTORGETRIEBE	MOTORREDUCTOR
605	573700160	CENTRAL.AGEMASTER 60+60	ELECTRONIC BOARD	CENTRALE ELECTRONIQUE	ELEKTRONISCHE STEUERKASTE	CENTRALITA ELECTRONICA
607	572910101	SONDA TS TIPO P09251 C.SILIC.	PROBE	SONDE	FUEHLER	SONDA
772	599100123	SCOVOLINO D. 30X640	FINE BRUSH	ECOUVILLON	REINIGUNGSBUERSTE	CEPILLO
830	743000110	TUBETTO PETROL-GEL 3540110	FOOD GRADE LUBRICANT	TUBE DE VASELINE	GELILUBE TUBE	TUBO GELILUBE
840	178600160	SPATOLA PULIZIA	CLEANING SPATULA	SPATULE	SPATEL	PALETA DE LIMPIEZA
912	552120153	M.CARP.M56 4 B14 220/50/60/1	MOTOR FOR GEAR BOX	MOTEUR POUR REDUCTEUR	MOTOR FUER MOTORGETRIEBE	MOTOR MOTORREDUCTOR
921	572910140	SONDA DRY REED N.O. 29	SAFETY SWITCH	SONDE DRY REED	REEDFUEHLER	SONDA DRY REED
924	155280010	NOTTOLINO	PLUG	CLIQUET	KLINKE	TRINQUETE
1225	541000225	OR 3,53 32,93 NB 70 4131	O-RING	JOINT OR	OR-DICHTUNG	JUNTA OR













STARCOMPACT 60



Cod. Documento:	Tav. 04
Codice macchina:	840817020
Rev.	00





PROMAG
Via Benaco, 4
20098 San Giuliano Milanese (MI) - italy
Tel. (02) 98296.1
Fax (02) 9880232

Promag si riserva il diritto di effettuare modifiche e/o revisioni del presente documento senza obbligo di preavviso.
Promag reserves the right to make change and/or revisions of this document without being bound to previously notify it.
Promag se réserve le droit d'apporter toutes modification et mises à jour jugées nécessaires et ce, à tout moment et sans obligation de préavis.
Promag behält sich das Rech vor, jederzeit Änderungen ohne Voranzeige vorzunehmen.
Promag se reserva el derecho de efectuar modificaciones y actualizaciones todas la veces que lo considere necesario sin la obligación de peraviso.

