

This document is valid for:

C120055 / 881154-01-03 Control panel Order No./Specification No. 1 Motor starter 2 Other components 3 **Parameters** 4 5 6 HINE M 7 8 9 10 -

Tetra Pak

Index_en.tm



Declaration of Conformity

Tetra Pak Processing Components AB, Box 103, S-221 00 LUND, Sweden, declares that

Control Panel SCS 92A (Type)

31821-9860-1 (article number) C120055 (serial number)

to which this declaration relates complies with



Directive 89/392 EEC with amendments 91/368 EEC and 93/44 EEC (Machinery Directive).

Directive 73/23 EEC with amendment EEC 93/68 EEC (Low Voltage Directive).



1

Directive 89/336 EEC with amendments EEC 92/31 EEC and 93/68 EEC (EMC-Directive).

Lund, Sweden 15 May 2002

sina Nans Engwall, Product Manager Centrifugal Separatio



Declaration of Conformity

Tetra Pak Processing Components AB, Box 103, S-221 00 LUND, Sweden, declares that

Inverter Starter (Type)

31821-9855-1 (article number) C120055 (serial number)

to which this declaration relates complies with



Directive 89/392 EEC with amendments 91/368 EEC and 93/44 EEC (Machinery Directive).

X

Directive 73/23 EEC with amendment EEC 93/68 EEC (Low Voltage Directive).



Directive 89/336 EEC with amendments EEC 92/31 EEC and 93/68 EEC (EMC-Directive).

Lund, Sweden 15 May 2002

Engwall, Product Manager Centrifugal Separatio Hans

an Anna Anna -ţ

•••

÷

. ·

, · · .

- 1. •

1. Control Panel

1

1. Control Panel

· · ·

This page intentionally left blank

· · · ·


A: Tetra Pak

MM2.2100011en2.fm

.

IM

Instruction Manual Separator Control System SCS92B





ł

This page intentionally left blank

70691en4.fro

Introduction

To the owner	• •	• •	••	•	•	• •	-	•	•	•	•	•	•	•	1
Notice on safety precautions	• •		•••	•	•	• •	•	•	•		•	•	•		2
Health and safety regulations	• •	•		•	•	•••		•	•	•	•	•	•	• •	3

General information

Introduction	5
Technical data	5
Requirements on air and water	7
Consumption material/data7	7
Description	7
Function	3

Installation

70691en4TOC.fm

	13
Storage	13
Unloading and transportation	14
Unpacking and inspection	14
Connections	14
Positioning and erection.	16
Check after Installation	16
Commissioning	16

Operation

	÷ .
	25
Preparation before start	25
Start/Run/Stop	
Alarm function	30
Emergency stop	.35
Start after emergency stop	35
Cleaning	36
F-value readings	.37
Minor adjustments	39

Maintenance	
	Introduction
	Preventive maintenance
	Corrective maintenance
	Parameters 46
Electricity	

Electricity			!	55
-------------	--	--	---	----

Spare parts/components

Spare parts/componen	ts	57
share harrencomhouen	19 • • • • • • • • • • • • • • • • • • •	JI

70691en4_0.1m

To the owner

This instruction manual is your instant guide when dealing with your Tetra Pak equipment.

Tetra Pak advises you to study it carefully, and - above all - to ensure its availability to those who install, maintain and operate the equipment on a daily basis. This documentation will be of no value to you if it is locked away when your personnel needs it!

Furthermore it is important that you:

- keep this instruction manual and other documentation for the life of the equipment
- incorporate any amendments in the text
- pass the documentation on to any subsequent holder or user of the equipment

Tetra Pak will not be responsible for any breakdown of the equipment caused by the owner's failure to follow the instructions given in this document.


This instruction manual describes the authorised way to use the equipment. Tetra Pak will take no responsibility for injury or damage if the equipment is used in any other way.

Notice on safety precautions

Before attempting to unpack, install and operate this unit, please read through concerned part of the manual. Pay particular attention to all dangers, warnings, cautions and notes. Failure to do so could result in serious injury to involved personnel or damage to the equipment.

Use of Danger, Warning, Caution and Note:

Danger, Warning, Caution and Notes used in this manual have the following significance:



Note! Information that requires special emphasis.

Health and safety regulations

Read and follow the instructions in the instruction manual.

- regard all electrical equipment as live.

Before carrying out maintenance and repair:

- switch off power,
- inform the operator and other concerned personnel about the work you intend to do,
- post warning signs,
- take note of warnings given for actual separator.

Read the health and safety regulations for concerned separator.

This page intentionally left blank

70691en4_1.fm

General information

Introduction

The Tetra Pak SCS 92 is an electronic control system specially designed to continuously control the operation of an Tetra Pak separator.

The control system comprises the:


UPPER CABINET consisting of electric and electronic components such as:

- SCS 92 Module
- Switches, relays, timers and push-buttons
- Transformers and fuses.
- LOWER CABINET consisting of water control components such as:
- Solenoid valves
- Reducing valves
- Pressure gauge
- Interconnecting piping

and of air control component such as:

- Reducing valves
- Solenoid valves.

The upper and lower cabinets with their components are on the following pages referred to as a "Control Unit".



Technical data

This description includes data concerning the complete Separator Control System type SCS 92. For technical data on special components please see "Spare parts/components".

Manufacturer: Tetra Pak Processing Components AB

P.O. Box 103, S-221 00 Lund, Sweden

Machine type: SCS 92

Weight: approx. 80 kg.

Electric Power: Power supply voltage:


- 24V AC +10%, -15%
- 50/60 Hz
- External fuse 6A


Control voltage: 24 V DC

Max. ambient temperature 40°C

Measurements:1100 x 600 x 300 mm

Operator position in front of the control cabinet.





Operator position

70691en4_1.fm

6

Requirements on air and water

Compressed air

used as instrument air (valves and instruments).

- dry and oil free
- operating pressure 6 00 +/- 50 kPa
- max. oil content 10 mg/l
- max. water content none
- max. dew point 20°C
- solid particles max. 0.01 mm

Water

used as drinking water and cleaning water. The quality shall meet the WHO guidelines or the European Union's EC drinking water directive.

- min. pressure 400 kPa
- max. pressure 600 kPa
- temperature 10-40°C
- **Note!** Variations in water pressure may influence the discharge volume from the separator

See specification for separator in separate instruction.

Non compliance.

Non compliance with these requirements may damage the equipment.

Consumption material/data

Air

The cabinet has no internal consumption of air. The connected air is used for the operation of the pneumatic valves to be controlled. For consumption see valve instruction.

Water

The cabinet has no internal consumption of water. The connected water is used for the operation of the separator to be controlled. For consumption see separator instruction.

Electricity

installed load: 6 A

Description

The SCS 92 control unit is equipped with the required control functions for discharge, system valves, alarm indication, program selection etc.

The control panel is placed on the upper part of the SCS 92 and contains switches and buttons for starting the separator, selection of running mode, acknowledgment of alarm, manual discharge initiation and emergency stop.




A control module (SCS 92) is located inside the door of the upper cabinet. At delivery the module is programmed with a standard application program. At commissioning, necessary adjustments are easily made.

The inside of the lower cabinet contains air and water control valves. For detailed descriptions of components please see "Spare parts/components".

Function

The SCS 92 control system, automatically controls and monitors a separation system. Motor starter, external components and sensors are electrically connected to the upper cabinet. Pipings for operating water, flushing etc., are connected to the lower cabinet.

The separation system is controlled in accordance with a control program in the control module of the upper cabinet. Signals for control of the separator function are sent to the solenoids in the lower cabinet and to the motor starter.



g) Alarm signal

70691en4_1.1m

70691en4_1.fm

Control system

The control system operates in four different modes:

- STAND STILL
- START
- RUN
- STOP

These four modes can all be controlled from the operators panel or via remote signals.

Stand still mode

The program is in the mode STAND STILL when the main power to the control unit is ON and the separator is not yet started. This is also the condition the program enters after a completed stop sequence.

Operation (Start/Run/Stop)

It is possible to select 8 different Run modes by use of the function selector on the control panel.

- L/A CIP lye/acid
- WATER CIP water
- FEED OFF Feed-off
- P1 Production 1
- P2 Production 2
- P3 Production 3
- STD.BY Stand-by
- REMOTE Remote control


A function can be selected before start, during the start sequence and when the separator has attained full speed.

CIP (L/A or WATER)


At Cleaning-In-Place (CIP) there are two possible selections.

- Cleaning with lye/acid (L/A).
- Flushing with water (WATER).

The control unit will enter a new cycle for discharge interval time and effect an appropriate discharge type.



Stand-still



Switch FUNCTION

FEED OFF

The flow to the separator is stopped.

Discharge is not possible in this mode.

• When the feed-off timer has elapsed an alarm is triggered.


P 1-3

There are three different run modes for production.

22

- In production 1 and 2 the discharge interval is set by parameters P1 and P2. See "Minor adjustments".
- In production 3 the discharge interval time is set on the timer in the front of the control panel.

Use production 3 when a frequent change of discharge interval time is needed.



Timer for PRODUCTION 3

STAND-BY

The separator is at full speed with flow and is waiting for a new command.

• Discharges are initiated during stand-by according to parameter values. **REMOTE CONTROL**

The control system and thus the separator is controlled by external binary signals.

DISCHARGE

A discharge can be triggered in three ways.

- Automatic by timers (parameter values).
- Manually by pressing the discharge push-button.
- Remote by an input signal.
- The discharge indication lamp is lit during the discharge sequence.
- A discharge takes place some seconds after the sequence is initiated.
- The discharge sequence will always take at least 60 seconds.



Discharge lamp is lit during discharge

70691en4_1.im

This page intentionally left blank

Installation

Introduction

Before installation, carefully read through this chapter.

Requirements on installation personnel:

Electrician:

Certified according to local regulations with at least 3 years experience from similar types of installations. Proven skills in reading and working from drawings and cable lists.

Knowledge of local safety regulations for power and automation. Furthermore he shall make sure that the electrical installation and equipment or device the work comprises has been checked in an adequate way regarding safety for personnel and property before it is put into operation.



70691en4_2.fm

Unauthorized Personnel.

Operation by unauthorized personnel may endanger personnel and property.

Storage

To avoid damage to the equipment during storage the following requirements should be met:

Storage class A

Type of equipment:

- control panels
- electronic equipment
- electric control equipment (contactors, instruments...)
- machines with built-in control equipment

to be stored indoors, warm and dry.

Temperatures: +10°C - +40°C

Humidity: 20% - 85%



Non compliance.

Non compliance with these requirements may damage the equipment.

Unloading and transportation

Unloading and transportation of SCS 92 crates are most conveniently made by use of a fork lift. Please observe the signs "center of gravity".



Moving crates

Unpacking and inspection

Opening and unpacking of crate shall be done in the presence of a Tetra Pak or customer representative. It is advisable not to unpack the equipment until it is time for installation.

Check unpacked equipment against the packing list attached to the crate and report any damage to Tetra Pak immediately.



Packing list

Connections

Electricity

Screened signal cables must be used for input signals. These cables must be kept well away from the power cables (min. 300 mm = 1 foot). Avoid parallel power and signal cables.




70691en4_2.1m

\land Tetra Pak

Reference is made to appropriate "Timer Diagram" and "Interconnection Diagram" for the separation system.

Before power is switched on by the main switch (S0):

- Check power supply, 24 VAC +10/-15%
- Check that ground and common for connected components are wired.




Upper cabinet

Piping

For piping see installation drawings.

- A Operating water supply Pipe 1"
- C Drain R1/4"
- B Flushing water supply Pipe 1"
- F Oil cooler R1/4"
- H Sludge cover flushing Pipe 1"
- K Seal lubrication R1/4"
- G Cooling water supply R1/4"
- J Return from oil cooler R1/4"
- X Frame water R1/4"
- E Make-up water Pipe 1"
- Z Discharge water Pipe 1"



Lower cabinet

Tetra Pak Doc No

Positioning and erection

The control unit should be installed close to the separator in a vertical position free from heavy vibrations. It is important for the operator to be able to see the separator from operator position.

Before positioning the control unit make sure that the wall or holding equipment are of adequate quality.

Do as follows:

- 1) Prepare the wall or holding equipment (drill holes etc.).
- 2) Position the cabinet and fix it with 4 bolts.
- 3) Make all necessary connections.

Check after installation

Check after installation is to be done in conjunction with commissioning.

Commissioning

The SCS 92 control system is to be commissioned before it is put in commercial operation.

Adhere strictly to the steps below. See also previous page concerning "Check after installation".

Requirements on commissioning personnel:

- skilled process engineer with adequate experience of commissioning of industrial liquid processes
- knowledge of process controllers
- proven skill in reading flow charts
- knowledge in local safety regulations





Unauthorized Personnel.

Operation by unauthorized personnel may endanger personnel and property.





70691en4_2.fm

Note! Before commencing commissioning the engineer is requested to read through the complete instruction manual thoroughly.

Do as follows:

External utilities:

Check that all connections are in accordance with the requirements set out in the Technical data and related documents. Flush through new piping to ensure that dirt will not enter and block valves etc.

Pressurize:

Ensure that no leakage exists.

- Set air reducing valve PC1 and PC2.
- Set water reducing valve PC3.

Test of wiring:


Check that there are no short circuits in the external connections and also check the wiring for the input signals.

A functional test can be performed by running a built-in test program.

Test of emergency stop button:

Check the function of the emergency stop button.

- Power supply to separator will be cut off when emergency stop button is pressed.
- The separator can be restarted when emergency stop button is reset (released).



Air reducing valves PC1 and PC2 Water reducing valve PC3

Built-in test programs


The built-in test programs can be used only when the separation system is out of operation.

To run the test programs, proceed as follows:

- 1) Close manual shut off valves for air and water
- 2) Switch off control unit power by using the main switch (S0) inside the cabinet.
- 3) Simultaneously press the two lowest push-buttons on the control module. Switch on power while holding the two buttons pressed.

Hold the buttons pressed for a few seconds until the test program is started - indicated by a sequential test of LEDs (Light Emitting Diodes) and indicating segments, see illustrations below.

- 4) To operate the test programs use the three upper push-buttons;
- a) Step between test programs: Press upper push-button
- b) Step within test program: Press second upper push-button
- c) Switching digital outputs ON/OFF: Press second lower push-button.
- Note! Only 6 of the 9 possible test programs are utilized. Progr. 7 9 are not applicable and are just to be stepped through.



Start and operation of test procedure





Accidental activation.


Output test signals will activate connected objects. Disconnect power cables. Depressurize pipes.

Display test

To visually show that the display works properly

Test	Note
0.1	Light one segment at a time on all displays
0.2	Light all segments in one display at a time
Interval 1	time = 5 seconds







Display test


One of eight segments

Memory test

To ensure that no faults exist in the control unit memory

.

Test	Memory	Note
1.1	Prom	checksum test
1.2	Internal RAM	test if writeable
1.3	External RAM	test if writeable
1.4	EEPROM	checksum test
Display	indication: 0 = corre	ct, E = faulty





Circuit faulty



- 5-

Digital input test

Activate/deactivate input switches and observe 1 - 0 changes.

Test	Control Module	SCS 92 component or terminal	Designation
2.1	X7.4	A11:4-1	Too high current
2.2	X7.3	24V	Not used
2.3	X7.2	X24:6-4	D contactor response
2.4	X7.1	X24:7-4	Motor failure
2.5	X8.4	S3.X24:8-4	Emergency stop button
2.6	X8.3	K50, SH1 X24:16-15 (S2)	Discharge initiation
2.7	X8.2	S1, X24:17-15 (S2)	Start/Stop
2.8	X8.1	SH2, X24:18-15 (S2)	Alarm acknowledge
3.1	X9.4	X24:21-15 (S2)	See timer diagram
3.2	X9.3	X24:22-15 (S2)	See timer diagram
3.3	X9.2	X24:23-15 (S2)	See timer diagram
	indication:1 = input ut OFF (Circuit open)		· · · · · · · · · · · · · · · · · · ·

Circuit open


Circuit closed



Selector switch test

To ensure proper function of selector switch.

Test	Note
а	Display indicates (r. co.) if switch is in position for Remote control (R)
b	Display indicates (Loc) if switch is in position for Local control (L)
С	Display indicates (Pro) if switch is in position for Program mode (P)







Pressurized equipment.

This unit works under pressure. Depressurize before running digital output tests 5.3, and 5.7 to avoid jets. Watch out for leakage.



Accidental start.

Output test signals will start motors. Disconnect power cables at starter cabinet or motor before running digital output test 5.5, 6.4. i.

70691en4_2.fm


Digital output test

To ensure activation/deactivation of output signal is working properly

 To activate/deactivate push second lower push-button. Observe valves and contactors

Test of digital output signals must be done only when the separator is in stand-still position.

Test	Control Module	SCS 92 component or terminal	Designation
5.1	X4.4	X25:12-11	Pneumatic brake
5.2	X5.1	Y16 (X25:9-10)	Oil an sealing cooling
5.3	X5.2	Y23, Y13 (X25:14-11) (X25:5-6)	CIP valve
5.4	X5.3	Y11 (X25:1-2)	Make-up water
5.5	X5.4	Y24, Y22 (X25:15-11) (X25:13-11) (X24:12-13)	Start/Stop flow
5.6	X6.1	Y12 (X25:3-4)	Cover flush
5.7	X6.2	Y15 (X25:7-8)	Discharge
5.8	X6.3	SH1	Discharge lamp
6.1	X6.4		Not used
6.2	X4.2		Not used
6.3	X4.3		Not used
6.4	X1.1	X24:109 (S3)	Start/Stop
6.5	X1.3	X24:11-9	Delta signal
6.6	X2.1	K100, K101	Alarm
6.7	X2.3-4	K50	Discharge interval timer prod. 3



70691en4_2.fm




Start of motors.


Never use a digital output test signal for initializing start of motors.


Initial start-up


- Perform a lamp test by pressing the alarm reset push-button (D) on the control module inside the cabinet (more than 5 seconds) to ensure all diodes and display segments are working.
- Set P90 to "1" as a guidance during the first start and stop. See "Parameters".
- Check start and stop timers. Set with margin (T51-53, T81-82). Second lower push-button (C) on the control module can be used to shorten but not to prolong a set time. See "Timer reset" at the bottom of the page.
- Make adjustment of timers T61-67 if needed. Refer to the requirements of the actual separator. See "Parameters".
- Record during the first run the maximum reading of the ampere meter during discharges.
- After first start and stop set the timers to final settings and record set values for all parameters in this manual. See "Parameters".
- During the second start sequence it is possible to adjust the current relay to a value slightly above the value at normal maximum discharge size. Use values from first run. Current relay (A11) is placed inside the upper cabinet.
- Perform an emergency stop. See "Emergency stop".
- Set P90 to "4" before handing over to the operator. See "Parameters".



Panel - mounted ampere meter







Current relay inside the upper cabinet

Timer reset

If restart is done when the separator is at almost full speed and a full start sequence is not necessary (e.g. after a short power failure) it is possible to cancel one or several of the timers in the start sequence (T51-T55).

Open the upper cabinet door and push the second lower push-button (C) once for each timer to be cancelled.

Note! Setpoint is still valid for next start of the timer.



Cancellation of timer.

Cancellation of timers during START and STOP mode may cause malfunction.

Operation

Introduction

The SCS 92 can be controlled from the operators panel or via remote signals.

Requirements on operating personnel:

Basic knowledge of process and process controller.





Unauthorized Personnel.

Operation by unauthorized personnel may endanger personnel and property.



Electrical hazard.


While power supply is switched on: Open the upper cabinet door only to investigate/reset alarm.

Preparation before start

To ensure a safe and easy operation, do as follows:

Check that required utilities are available

- 1) cooling water supply, manual shut off valve
- 2) water (pressure), manual shut off valve
- 3) air (pressure), manual shut off valve
- 4) electricity, power to control unit



Control panel and the interior of lower cabinet



Condensate.


Condensate may damage the equipment. Keep power switch ON to avoid condensate inside the cabinet.

70691en4_3.fm

Start/Run/Stop

Control panel design

The control panel contains switches and lamp/push-buttons for control and alarm acknowledge and an ampere-meter for indication of the motor current.



Motor power indication lamp (1)

No light – Separator at STAND STILL or STOP mode. Steady light – Separator at START or RUN mode.

Discharge indication lamp/push-button (2)

Steady light – DISCHARGE. Push to initiate a DISCHARGE.

Alarm indication lamp (3) Steady light – ALARM.

Alarm acknowledge push-button (3)

Push once to acknowledge ALARM. See "Alarm function" for reset of alarm

Control voltage indication lamp (4)

No light – Power to control unit OFF. Steady light – Power to control unit ON.

Separator start/stop switch (5) *

Position 0 – Separator at STAND STILL or STOP mode. Position 1 – Separator at START or RUN mode. * when not remote controlled



Function selector switch (6)

Selector for RUN modes. See "Function"

Timer (7)

Discharge interval timer for PRODUCTION 3 (P3).

Emergency stop button (8)

Push for direct stop of separator. The program omits the STOP-sequence. At emergency stop the product feed valve will remain open. See "Alarm function".

Ampere-meter (9)


Indicates separator motor current.


Start

Before start.

Make sure that the machine is in operable condition.

- 1) Select an operating mode with the switch FUNCTION.
- 2) Start separator by turning the switch SEPARATOR to position 1 (if not FUNCTION switch in remote control position).
- The lamp MOTOR POWER is lit.
- The ampere-meter rises to a high value.
- Note! If REMOTE is chosen the start signal is received from an external source.





Switch FUNCTION





Vibrations.

In case of heavy vibrations stop the separator by using the emergency stop push-button.

70691en4_3.fm

- When full speed is attained the amperage has fallen to a lower steady value.
- The program changes to selected program function.






Starting

Separator attained full speed

Run


1) The operating mode can be altered during operation by use of the switch FUNCTION.



Switch FUNCTION

Stop

- 1) Stop the separator by turning the switch SEPARATOR to position 0 (if the FUNCTION switch is not in remote control position).
- 1) The lamp MOTOR POWER will go out.
- The switch FUNCTION remains in its position.
- The control program will enter the STOP sequence and power to the separator will be switched off.



Stopping




Moving parts.

Aways check on the tachometer knob on the separator that the machine has come to a complete standstill before starting to disassemble the separator.

Alarm function

Alarm indication

When a fault occurs, the signal lamp "ALARM" will light up. Faults are displayed, on the control module inside the cabinet, in the following way (from left to right):



Alarm indication

Faults from external sensors


- Timer running when the fault appeared (in picture 63).
- Control module terminal number of the fault signal (in picture 7.4).

Faults detected by software

- Alarm group (in picture A1).
- Complementary information (in picture 5).



Too high current during production 3



Selector switch error



'0691en4_3.fm

Fault indication.


Always investigate the cause of a fault indication. Otherwise you may endanger the equipment.

Alarm acknowledge and reset

- 1) Press the alarm lamp/push-button once, in order to acknowledge the alarm.
 - The alarm lamp/push-button will go out.
 - Any possible external warning indication devices will also stop.
- 2) Open the upper cabinet door.
 - The display is flashing revealing the appropriate alarm code.
 - The two red ALARM-LEDs are flashing.
- 3) Record the displayed alarm code.

70691en4_3.fm

- 4) Press the lowest push-button to reset the alarm function.
 - Three reactions are possible:
- a) The flashing light changes to normal display and the two LEDs goes out.
 - The alarm cause has disappeared and no other alarm is triggered.
- b) The flashing code disappears but the two LEDs changes to steady.
 - The alarm cause(-s) is remaining, and no other alarms exist.
- c) The flashing alarm code changes to another flashing alarm code.
 - The first alarm is reset and another alarm indication has started. Repeat from step 3.
- Note! Remaining alarms may be inspected again by pressing the lowest pushbutton. After the display of all remaining alarms the F-value will show. See "Parameters".
 - 5) Remedy the fault(-s).
 - 6) Close the upper cabinet door when all alarms have been reset.
 - All alarms are reset when the display is at normal display and the two LED's have gone out.



	F	AULT LIST	
Display	Alarm function	Action	Reset
74	Too high current. Activate when the preset value at the current relay is exceeded.	Program steps to FEED-OFF (T61).	Normal reset. When current has decreased below alarm limit program will return to selected function.
	Delta-contactor response.	Program steps to stop (T81).	Normal reset.
	Motor failure. Occurs when the thermal relay or the thermistor (if applica- ble) of the separator motor is released.	Program steps to stop (T81).	Normal reset when motor tem- perature recovered.
84	Emergency button. When emergency button is pressed.	Program steps to stop (T81). Product feed valve will remain open.	Normal reset when emergency button is released.
83	Too frequent discharges. Too many discharges within a period of time.	Alarm signal only.	Normal reset.
8: :	Internal RAM error.	Alarm signal only.	Switch control unit OFF and ON to reset. Restart.
RI IZ	External RAM error.		
R : 3	E2 RAM error.		
R ; 4	PROM error.		
<i>R i</i> 5	Selector switch error.	Alarm signål only.	Normal reset.
R2	In programming mode too long.	Alarm signal only.	Reset enabled when selector switch shifted.
83	Power failure.	Alarm signal only.	Normal reset.
हिप	Not used.		

🏝 Tetra Pak

33

	F/	AULT LIST	
Display	Alarm function	Action	Reset
	Rotation - No pulses received (within time set in T51).	Program steps to STOP. An alarm is activated.	Remedy fault or set P25=0 before normal reset.
R5 0	Rotation - No pulses received during T52-T81.	Alarm signal only.	Remedy fault or set P25=0 before normal reset.
	Rotation - No pulses received (during T82-T83 and Stand- still).	None	None
R S <u>S</u> 3	Speed not attained Full speed not attained when T53 has elapsed.	Program steps to stop. An alarm is activated.	Normal reset
<u> </u>	Low speed. Speed is lower than set point for delta switch over during T55-T78 (*1).	Program steps to FEED OFF. An alarm is activated.	Wait for speed to recover before normal reset.
RS 82	Too long stop time RPM pulses continues after T82 has elapsed.	An alarm is activated. T83 does not start until rpm=0.	Resets automatically when T83 starts. Restart is possible.
R 5 ! 50	High speed. Speed is higher than max. speed (*2).	Program steps to stop. An alarm is activated.	Normal reset when speed is lower than max. speed.
RE	Start function blocked.	Alarm signal only.	Local restart only.
R ? - R8	Not used.		
89 0	Vibration - shortage in con- nection.	Alarm signal only.	Normal reset when fault is corrected.
89 []];	Vibration - No connection.	Alarm signal only.	Normal reset when fault is localized.
89 10	Vibration - pre-warning. Vibration limit low (P31) is exceeded (*3).	Alarm only.	Normal reset when vibrations have ceased.
89 15	Vibration - Shut down. Vibration high level (P32) is exceeded (*4).	An alarm is activated. Program steps to STOP with feed valve open during T81 or until vibrations are lower than P32.	Normal reset in STANDSTILL. Restart from stop sequence not possible.

(*4) Value of P32 indicated.

(,)

•


Emergency stop

In case of emergency press the red emergency stop button located on the control panel.

This will stop the separator in the following way:

- The program steps directly to stop mode (T81).
- The product feed valve will remain open.

The emergency stop button will stay activated until manually released. When released the separator control will remain in stop sequence.



Emergency stop button on control panel



Emergency stopped.

The machine may contain hot liquid or cleaning solution. Handle with outmost care to avoid exposure.

Start after emergency stop


- 1) Make sure that the cause of the emergency stop is no longer valid.
- 2) Release the emergency stop button.
- If separator has stopped with sludge in the bowl it has to be cleaned manually. See instructions for separator.

Vibrations.

Imbalance may occurs if start sequence is entered with sludge in the separator bowl. If necessary: disassemble and clean the bowl.

70691en4_3.fm

3) Make a normal start up. See "Start/Run/Stop".



Resetting the emergency stop button

Cleaning

See instructions for separator.

70691en4_3.fm

F-value readings

The alarm reset push-button in the control panel can be used to display the following information about the separator.


- separator speed in 1000 rpm with decimal point, e.g. 6.14 = 6142 rpm.
- vibration level in mm/s.

When the push-button is used for this purpose there must not be unacknowledged alarms present.


Note! If the button is not pressed for 10 minutes the display will return to normal indication.

To display information do as follows:

- 1) Open the upper cabinet door.
- Locate the four push-buttons and the display.
- Note! Ensure that no unacknowledged alarms are present.




- 2) Press push-button 4 to set the control unit in program mode F0 Pro.
- Step through not reset alarms (if any) by repeatedly pressing push-button 4 until **F0-Pro** is displayed.





- 3) Press push-button 4 to display F1 separator speed.
- 4) Press push-button 4 to display F4 Vibration level.
- 5) Press push-button 4 to return to normal indication.






Minor adjustments

Change of discharge interval

To change discharge interval setting for production 1 and 2 do as follows:

- 1) Open the upper cabinet door.
- Locate the four push-buttons and the display.
- Note! Ensure that no unacknowledged alarms are present.



Push-button and display




70691en4_3.1m

Change of values.


A change of value will change the machine's way of working.

- 2) Press push-button 4 to set the control unit in program mode F0 Pro.
- Step through not reset alarms (if any) by repeatedly pressing push-button 4 until F0 Pro is displayed.






- 3) Press push-button 1 to step to concerned parameter for production 1 and 2.
- Each pressing will display the following in turn:
- C1 1 (Open parameters)
- **1 30** Parameter 1 (interval timer for production 1 set to 30 min.)
- 2 45 Parameter 2 (interval timer for production 1 set to 45 min.)
- C2 2 (Plant parameters)
- F0 Pro Program mode



Stepping in program


- 4) Press push-button 3 or 4 to set new discharge interval time (press button 3 to increase and button 4 to decrease in steps by one).
- The parameter number starts to flash.
- Press both push-buttons simultaneously to restore previous value.



Setting of timer value

- 5) Press push-button 1 to:
- store new value and
- step to next parameter


If needed repeat step 4 above.




Storing of timer value when stepping

70691en4_3.fm

- 6) Press push-button 1 until F0 Pro is displayed.
- Program mode is ended.



- 7) Press push-button 4 to:
- leave program mode
- resume normal indication on display



Leaving program mode

For further information regarding parameters see "Parameters".

Maintenance

Introduction

A disciplined maintenance programme is essential to minimise breakdowns and maximise equipment life.

Requirements on personnel:

Skilled mechanic with at least 2 years experience of industrial maintenance. Proven skill in reading engineering drawings.

During repair and maintenance he shall take all necessary precautions to guarantee the safety of personnel and to avoid machine risks (e.g. switch off power, post signs, fence off a safety area).

If you need assistance or have questions - please contact Tetra Pak.



Unauthorized Personnel.

Operation by unauthorized personnel may endanger personnel and property.

DANGER!

Electrical hazard.

An electric shock can cause bodily injury or death. Treat all electrical equipment as powered. Switch off power before maintenance and repair. Avoid contact.

Preventive maintenance

Preventive maintenance primarily consists of visual inspection of the equipment followed by necessary adjustments.

- silicon greasing of packing in cabinet doors once a month
- test function of emergency stop once a week

Corrective maintenance

In case of repair work in the lower cabinet:


- 1) Switch off power inside the upper cabinet
- 2) Shut off the water and air supply
- 3) Replace necessary parts

If a persistent fault is found in the control module it must not be repaired but replaced and submitted to Tetra Pak representatives for repair.

Replacing the control module


- 1) Open the upper cabinet door and switch off the control voltage by the main switch (S0).
- **Note!** Before touching the control module circuit board, discharge static electricity by touching the cabinet earth terminal.
- Note! Check present position of jumpers for comli and vibration transmitters. Fig. 7.
 - 2) Pull out the wire terminal sockets by hand and remaining wires with tools.
- Note! Sockets are marked with terminal numbers.
 - 3) Remove the two screws holding the module by using a screw driver and hinge the control module outwards.
 - 4) Lift off the control module from the cabinet door and replace it with a spare module.
- **Note!** Before touching the control module circuit board, discharge static electricity by touching the cabinet earth terminal.
 - 5) Fit the spare module in reverse order. When replacement is completed switch on the control voltage, set parameters to appropriate values and shut the cabinet door.
 - 6) Fill in a return note (state fault symptoms and running time) and send it together with the old module in the return package.

70691en4_4.1m



7) Make sure that the jumpers for comli and vibration are put in the same position on the new circuit board. If necessary check against circuit drawing. (Comli connection is not in use for Control System SCS92B).

Replacing control module



70691en4_4.fm

C Tetra Pak Doc No. IM 70691en4

.

70691en4_4.fm

Parameters

There are two types of parameters:

- open parameters (P1 and P2)
- plant parameters (P20 P99)


Open parameters (P1-P2)

The open parameters P1 and P2 can be reached by the operator and are used for setting discharge interval for Production 1 and Production 2 respectively (See "Minor adjustments"). The values of the parameters P1 and P2 are limited by the value of parameters P64 and P65 respectively.

Plant parameters (P20-P83)

Plant parameters are set at factory (default) but may in some cases be adjusted at commissioning. Among plant parameters are:

- separation system specific parameters (P20-39)
- timer sequences (P51-P83)
- service parameter (P90)
- 1) Open the upper cabinet door and set the selector switch in position P.
- **Pro** is intermittently displayed.






Change of values.

A change of value will change the machine's way of working.




70691en4_4.1m

- 2) Press push-button 1 four times
- to display C2 2
 - Each pressing will displayed the following in turn:
 - C1 1 Open parameters
 - 1 30 Open parameter 1 can be adjusted
 - 2 45 Open parameter 2 can be adjusted
 - C2 2 Plant parameters "entry"




- 3) Press push-button 3
- to set the parameter code C2 to 12 for access to the plant parameters.
 - Push-button 3 will increase value.
 - Push-button 4 will decrease value.




.

70691en4_4.fm


- 4) Press push-button 1 or 2
- to select parameter to adjust.
 - Parameter is displayed to the left.
 - Value is displayed to the right.




- 5) Press push-button 3 or 4
- to adjust the parameter value.
 - When one of the two push-buttons is pressed the parameter number starts to flash.
 - Press both push-buttons simultaneously to restore previous value.



- 6) Press push-button 1 or 2
- to store the value and step to next or previous parameter.
 - Push-button 1 will step to next parameter.
 - Push-button 2 will step to previous parameter.



- 7) Repeat step
- 5 and 6 above to make all necessary parameter adjustments.
 - After **P99 End** will appear in the display.




8) Set the mode selector switch in position L or R, whichever applicable, when the parameter value(s) is/are set.

L = Local control (No serial communication)

R= Remote control (Serial communication)

Note! Switching of the mode selector can be done at any parameter display.

For information concerning various parameters, see "Parameter list".



'0691en4_4.fm

Parameter list

	OPEN PARAMETERS								
Param	neter	Designation/Unit	Range	Default	Plan set value				
P1	Discharge interval time for production 1.	Minutes	see P64	30					
P2	Discharge interval timer for production 2.	Minutes	see P65	45					

		PLANT PARAMET	ERS	·	
P20	Control mode.	0 = local control. 1 = external control.	0-1	1	
P21	Not used.				
P22	Alarm delay. Delta-contactor response.	0 = not defined. 1 = direct start. 2 = Y-D start, friction coupling. 3 = Y-D start, CT-motor.	0-3	2 = P51 = P51 = sum P51-53	
P23-24	Not used.		ľ		
P25	Max. motor speed provided P43=1	0 = Speed monitoring off 150 = 1500 rpm 180 = 1800 rpm	0		
P26	Delta switch over speed (if P43=1). Also used as low speed limit	% of P25		93	
P27	Not used				
P28	Not used	-			
P29	Not applicable				
P30	Vibration max. indication	mm/s (if applicable)		20	
P31	Vibration pre-warning limit	mm/s (if applicable)		10	
P32	Vibration shut-down limit	mm/s (if applicable)		15	
P33-49	Not used				

SCS92B

		PLANT PARAMETE	RS
P90	Service mode.	 0 = not used (display indicates "F0 0". 1 = show running timer no. and time left. 2 = not used. 3 = prom version. 4 = enable enter of prog mode ("F0 Pro"). 5 = no. of discharges today. 6 = no. of discharge indication faults today. 7 = no. of vibration alarms today. 8 = run time today "h.m" (eg. 2.4 = 2h 40min.). 	
P91	No. of discharges.	1000's	
P92	No. of discharges.	total no. = P91x1000+P92.	
P93	Total no. of failed discharges.		
P94	Total no. of vibration alarms (pre-warnings).		
P95	Total run time.	1000 hours.	
P96	Total run time.	hours total hours = P95x1000+P96.	
P97-99	Not used.		

,

SCS92B

Timer list

		TIMERS		
Timer	·····	Comment	Plant set value	
P50	Not used			
P51	Start timer (see P22)	seconds		Total start time
P52	Start timer	seconds		
P53	Start timer	seconds		3
P54	-			-
	Start timer	seconds		_
P55	Start timer	seconds	·	_
P56-59 P60	Not used	defende medere beer en sieren t		
P60 P61	Feed off	default mode when no signal minutes before alarm		
P62	Stand-by	minutes, discharge interval		-
P63	Not possible to set	time present in production 3		_
P64	Prod. 1	minutes, discharge interval		
P65	Prod. 2	minutes, discharge interval		-
P66	CIP water	minutes, discharge interval		-
Ė 67	CIP lye/acid	minutes, discharge interval		
P68-70	Not used			-
P71	Discharge sequence	seconds		
P72	Discharge sequence	seconds		
P73	Discharge sequence	seconds		-
P74	Discharge sequence	seconds		-
P75	Discharge sequence	seconds		-
P76	Discharge sequence	seconds		-
P77	Discharge sequence	seconds	·	
P78	Discharge sequence	set by program, seconds		
P79-80	Not used			
P81	Stop timer	seconds		Total stop time
P82	Stop timer	seconds		
P83	Stop timer	seconds		3
P84-89	Not used			

70691en4_4.fm

70691en4_4.tm

FUNCTIONS	TEF	RMINALS	STAN STIL			!	STARI	г					R	UN				1	STOP)
	Module	Panel	Timer	-	51	52	53	54	55	60	61	62	63	64	65	66	67	81	82	83
OUTPUTS			t –									+	<u> </u>	· •		1		<u> </u>		
tart/Stop separator	X1:1	S3-X24:10-9				•	•	•			•	1			<u> </u>	·	1	-		
Delta signal	X1:3	X24:11-9				ļ		J										-		
Varm	X2:1	K100, K101				'	'												<u> </u>	
Discharge interval timer prod. 3	X2:3-4	K50			I			1	i	I	1	1	<u> </u>	.	1	1	1	1		.
neumatic brake	X4:4	X25:12-11													1		ļ		1	
Dil and seal cooling, Y16	X5:1	X25:9														1]		1	
CIP-valve, Y23, Y13	X5:2	X25: 14-11	I I						ļ	ļ								-		
		X25: 5-6						i i									1			
Make-up water, Y11	X 5:3	X25: 1-2											1							
Start / Stop flow, Y24	X5:4	X25: 15-11										—	•	•		•	•	-		ļ
		X24: 13-11											1	1	1	1]
		X24: 12-13				l														
Sediment cover flush, Y12	X6:1	X25: 3-4				ļ										.				
Discharge signal, Y15	X6:2	X25: 7-8					1													
Discharge indication lamp	X6:3						[1
Remote control		X24: 19-20				<u> </u>	<u> </u>	<u> </u>	'	·		<u> </u>	<u> </u>	'	'	-'		<u> </u>	<u> </u>	'
COMMUNICATION INPUTS					1	l	[1	I	1	1	1	I I	1	1	i	1	ł	1	1
Discharge initiation	X8:3	K 50, SH 1, X 24:16																-		
Start / Stop	X8:2	SI, X24:17			•	1	,	1			•	1							1	
Alarm acknowledge	X8:1	SH2, X24:18									_:									
l	X9:4	S2, X24:21				1		1			1]						-		
Choice of RUN-mode	X9:3	52, X24:22											•			 		-		
	X9:2	52, X24:23									-	-	<u> </u>			-	<u> </u>	-		
BINARY ALARM INPUTS Alarm condition)							i							1 ·						
oo high current (0)	X7:4	A11: 4-1									l		l	1			I			ł
Not used	X7:3										1	1	1	1	1	1	1			ł
								ļ			l	1					1			
0-contactor response (0)	X7:2	X24: 6-4	1		,								-					-1	1	
fotor failure (1)	X7:1	X24: 7-4																		
mergency button (0)	X8:4	X24: 8-4																-		
NALOGUE MONITORING INPUTS																			1	l
Not used ·	X10:1-3]			1			ł					
Not used	X11: 1-3													1				1		
peed, Namur	X12: 3-4	X24:25-24	1											1						
/ibration, Schenk (option)	X 12: 1-2		1				1	1												
	·	L	1		L	Title S	CS92B	1	1	1	1	1	I	<u> </u>	1		L	1	ł	l
									er diagi					Date		T		_		

.

•

•

5 Tetra.Pak

Doc No. IM 70691en4

53

(J)	
4	

`

FUNCTIONS	TEF	RMINALS	RU	N		DISCHARGE SEQUENCE							RUN	COMMENTS
	Module	Panel	Timer	+	71	72	73	74	75	76	77	78		
OUTPUTS MRPX610		<u> </u>									· · · ·	<u> </u>		
Start/Stop separator	X1:1	S3-X24: 10-9				•	1				I	1		
Delta signal	X1:3	X24: 11-9												
Alarm	X2 :1	K100, K101												Apply in production 3 or
Discharge interval timer prod. 3	X2:3-4	K50												
Pneumatic brake	X4:4	X25: 12-11					1				1	1 1		
Oil and seal cooling, Y16	X5:1	X25:9												
CIP-valve, Y23, Y13	X5:2	X25: 14-11												Apply in CIP only
		X25:5-6												
Make-up water, Y11	X5:3	X25: 1-2												
Start / Stop flow, Y24, Y22	X5:4	X25: 15-11										1		-
• •		X25: 13-11					I	F	I I		1	1	I	
		X24: 12-13						l			1	1		
Sediment cover flush, Y12	X6:1	X25: 3-4					1	I	1 1		I —	1	I	
Discharge signal, Y15	X6:2	X25: 7-8												
Discharge indication lamp	X6:3											I		
Remote control		X24: 19-20		i										
Remote control		X24: 19-20			. – –			·				· — —		
													•	
		ł												
			i i									1 1		
]		
		1												
	·	······································				Title S	CS92B		[1	•	
					I			ont Tim	er diagra					Date
						iype 0	i docum	eur 110	er utagra	411]

۰.,

Maintenance

•

I C: Tetra Pak

Doc No. IM 70691en4

Electricity

Electrical installations place special demands on layout, safety and the personnel handling them.

This chapter is valid for both power, control and automation. Please see separate file for detailed information about:

- list of components
- layout/design
- circuit diagrams
- cable connections

Requirements on installation personnel:

Electrician:

Certified according to local regulations with at least 3 years experience of similar type of installation. Proven skills in reading and working from drawings and cable lists. Knowledge of local safety regulations for power and automation. Furthermore he shall make sure that the part of the electrical installation or device the work comprises has been checked in an adequate way regarding safety for person and property before it is put into operation.







Unauthorized Personnel.

Operation by unauthorized personnel may endanger personnel and property.



Electrical hazard.

An electric shock can cause bodily injury or death. Treat all electrical equipment as powered. Switch off power before maintenance and repair. Avoid contact. This page intentionally left blank

70691en4_5.1m

7.

Spare parts/components

All machinery is subject to wear and tear. To help you cope with this Tetra Pak is prepared to quote tailor made spare parts kits for your equipment. To minimize process stops it is advisable to always have these kits available in your plant.

For inquires and orders please contact your nearest Tetra Pak representative.

This page intentionally left blank

Α

Alarm acknowledge and reset	31
Alarm acknowledge push-button	27
Alarm function	30
Alarm indication	30
Alarm indication lamp	27
Ampere-meter	

В

Built-in test programs		1	8
------------------------	--	---	---

С

-	
Change of discharge interval 3	39
Check after installation 1	6
CIP (L/A or WATER)	9
Cleaning	36
Commissioning 1	6
Connections 1	4
Consumption material/data	7
Control panel design 2	27
Control system	9
Control voltage indication lamp	27
Corrective maintenance4	14

D

70691en4IX.fm

Description	7
Digital input test	20
Digital output test	22
DISCHARGE	11
Discharge indication lamp/push-button	27
Display test	

E

Electricity14	, 55
Emergency stop	35
Emergency stop button	
External utilities	17

F

FAULT LIST	33
Faults detected by software	
Faults from external sensors	31
FEED OFF	10
Function	8
Function selector switch	
FUNCTIONS	53, 54
F-value readings	
Ű,	

G

General information	
---------------------	--

H

Health and safety regulations3

Ι

Initial start-up	23
Installation	13
Introduction5, 1	13, 25, 43

Μ

Maintenance	43
Memory test	19
Minor adjustments	39
Motor power indication lamp	27

Ν

0

OPEN PARAMETERS	.50
Open parameters (P1-P2)	.46
Operation	.25
Operation (Start/Run/Stop)	9

P

-	
P 1-3	11
Parameter list	50
Parameters	46
Piping	15
PLANT PARAMETERS	50
Plant parameters (P20-P83)	46
Positioning and erection	16
Preparation before start	25
Pressurize	17
Preventive maintenance	43

R

REMOTE CONTROL11
Replacing the control module44
Requirements on air and water7
Requirements on commissioning
personnel16
Requirements on installation
personnel13, 55
Requirements on personnel43
Run

S

Selector switch test	21
Separator start/stop switch	27
Spare parts/Components	57

.

Stand still mode	9
STAND-BY	11
Start	
Start after emergency stop	35
Start/Run/Stop	27
Stop	
Storage	13

Τ

Technical data	6
Test of emergency stop button	17
Test of wiring	17
Timer	28
Timer list	52
Timer reset	24
TIMERS	52
To the owner	1

U

Unloading and transportation1	4
Unpacking and inspection1	4

This page intentionally left blank

-

. .


.

.

,







							LIST OF	CONTENT	S							
<u>1210N</u>	<u>PABE [</u> ≈0/0 1		ATION OF	OOCUMEN	TS			REV	<u>8108</u>		UNIT, DIG					
	≠0/1 L	IST OF C	ONTENTS								UNIT. DIG					
	=1/1 P	ARTS LIS	т								UNIT, DIG					
	=1/2 P	ARTS LIS	т						=5/11	CENTRAL	UNIT, DIG	ITAL OUTE	PUTS			
	≈1/3 P	ARTS LIS	т								UNIT, DIG					
	=1/4 P	ARTS LIS	т						⇒5/13	CENTRAL	UNIT, DIG	ITAL OUTE	PUTS			
	=1/5 P	ARTS LIS	т						-5/14	SIGNALS						
	=1/6 P	ARTS LIS	т						=5/15	i PNEUMAT:	ICS					
	=4/1 A	SSEMBLY	DRAWING	1					=5/16	i WATER						
	=4/2 A	SSEMBLY	DRAWING	2					=7/1	. INSTALLA	ATION DRAW	ING				
	=4/3 R	SSEMBLY	DRAWING	3												
	-4/4 A	SSEMBLY	DRAWING	4												
	≖5/0 I	DENTIFIC	ATION OF	WIRING 3	INSIDE CON	TROL CAB	INET									
	≖5/1 C	ONTROL,	SUPPLY V	OLTAGE												
	÷5/2 C	ONTROL, :	SUPPLY V	OLTAGE												
	=5/3 C	ONTROL, S	SUPPLY V	OLTAGE												
	=5/4 A	LARM														
	=5/5 M	OTOR CURF	RENT													
	∍5/6 C	ENTRAL UI	NIT, ANA	LOG INPUT	\$											
	=5/7 C	ENTRAL UI	NIT, DIG	ITAL INPU	2 T L											
OF C	ONTEN	<u>TS</u>														
									Tetra Pa Processing	ak	Department	Designer		Versflad	Here of Eplen-project	Ho. c
								· · · · · · · · · · · · · · · · · · ·	• • • • • • • •	<u> </u>	CCP	UN	01.0Z.13	11	35411-410	1

				ACX I OCESSING SYSTEMS		
Sign.						Cont. on page
	 	·		Prajaci Wo.	31821-9860-1	=1/1
Dete					SEPARATOR	7400
uate	 			Drawing Ho,		_
				1	SCS92B	
			Drawing remarks	35411-410-0		1 1
					1	!

POS. No.	ARTICLE No.	PAGE REF.		RENOVINGTION.			,		
	HATILLE NO.	FHUE KEF.	QUANTITY	DENOMINATION			REV. N	0.	
07	3530210213	5/2.6	5,0	TERMINAL, WOU4					
1	252240101	5/16.2	1,0	HUFF, OUTS.1°-INS.3/4"R		•			
1	3180150671	5/16.2	1,0	STRAIGHT RADIATOR JOINT OF PIPES					
_1	3180150681	5/16.2	1.0	BALL VALVE, 3/4"R.BALLOFIX					
1	52633605	5/16.2	2.0	2.0 NIPPLE.3/4"R					
1	3180150911	5/18.2	1.0	T-PIPE, 3/4"R					
1	3180150861	5/16.2	1,0	NIPPLE, 3/4"R					
1	52637301	5/16.2	1.0	HOSE SLEEVE, 3/4"R					
1	224510206	5/16.Z	1.0	HOSE CLAMP, 19-28HM		_			
1	9160150921	5/16.2	1,0	MUFF, OUTS, 3/4"-INS, 1/4"R					
1	3180152102	5/16.2	1.0	SOLENOID VALVE, 24VDC, 5W, BÜRKERT ;	2618				
<u>1.</u>	3180151946	5/16.2	1.0	PRESSURE GAUGE.0-1MPa.1/4"R.GLYCE	RINE				
2	224510206	5/16.2	1.0	HOSE_CLAMP, 19-28MM					
2	52637301	5/16.2	1,0	HOSE SLEEVE, 3/4"R					
2	3180150861	5/16.2	1.0	NIPPLE.3/4"R					
2	3180150872	5/16.2	1.0	L-RADIATOR JOINT OF PIPES, 3/4"R					
2	3180150911	5/16 2	1.0	T-PIPE, 3/4"R				_	
2	3160150921	5/16.2	1,0	MUFF, OUTS.3/4"-INS.1/4"R					
2	3180150871	5/ <u>1</u> 6 2	1.0	STRAIGHT RADIATOR JOINT OF PIPES.	3/4"R				
2	52633707	5/16.2	1.0	NIPPLE,1"-3/4"R	· · · · · · · · · · · · · · · · · · ·				
2.	52635105	5/16.3		PLUG.3/4"R.STAINLESS STEEL					
3	52633605	5/16.3		NIPPLE, 3/4"R					
3	3160152101	5/16.3		SOLENGID VALVE, 24VDC. 5W. BURKERT Z			<u> </u>		
3	3160150872	5/16.3		L-RADIATOR JOINT OF PIPES. 3/4"R		· · · · · · · · · · · · · · · · · · ·			
3	3180150861	5/16.3		NIPPLE, 3/4"R	· · · · ·		<u> </u>		
3	52637301	5/16.3		HOSE SLEEVE, 3/4"R					
3	224510206	5/16.3	1.0	HOSE CLAMP, 19-26MH	·	·			
TS LIST			<u> </u>				_ I		
				▲ Tetra Pak	Depertaent Oastgear	Dete Verified	News of Eplen-project	Ro. of	
				Processing Systems	CCP UN	01.02.13 ня	35411-410	3	
	_			Project Ko.	31821-986	0-1		Cont. o	
					SEPARATOR			Pops	

35411-410-1

Drawing remarks

0 PDS. No.	1 2 ARTICLE No.	PAGE REF.	QUANTITY	UENOMINATION	REV. No.					
4	224510206	5/16.3	1,0	HDSE CLAMP, 19-28MN						
4	52637301	5/16.3	1.0	HOSE SLEEVE, 3/4"R						
4	52633707	5/16.3	1,0	NIPPLE.1"-3/4"R						
5	52633707	5/16.4	1,0	NIPPLE, 1"-3/4"R						
5	3180150871	5/16.4		STRAIGHT RADIATOR JOINT OF PIPES.3/4"R						
5	3180150861	5/16.4	1,0	NIPPLE.3/4"R						
5	52637301	5/16.4	1,0	HOSE SLEEVE, 3/4"R						
5	224510206									
5	3180152101									
6	224510206	5/16.4	1.0	HOSE CLAMP, 19-28MM						
6	52637301	5/16.4	1.0	HOSE SLEEVE, 3/4*R						
6	3180150872	5/16.4	1.0	L-RADIATOR JOINT OF PIPES.3/4"R						
6	3180150861	5/16.4	1.0	NIPPLE.3/4"R						
6	252240101	5/16.4	1.0	MUFF, OUTS.1"-INS.3/4"R						
7	3180150831	5/16.2	1.0	BALL_VALVE.1/4"R						
8	3180152111	5/16.2	1,0	SOLENOID VALVE,24VOC,5W,BÜRKERT 330F						
9	51784609	5/16.2	1,0	NEEDLE VALVE,1/4"R						
12	3180152111	5/16.3	1,0	SOLENDID_VALVE,24VDC,5W,BÜRKERT 330F						
12	3180150901	5/16.3	1.0	NONRETURN VALVE.3/8"R						
12.	3180150901	5/16.4	1.0	NONRETURN VALVE, 3/B"R						
13	51784609	5/16.4	1.0	NEEDLE VALVE,1/4"R						
13	3180151945	5/16.4	<u> </u>	PRESSURE GRUGE,0-250kPa,1/4"R,GLYCERINE						
A1	3183054623	5/3.1	1,0	CONTROL MODULE FOR SCS 92						
<u>A1</u>	3183061092	5/3.1	1.0	PROGRAM FOR SCS92.VERSION Z.						
A1	3183058011	5/3.1	1,0	INSTRUCTION LABEL FOR SES 92						
R <u>1</u>	3183052181	5/3.1	1,0	SET OF TERMINALS FOR SCS 92, PHOENIX						
A1	490106904	5/3.1	1.0	CONNECTOR BODY, 4-POLE, ANPZ80591	-					
TS LIST					·····					
				Tetra Pak Processing Systems CCP UN 01.02.13	Terified Ness of Episn-project No. a					
				Processing Systems CCP UN 01.02.13	NR 35411-410					
				Project #e. 31821-9860-1						

Page

2

SEPARATOR Date Brauting He. SC S 9 Z B Drawing remarks 35411-410-1

0	1 2	Э	 	4 5 6 7 8	9
<u>POS. No.</u>	ARTICLE No.	PAGE REF.	QUANTITY	DENOMINATION	REV. No.
A11	3180152132	5/5.3	1.0	CURRENT RELAY,4-ZOMA,24VOC,ELECTROMATIC	
C1	3180152201	5/3.3	1.0	CAPACITOR, 0,47UF,63V	
C 2	3180152201	5/3.3	1.0	CAPACITOR, 0,47UF,63V	
C3	3180152121	5/3.5	1,0	CAPACITOR, 22.000UF, 404	
F10	490085220	5/3.6	1.0	FUSE, 2AF	
F10	3180151821	5/3.6	1.0	FUSE HOLDER, 5X20MM, IND WSI6 24/48V	
H1		5/7.1	1.0	LAMP LENS, GREEN, TELEMECANIQUE	
<u>H1</u>	3180151781	5/7.1	1.0	LAHP UNIT, BA95, <= 380V, TELEHECANIQUE	
H1	3180104051	5/7.1	1.0	BULB, BR95, 24V, 2W	
I1	3180195321	5/5.2	1.0	AMPERE METER, 4-20mA DC, IME R096	
<u>K50</u>	3180190981	5/11.7	1.0	TIME RELAY,12-24VOC.OMRON H5CL	
<u>K50</u>	3180151024	5/11.7	<u>1</u> _0	SPLASH GUARD FOR H3CA TIME RELAY	
K100	3180195271	5/11.5	1.0	TERMINAL RELAY, SPOT, 24V, LED, WEIDM. DK5R	
K101	3180159561	5/11.5	1,0	HINIATURE_RELAY, 2-POLE. 24VOC, LED	
K105	3180159561	5/11.1	1.0	MINIATURE RELAY, 2-POLE, 24VDC, LED	
K110	3180159561	5/13.1	1.0	MINIATURE RELAY.2-POLE.24VDC.LED	
K115	3180195271	5/13.2	1,0	TERMINAL RELAY, SPDT, 24V, LEO, WEIDM. DK5R	1
PC1	53940003	5/15.2	1.0	HIN.REDUCING VALVE,0-700kPa,1/8"R,NORGR,	
PC1	3180151943	5/15.2	1.0	PRESSURE GAUGE.0-1MPA.1/8"R,PLASTIC	
PC 2	3180125172	5/15.4	1,0	REDUCING VALVE,0-800kPa,1/4"R,NORGREN	
PC 2	3180151946	5/15.4	1,0	PRESSURE GRUGE.0-1MPa.1/4"R.GLYCERINE	
PC3	3180125151	5/16.0	1.0	REDUCING VALVE FOR WATER, 3/4"R, BRAUKMAN	
PC3	3160151945	5/16.0	1.0	PRESSURE GRUGE, D-250kPa, 1/4"R, GLYCERINE	
PC3	3180150911	5/16.0	1.0	T-PIPE, 3/4"R	
PC3	3180150921	5/16,0	1,0	MUFF, OUTS.3/4"-INS.1/4"R	
PC3	3180150871	5/16.0	1,0	STRAIGHT RADIATOR JOINT OF PIPES, 3/4"R	
PC3	52633707	5/16.0	1.0	NIPPLE, 1"-3/4"R	
S LIST					· · <u> </u>

Note	 <u> </u>		Tetra Pak Processing Systems	CCP	UN	01.02.13	Yerified HR	**** of Colum-project 35411-410	No. of Papes 30
Sign,	 		Project No.	3182	21-986	0-1	•		Cont. on page
0ate			Draxing Ho.	ſ	RATOR				Page
		Orawing remarks	35411-410-1	SCSS	28				3

	1 2	3		4 5 6 7 8	9
POS. No.	ARTICLE No.	PAGE REF.	QUANTITY	DENOMINATION	REV. No.
50	3180151372	5/2.2	1.0	SWITCH, K&N CA10-A201, ENCLOSED	
S1	3160152191	5/9.5	1.0	SWITCH, K&N CG8-A201	
<u>\$2</u>	3180152192	5/9.1	1.0	SWITCH, K&N CG8-S	
53	3180151769	5/8.4	1.0	MUSHROOM ACTUATOR, RED. TELEMECANIQUE	
53	3180151783	5/8.4	1.0	CONTACT BLOCK WITH HOLDER, NO+NC, TELEMEC.	
53	3180151789	5/8.4	3,0	CONTACT BLOCK.NC.TELEHECANIQUE	
<u>5</u> 3	4868260001	5/8.4	1.0	SIGN FOR EMERGENCY STOP.YELLOW.70MM DIAMETER	
SH1	9160151751	5/11.8	1,0	LAMP PUSHBUTTON ACTUATOR, GREEN, TELEMEC.	
SH1	3180151782	5/11.8	1.0	LAMP UNIT WITH CONTACT BLOCK,NO+NC,TELEM	
SH1	3180104051	5/11.8	1.0	BULB, BA9S, 24V, 2W	
SH2	3180151753	5/4.1	1.0	LAMP PUSHBUTTON ACTUATOR, YELLOW, TELEMEC.	
SH2	3180151782	5/4.1	1.0_	LAMP_UNIT WITH CONTACT BLOCK,NO+NC,TELEM	
SH2	3180104051	5/4.1	1.0	8ULB, BA9S, 24V, 2W	
<u>снз</u>	3180151755	5/4.4	1.0	LAMP PUSHBUTTON ACTUATOR, WHITE, TELEMEC.	
снз	3180151782	5/4.4	1.0	LRMP_UNIT WITH CONTACT BLOCK, NO+NC, TELEM	· · · ·
<u>снэ</u>	3180104051	5/4.4	1.0	BULB, BA9S, 24V, 2W	
снз	3180151788	5/4.4	Z, D	CONTACT BLOCK, NO, TELENECRNIQUE	
T1	3180152181	5/3.1	1.0	TRANSFORMER, 130VA. SHIELDED, SCS 92	
V1	3180113581	5/3.5	1.0	RECTIFIER, 25A, 60V	
V2	3180114751	5/12.1	1,0	DIDDE, 1A. 1000V	
¥3	3180114751	5/12.2	1,0	DIODE.18,1000V	
V4	3180114751	5/12.4	1.0	DIODE, 18, 1000V	
V5	3180114751	5/12.5	1,0	DIODE, 18, 1000V	
V6	3180114751	5/12.6	1,0	DIODE, 18, 1000V	
V7	3160114751	5/12.8	1.0	DIODE, 19, 1000V	··
NO_1	3160151708	5/2.5	6,0	EARTH TERMINAL, WPE2.5	
W0_2	3180159611	5/2.6	2,0	METAL SUPPORT FOR CONNECTION BAR	
RTS LIST					
					of Eplan-project. Ma. of
┼─┼─┼				Processing Systems CCP UN 01.02.13 HA 35	411-410
+ $+$ $+$				Project No. 31821-9860-1	Cent.
					Page
				SCS92B	
		Orawing remarks	s	35411-410-1	

0	1 2	3		
POS. No.	ARTICLE No.	PAGE REF.	QUANTITY	DENOMINATION REV. No.
W10	3180159611	5/2.5	2.0	METAL SUPPORT FOR CONNECTION BAR
W10	3180111782	5/2.5	1,0	CONNECTION BAR, 10X3HH
X21	3180151707	5/1.0	1.0	TERMINAL ROW, 2-POLE+PE, WOU2, 5
X21	353021401	5/1.0	5.0	TOUCH PROTECTION FOR TERMINAL, WADS
X22	3180151707	5/3.2	1,0	TERMINAL ROW, 2-POLE+PE, WOUZ, 5
X24	3180152612	5/5.1	1.0	TERMINAL ROW,1-35,WDU2,5
<u>X24</u>	3180152612	5/5.2	1.0	TERMINAL ROW.1-35.WOU2.5
X25	3180151701	5/12.1	1.0	TERMINAL RDW,1-25.WOU2.5
Y <u>21</u> _	3180152012	5/13.3	1.0	SOLENDID VALVE.1X3.24V.2W.BÜRKERT
¥24	3180152012	5/13.6	1.0	SOLENDID VALVE, 1X3, 24V, 2W, BÜRKERT
<u>Z1</u>	3180116161	5/2.2	1.0	MAINS FILTER, SA
2PNE	3180150831	5/1.2	1,0	BALL VALVE.1/4"R
<u>ZPNE1</u>	1995101048	5/1.2	<u>2</u> ,0	AIR TUBE,6/4
ZPNE1	1995106130	5/1.2	2,0	CABLE, 612X0.5mm0
ZWAT	1995101050	5/1.3	_2,0	RIR TU8E,10/8
ZWAT	1995101045	5/1.3	1.0	PLASTIC HOSE, 26/19
ZWRT	1995106491	5/1.3	3,0	CABLE, 63X0, 75mm0
<u>ZW</u> RT	3182030441	5/1.3	2 , D	HOLDER FOR SOLENOID VALVE, SCS, 2PCS
ZZA	3180118742	5/1.2	_5.0	RUBBER GROMMET, 5-7MM
<u>ZZ</u> A	352103111	5/1.2	8.0	CABLE INLET, 9-14mm, PR22, 5, PLASTIC
Z Z A	9904000003	5/1.Z	1.0	SIGN, "TETRA PAK,LOGOTYPE", 260X38mm
<u>Z Z A</u>	3182030421	5/1.2	1,0	CABINET FOR SCS92.STAINLESS STEEL
ZZA	901940016	5/1.2_	3.0	CAUTION SIGN, "VOLTAGE ARROW", 50x50mm
ZZA	3180118743	5/1.2	5.0	RUBBER GROMMET.7-10MM
<u>ZZA</u>	3180118744	5/1.2	6,0	RUBBER GROMHET, 10-14MM
TS LIST				
				A Tetra Pak Department Bestgner Date Yerified Need of Ealen-project No.
 				Processing Systems CCP UN 01.02.13 MA 35411-410

Graving No.

35411-410-1

Drawing remarks

Date


5


P=0=

SEPARATOR

SCS92B

0	-	1	1	2		3			4	1	5	1	<u>this draving m</u>	<u>ist pol with</u> e	<u>qut the consen</u> 7	nt of Tetra	P ## 88 50	<u>copied, tren</u> 8	saitted or disc	d to eny th 9
POS.	<u>N</u> o.	ART	ICLE No	b .	PAGE	REF.	QUAN	TITY	DENO	MINATI	EON								REV	No.
ZZE			31801519	22	5/1.2			1.0	PLASTI	C FLANG	Ê,FL21,1	ZXPRZZ,	5, HB1001	.4						
ZZE	_		31801124	92	5/1.2			1.0	RUBBER	GAŞKET	, FL 21									
ZZĘ			31801526	99	5/1.2		-	4,0	RIVET	FOR FLA	NGE,GASK	ET						<u> </u>		
							-	a 1.000												
									<u> </u>	<u></u>			-							
		<u> </u>							_											
	-	_																		
				_														<u> </u>	-	
		_																		
	<u> . </u>										_									
				_																
	_																			
							-				<u></u>									
		_																	_	
					_	, _														
																			_ <u></u>	
		_	<u> </u>								_									
	_									_										
		<u> </u>					<u> </u>												_	
	··· -				•		+		<u> </u>										_	
n		<u> </u>								• · · · · · · · · · · · · · · · · · · ·					<u> </u>					
TS LIS	 5Т			<u>L</u>			<u> </u>				, <u></u>									
										T	etra 1	°ak	De	per Leavet	Designer	Oate		(erified	Name of Epien-	
										O ^e	etra i rocessin	g Syste	ns C	<u>CP</u>	UN	01.0	2.13	HA	35411-4	10 [ant.
										Project Ho.					1-986					=
										Oreving No.		·			RATOR					P = 0 +
				D	rawing	remark:	s			3541	1-410	-1		\$633	2 B					






۰.

.

	Ints draving ours not without the contact of Terre Pak AB be copied, transisted or disclosed to any third p 5 6 7 8 9 9
	$ \begin{array}{c} $
<u>A — A</u>	<u>B — B</u>
ASSEMBLY DRAWING 3	Tetra Pak Processing Systems Operation CCP Dester Dester Tetra Pak 01.02.13 Mess of Extended State Mess of Extended State

· •




											This draws	ng must not with	out the consent		e copied, true	unitted or disclosed t	a any third party.
	0	I	1		2		3	·	1	5	6		7	ļ	6		9
				· .													
				TOF	NTTETCO	TTON 05	UTRINC	THETOP	CONTO	0							
				105	NIIFICH	IION OF	WIRING	INSIDE		OL CABINET							
				C 0	LOR CODING	IS USED I	FOR IDENTI	FICATION O	F SINGLE	-CORE CABLES:							
				GR	EEN-AND-YE	LLOW	EART	Н СОНОИСТО	RS								
					UE		NEUT	RAL CONDUC	TORS								
				BL	ACK N			R CIRCUITS Control C									
					UE			CONTROL C									
				OR	ANGE			RLOCKING C									
							SUPP	LIED FROM	EXTERNAL	POWER							
				CR	OSS-SECTIO	N OF SINGL	LE-CORE CA	BLES IS O,	75mm² IF	NOTHING ELSE	IS SPECIFIED	Ι.					
				L			<u></u>										
IDE	<u>NT</u> IFI	CATI	<u>on</u> of	WIRIN	G INSIE	E CONTR	ROL CABI	[N E T									
Note	Т					·				A Tetra P	Pak	Guperisant	Designer	0.1.4	¥ar 1 Find	Hase of Enlen-project	Ho. of pages
ND L C										Tetra f	g Systems	ССР	UN	01.02.13	94	35411-410	Э0
Sign.										Diect No.		2103	1 000	0 1			Cont. on page
													21-986) Irator	0-1			1
Oate									Ori	aving No.							
			ĺ			Drawing r	emarks			35411-410	-5	3139	20				0
											3	1					


Å


•


0 1	2 3	4	5	this drawing most ng 6	L without the const 7		8 8	9
								→ L/2.0 → N/2.0
	Ъ							
x210 1 0 2 0 H0_1	X/W100	·						
								
						٠.		
STARTER ZUV-F/ZUV-N								
HAINS SUPPLY 1-50/60Hz 24V Fuse (A): 6	INSTALLATIONS Grounding point							
FUSE (A): 6								
ONTROL, SUPPLY VOLTAG	E							
<u>a</u> ZZ	A ZPNE ZWAT		Tetra Pak	stems CCP	ns Designer UN	01.02.13 H	ified Neve of Eplen-ord 35411-41(
n ZZI	ZPNE1		Project No.	31	821-986		ł <u></u>	Cont. on 2
e			Draving Ho.		PARATOF S928	र		P 6110
	Drawing remarks		35411-410-5					1


.
















*






























,






LIST OF CONTENTS 0-00 IDENTIFICATION OF DOCUMENTS 0-01 IDENTIFICATION OF DOCUMENTS 0-02 IDENTIFICATION OF DOCUMENTS 0-03 SCR37 DI AVERTER SUMMER SUMMER 0-04 INVENTER SUMMER SUMMER 0-05 SCR37 DI AVERTER 0-05 SCR37 DI AVERTER 0-05 SCR37 DI AVERTER SUMMERER 0-05 FRED. INVERTER SUMMERER 0-05 SCR37 DI AVERTER SUMMERER		5	5	7		8	ted or disclosed to any
-0/0 IDEWISICATION OF DOCUMENTS -0/1 LIST OF CONTENTS -0/1 LIST OF CONTENTS -0/2 SCS92 SUPPLY -5/2 SCS92 SUPPLY -5/3 SC92 TO INVERTER STRATER -9/4 INVERTER STRATER TO RECO. INVERTER -9/5 FREG. INVERTER STRATER -9/6 CONTENL CABLES TO INVERTER -9/6 CONTENL CABLES TO INVERTER -9/7 CONTROL CABLES TO INVERTER -9/8 CONTAGL CABLES TO SCS92 -9/9 CONTAGL CABLES TO SCS92 -9/1 O RENOTE CONTAGL CABLES TO SCS92	LIST OF 1	CÓNTENTS					
-0/0 TOENTFICATION OF DOCUMENTS -0/1 LIST OF CONTENTS -0/1 LIST OF REOL INVERTER STARTER -0/2 SCS2 TO INVERTER TO HOTOR -0/1 REOL TAREER TO HOTOR -0/1 CONTENL CABLES TO INVERTER STARTER -0/2 CONTROL CABLES TO INVERTER STARTER -0/2 CONTROL CABLES TO SCS92 -0/1 DERNOTE CONTROL CABLES TO SCS92 -0/2 CONTROL CABLES TO SCS92 -0/1 DERNOTE CONTROL CABLES TO SCS92 -0/2 CONTROL CABLES TO SCS92		· · · · · · · · · · · · · · · · · · ·					
-0/1 LIST OF CONTENTS -3/2 INVERTER STARTER SUPPLY -3/2 SCS2 SUPPLY -3/3 SCS2 TO INVERTER STARTER -3/4 INVERTER STARTER TO FRED. INVERTER -3/5 SCS2 TO FRED. INVERTER -3/6 CONTROL CABLES TO INVERTER STARTER -3/7 CONTROL CABLES TO INVERTER STARTER -3/6 CONTROL CABLES TO INVERTER STARTER -3/7 CONTROL CABLES TO INVERTER STARTER -3/8 CONTROL CABLES TO SUBJECT TO SCS92 -5/10 RENOTE CONTROL CABLES TO SCS92		REVISION PAGE CONTENTS			•		
-5/1 INVERTER STARTER SUPPLY -5/2 SCS2 SUPPLY -5/3 SCS2 TO INVERTER STARTER -5/4 INVERTER STARTER -5/5 SCS2 TO INVERTER STARTER -5/5 SCS2 TO INVERTER STARTER -5/6 CONTROL CABLES TO INVERTER STARTER -5/7 CONTROL CABLES TO SUPERTER -5/7 CONTROL CABLES TO SUPERT							
-5-72 SCS92 SUPPLY -5-73 SC92 TO INVERTER STARTER -5-74 INVERTER STARTER TO FRED. INVERTER -5-75 SCS92 TO FRED. INVERTER -5-76 EDMTRDL CABLES TO INVERTER STARTER -5-76 CONTROL CABLES TO INVERTER STARTER -5-79 CONTROL CABLES TO SCS92 -5/10 REMOTE CONTROL							
-5/3 SC92 TO INVERTER STARTER -5/4 INVERTER STARTER TO FRED. INVERTER -5/5 SC92 TO FRED. INVERTER -5/6 SRED. INVERTER TO HOTOR -5/7 CONTROL CRALES TO INVERTER STARTER -5/8 CONTROL CRALES TO INVERTER STARTER -5/9 CONTROL CRALES TO SC92 -5/10 RENOTE CONTROL SC92 -5/10 RENOTE CONTROL CRALES TO SC92 -5/10 RENOTE CONTROL CRALES TO SC92 -5/10 RENOTE CONTROL SC92 -5/10 RENOTE CONTROL SC92 -5/10 RENOTE CONTROL CRALES TO SC92 -5/10 RENOTE CONTROL SC92 -5/10 RENOTE CONTROL CRALES TO SC92 -5/10 RENOTE CONTROL SC92							
-5/4 INVERTER STARTER TO FRED. INVERTER -5/5 SCS92 TO FRED. INVERTER -5/6 CONTROL CABLES TO INVERTER STARTER -5/6 CONTROL CABLES TO INVERTER STARTER -5/6 CONTROL CABLES TO SCS92 -5/10 RENOTE CONTROL CABLES TO SCS92							
-5/5 FRED. INVERTER TO NOTOR -5/7 CONTROL CABLES TO INVERTER STARTER -5/8 CONTROL CABLES TO INVERTER STARTER -5/9 CONTROL CABLES TO SCS92 -5/10 RENOTE CONTROL CABLES TO SCS92 -5/1							
-5/7 CONTROL CROLES TO INVERTER STRATER -5/6 CONTROL CROLES TO SCS92 -5/10 REMOTE CONTROL CROLES TO SCS92							
-5/6 CONTROL CROLES TO INVERTER STARTER -5/9 CONTROL CROLES TO SCS92 -5/10 REMOTE CONTROL CROLES TO SCS92 							
-5/9 CONTROL CABLES TO SCS92 -5/10 REMOTE CONTROL CABLES TO SCS92							
-5/10 REMOTE CONTROL CABLES TO SCS92							
OF CONTENTS							
OF CONTENTS	=5/10 REMOTE CONTROL CABLES TO SCS92						
I OF CONTENTS							
OF CONTENTS							
OF CONTENTS							
OF CONTENTS Tetra Pak Descrition Marriel Mar							
Indextor Description Description Description Description Vertified Mass of Extension3det N 1.04.09 0.04.09 0.04.00	· · ·						
N Deportation Date Verified Mase of Enten-project N 1.04.09 01.03.12 N 01.03.12 N 01.03.12 N							
N Deportation Date Verified Mase of Enten-project N 1.04.09 Drating Mo. Deportation CCP UN 01.03.12 Mase of Enten-project							
N Deportation Date Verified Mase of Enten-project N 1.04.09 01.03.12 N 01.03.12 N 01.03.12 N							
N Deportation Date Verified Mase of Enten-project N 1.04.09 Drating Mo. Deportation CCP UN 01.03.12 Mase of Enten-project							
N Deportation Date Verified Mase of Enten-project N 1.04.09 Drating Mo. Deportation CCP UN 01.03.12 Mase of Enten-project				-			
N Deportation Date Verified Mase of Enten-project N 1.04.09 01.03.12 N 01.03.12 N 01.03.12 N						-	
N Image: Constraint of the state of the	OF CONTENTS						
Prosect No. SCS92 ~ INV.STARTER		A Tetra Pak			1 1		
L.04.09 SCS92 - INV.STARTER							1411-420H1
	N I I	Project No.	SCSS	92 - I	[NV.START	ER	
							Per





•





· • -


		•	This gravin	g sust ngt ujihaw	the conser	IL of Jairs 944 AB b.	e capied, to end	Initial or disclosed to	ony third porty.
0 1 1	2 .3	4, 5	6		7		8		9
	INVERTER STARTER	W2:1 E TABLE IN CIRCUIT DIAGRAN) 1 2 3 4	FREQ. IN	VERTER		FREQ. I Supply (NVERTER CABLE		
13MI CONTRICTOR.	X3: 1390 1 1400 2 1410 3 1420 4 K111:	W60 (6+0.5) (A 1 2 3 4	• 0 04 • 0 05 • 02 • 01			FEEDBACH DELAYED RUNSIGNA +24¥DC	FEEOBAC		
	110 <u>5</u>	5 6	• 12 • 18 • 27			STARTS <u>I</u> (5NAL		
INVERTER STARTER TO FRE	O. INVERTER								
Note 1		Tetra Processi	Pak ng Systems	CCP	Designer UN	01.03.12	verified NA	35411-420A1	
19n. UN		Project Ho.		scsa	2 - I	NV.STAR	TER		5 Page
iele 01.04.09	Drawing remarks	<u> </u>	0-5	INTER	RCONN	ECTION	DIAGRA	M	ц


.


- · ·












١

.

4

*1



2. Motor starter

🔊 Tetra Pak

MM2.2100014en2.fm

4;

This page intentionally left blank

Š

	$\bullet \bullet$		\bullet			
0	2 3	4 5 6	ing must not without the consent 7	of lairs Pak AB be copied, iron	entitied or disclosed to e	
	31821-9855-1 SEPARATOR INVERTER STAF	RTER PANEL				
	IDENTIFICATION OF DOCUMENTS	· · · · · · · · · · · · · · · · · · ·				
						2
	THE LAST DIGIT IN THE DRAWING NUMBER IS -0 LIST OF CONTENTS -1 PARTS LIST -2 FUNCTION EXPLANATION -3 SOFTWARE DOCUMENTATION -4 ASSEMBLY DRAWING -5 CIRCUIT DIAGRAM -6 INTERCONNECTION TABLE -7 INSTALLATION DRAWING (E.G. 3541-****-5 IS A CIRCUIT DIAGRAM)	USED TO IDENTIFY THE TYPE OF OOCUHE	NT :			
IDENTIFICATION OF	DOCUMENTS					
Note		Tetra Pak Processing Systems	CEP MA	Data Verified 01.12.12 JL	Name of Eplan-project 35411-40483	'
Sign.		Project He.	31821-9855 SEPARATOR	L		iont, on page 1 ingu
	Drawing remarks	35411-404-0			-	0

• •

	n					-											·
							LIST O	F CONTE	NTS		=						
									•								
REVISION	_ <u>₽</u> ₽₿ ⇒0/0	<u>é contents</u> IDENTIFI	CATION O	F DOCUMEN	ITS				REVISION	PAGE CONTEN	15						
23	=0/1	LIST OF	CONTENTS														
23	-1/1	PARTS LI	ST														
	□ 1/2	PARTS LI	ST														
z	=4/1.	1 ASSEMBLY	DRAWING	6 (3182030	1432)												
z	=4/1.	2 ASSEMBLY	DRAWING	6 (3182030	1433)												
2	=4/1.	3 ASSEMBLY	DRAWING	6 (3182030	1462)												
	=5/0	IDENTIFI	CATION O	F WIRING	INSIDE CON	NTROL CAB	INET										
	=5/1	MOTOR, S	UPPLY VO	LTAGE													
	-5/2	CONTROL.	SUPPLY	VOLTAGE													
	=5/3	CONTROL.	SUPPLY	VOLTAGE													
	=5/4	CONTROL	LOGIC														
2 Э	-5/5	CONTROL	LOGIC														
23	-5/6	CONTROL	LOGIC														
23	=5/7	SPEED GU	ARD														
2	=5/8	SIGNALS	FOR FRED	I. INVERTE	R												
	=7/1.	1 INSTALLA	TION DRA	WING (318	2030432)												
	-7/1.	2 INSTALLA	TION DRA	WING (318	2030433)												
	=7/1.	9 INSTALLA	TION DRA	IWING (318	203046Z)												
				_					_								
T OF	CONT	ENTS					-										
1	2	з							▲ Tetr	a Pak		CP	MA	01.12.1	7 11 11 11 11 11 11 11 11 11 11 11 11 11	8000 of Eplen-proje	
או	UN	AL				ı.				sing Syste			<u> </u>				Can
··,		<u> </u>				1		Praj	jacl Ao.				1-985				
11.02.0	5 01.04.09	01.12.06						Orav	ing Ho.			- SEPARATOR Inverter starter panel			F=0		
	1				rawing rem				35411_0	~ ~ ~		1 17 F L	NICN	JINNICI	N TUNE	L	

35411-404-0

Drawing remarks


0	1 2	3		this draving aust not with 5 6	<u>pout the content of fetre Pek AB be copied, tren</u> 7 8	smilled or disclosed to any this
POS. No.	ARTICLE No.	PAGE REF.	QUANTITY	DENOMINATION		REV. No.
<u>A10</u>	3180191551	5/7.4	1.0	F/I CONVERTER. 24VDC. PR ELECTRONICS 5225A2	· · · ·	з
F31	99049251	5/2.1	1.0	CIRCUIT BREAKER, 1-POLE, 2RD		
F34	99049205	5/2.3	1.0	CIRCUIT BREAKER, 1-POLE, 6A		
<u>61</u>	99050346	5/8.1	1.0	FREQUENCY RC DRIVE 40DV, IP54, VLT5032		3
61	99050348	5/8.1	1,0	FREQUENCY RC DRIVE,400V.1P54,VLT5052		3
<u>61</u>	99050394	5/8.1	1.0	FREQUENCY AC DRIVE,400V,1P54,VLT5062C		3
К1	3180191992	5/6.1	1.0	CONTACTOR, DIL-2M, 44A, 230VRC, K&M		
К1	3180151646	5/6.1	1.0	AUXILIARY CONTACT, 11DIL, K&M		
K10	901190111	5/4.1	1.0	SAFETY RELAY, 230VAC, JOKRB RT6		
_K100	3180195271	5/5.2	1.0	TERMINAL RELAY, SPOT, 24V, LED, WEIDM. OK5R		
K101	3180159561	5/5.3	1.0	MINIATURE RELAY, 2-POLE, 24VDC, LEO		
K105	3180195271	5/5.4	1,0	TERMINAL RELAY.SPOT,24V,LED,WEIDM. DK5R		
K106	3180159561	5/5.5	1.0	MINIATURE RELAY.2-FOLE,24VOC.LED		-
K110	3180159561	5/6.6	1,0	HINIATURE RELAY, 2-FOLE, 24VDC, LEO		
K111	3180195271	5/6.7	1,0	TERMINAL RELAY.SPOT.24V,LED.WEIDM. DK5R		
K115	3180159561	5/5.8	1.0	MINIATURE RELRY, 2-FOLE, 24VDC, LED		
<u>K200</u>	3180159561	5/7.5	1.0	MINIATURE RELAY.2-POLE,24VDC.LED		
К210	3180159561	5/8.9	1.0	MINIATURE RELAY.2-POLE.24VDC.LED		1
<u>K220</u>	3180195271	5/7.2	1.0	TERMINAL RELAY.SPDT.24V.LEO.WEIDM. DK5R		1
K221	3180159561	5/7.3	1,0	MINIATURE RELAY, 2-POLE, 24VDC, LED		2
P1	3180151802	5/6.0	1.0	OPERATING TIME METER, 230VAC, MÜLLER		
00	99049014	5/1.0	1,0	HANDLE.K&H H-NZH7	n	_
00	99049015	5/1.0	1,0	SHAFT,K&M A-400-NZK7		
00	99049022	5/1.0	Z, O	TERMINAL, K&M_ST160-NZM7		
00	99049009	5/1.0	1.0	AUXILIARY CONTRCT.K&M EK10		
00	99049010	5/1.0	1,0	RUXILIRRY CONTACT.K&M EKO1		
00	3592410124	5/1.0	1.0	SYMBOL SIGN "MRIN SWITCH"		
RTS LIST					- • • • • • • • • • • • • • • • • • • •	
1 2 3				Tetra Pak Processing Systems	MA Di. 12.12 JL	Home of Epilen-project Ho. of a 35411-404A3 1
นท แท ค.						Cant. on
01.02.05 01.04.09 01.12	_D6			5102	21-9855-1 Irator	
		 Drawing remarks	···· <u>-</u>	of Ballio Rot	RTER STARTER PANEL	└ │ 1


POS. No.	ARTICLE No.	PAGE REF.	QUANTITY	DENOMINATION	REV. No.
00	99049002	5/1.0	1.0	CIRCUIT BREAKER.K&M_NZM7-63N-H+DA	
00	99049003	5/1.0	1.0	CIRCUIT BREAKER,K&M NZM7-80N-M+DA	
00_1	99048506	5/2.2	1.0	HOTOR PROTECT.PKZH0-1.6	
00_1	99048507	5/2.2	1.0	MOTOR PROTECT, PKZHO-2,5	
TO	3180152592	5/2.1	1.0	TRANSFORMER, 200-480/230+24V, 500VA, SHIELDED	
<u>w0_1</u>	3180111782	5/3.1	1,0	CONNECTION BAR, 10X3HM	
W0_1	3180159611	5/3.1	3,0	METAL SUPPORT FOR CONNECTION BAR	
W0_2	3180159611	5/3.1	2,0	METAL SUPPORT FOR CONNECTION BAR	
W10	3180159611	5/3.2	2,0	METAL SUPPORT FOR CONNECTION BAR	
X3/4/K	3180152245	5/5.5	1,0	TERMINAL ROW.SES CT	
ZO		5/2.1	1.0	MAINS FILTER, SA	
Z1	3180115963	5/2.3	1.0	MAINS FILTER,10A	
22	3180191701	5/7.4	1.0	HRINS FILTER, 1A, SCHAFFNER FN332	
ZZA	9904000003	5/1.2	1.0	SIGN, "TETRA PAK, LOGOTYPE", 260X38mm	
ZZA1	352103111	5/1.2	3,D	CABLE INLET,9-14mm,PR22.5,PLASTIC	
ZZAP	3182030462	_5/1.3	1,0	CABINET FOR SCS CT.PAINTED,ELDON AS08083	
<u>ZZRP</u>	3180151922	5/1.3	1.0	PLASTIC FLANGE, FL21, 12XPR22, 5, NB10014	
ZZAP	3180151924	_5/1.9	1.0	PLASTIC FLANGE, 21, 4XPR22, 5+3X37, MB10017	
ZZAP	352103121	5/1.3	3,0	CABLE INLET, 14-25mm, PR37, PLASTIC	
ZZAP	3180112492	5/1.3	2,0	RUBBER GASKET, FL21	
22AP	3180152699	5/1.3	в.0	RIVET FOR FLANGE, GASKET	
ZZAS	3182030432	5/1.3	1,0	CABINET FOR SCS CT.670×900×300,STAINL. STEEL	
<u>ZZAS</u>	3182030433	5/1.3	1.0	CABINET FOR SES CT. 800×1200×300.STAINL. STEEL	
<u>ZZAS</u>	99048046	5/1.3	3.0	CABLE_INLET,17-26mm,PR47,PLASTIC	
<u> </u>					
IS LIST					
				▲ Tetra Pak	rified Nese of Eplan-oroject No. of


 Sign.
 31821-9855-1
 =4/1.1

 Date
 Braving remarks
 35411-404-1
 SEPARATOR


 Drawing remarks
 35411-404-1
 2









	0	r	1	2	3	4	5	This drawing must not 6	vilhout the cane	ant of Selve Pek AS be	copied, ire 8	saittad or disclosed to	9
	-			, -	1	• •				I	,	I	_
				IDENTIFICAT	ION OF WIRING	INSIDE CONT	ROL CABINET						
				GREEN-RND-YEI Blue Black Red Blue Orange	NEUT Powe A.C. D.C. Inte	H CONDUCTORS RAL CONDUCTORS R CIRCUITS CONTROL CIRCUITS CONTROL CIRCUITS RLOCKING CONTROL LIED FROM EXTERNA	CIRCUITS, DWER	S SPECIFIEO.					
	<u>†1F1</u>	CATI	DN OF	WIRING INSID	E CONTROL CABI	INET		Geperteen	Deiloner	0eca	Yarsfied	Naso of Epigen-großpet	Ro. of Dag
Nate							Tetra Pa Processing	ak Systems CCP	НА	01.12.12		35411-404A	19
Sign.							Project No.	31	821-98				Cont. on pe
Date			. 1				Drewing Ho.	SE	PARATO	२			P408
								ты	VERTER	STARTER	PONE	1	0





. . . .





•

















. . .









·

3

· · · .

3. Other components

MM2.2100013_1en2.fm

3. Other components

This page intentionally left blank

MM2.2100013_1en2.fm



VLT* is a trademark of Danioss A/S

990503-01 R1



Changes in parameters and settings for the VIT 5000 Series Software version 3.4x

New parameters for Software Version 3.4x

455 Frequency range monitor (MON. FREQ. RANGE)

Value: Disable [0] [1]

🖈 Enable

Function: This parameter is used if warning 35 Out of frequency range must be turned off in the display in process control closed loop. This parameter does not affect the extended status word.

Description of choice: Select Enable [1] to enable the readout in the display if warning 35 Out of frequency range occurs. Select Disable [0] to disable the readout in the display if warning 35 Out of frequency range occurs.

557 Data read-out: Motor RPM (MOTOR RPM)

Value: Unit: RPM

Function: This parameter can be read out via the serial communication port. The value is updated every 80 ms.

Description of choice: The displayed value corresponds to the actual motor RPM. In open loop or closed loop process control, the motor RPM is estimated. In speed closed loop modes, it is measured.

558 Data read-out: Motor RPM x scaling (MOTOR RPM X SCALE)

Value: Unit: RPM x scale

Function: This parameter can be read out via the serial communication port. The value is updated every 80 ms.

Description of choice: The displayed value corresponds to the actual motor RPM multiplied by a factor (scaling) set in parameter 008.

New parameter settings

- For parameters 009-012 the following settings have been added for software version 3.4x:

RPM [min-1] (MOTOR RPM [RPM])	[31]
RPM x scaling [min ⁻¹] (MOTOR RPM X SCALE)	[32]

RPM [min⁻¹] indicates the motor speed. In speed closed loop, the value is measured. In other modes the value is calculated based on the motor slip. RPM x scaling [min⁻¹] indicates the motor RPM multiplied by a factor set in parameter 008

- For parameter 200 the following settings have been added for software version 3.4x:

Only counter clockwise, 0-132 Hz	
(132 Hz COUNTERCLOCK)	[4]
Only counter clockwise, 0-1000 Hz	
(1000 Hz COUNTERCLOCK)	[5]

Note that if Clockwise, 0-132 Hz [0], Clockwise, 0-1000 Hz [2], Counter clockwise, 0-132 Hz [4] or Counter clockwise, 0-1000 HZ [5] is selected, the output frequency will be limited to the range f_{MIN} - f_{MAX}

continued....

6.100

MG.50.A9.02 - VLT is a registered Danfoss trademark



VLT' 5000 Series

For parameter 319 and 321 the following settings have been added:

Outputs	terminal no.	42	45
	parameter	319	321

Value:

Mechanical brake control	(MECH. BRAKE CONTROL)	[32]	[32]
Extended mechanical brake con	trol (EXT. MECH. BRAKE)	[34]	[34]
$0 - \text{SyncRPM} \Rightarrow 0.20 \text{ mA}$	(0-SYNCRPM = 0-20 mA)	[60]	[60]
$0 - \text{SyncRPM} \Rightarrow 4-20 \text{ mA}$	(0-SYNCRPM = 4-20 mA)	[61]	[61]
$0 - \text{SyncRPM} \Rightarrow 0-32000 \text{ p}$	(0-SYNCRPM = 0-32000 p)	[62]	[62]
0 - RPM at $F_{MAX} \Rightarrow 0.20 \text{ mA}$	(0-RPMFMAX = 0-20 mA)	[63]	[63]
0 - RPM at $F_{MAX} \Rightarrow 4-20 \text{ mA}$	(0-RPMFMAX = 4-20 mA)	[64]	[64]
0 - RPM at $F_{MAX} \Rightarrow 0.32000 \text{ p}$	(0-RPMFMAX = 32000 p)	[65]	[65]

0 - SyncRPM \Rightarrow 0-20 mA and 0 - SyncRPM \Rightarrow 4-20 mA and 0 - SyncRPM \Rightarrow 0-32000 p, an output signal proportional to the synchronous motor RPM is

obtained.

0 - *RPM at* $F_{MAX} \Rightarrow$ 0-20 *mA* and 0 - *RPM at* $F_{MAX} \Rightarrow$ 4-20 *mA* and 0 - *RPM at* $F_{MAX} \Rightarrow$ 0-32000 p, an output signal proportional to the rated motor RPM at F_{MAX} (parameter 202) is obtained.

Conversion index and data type

PNU	Parameter	Factory setting	Conversion	Data
#	description		index	type
455	Frequency range monitor	Enable	0	5
557	Data read-out: Motor RPM		0	4
558	Data read-out: Motor RPM x scaling		-2	4
558	Data read-out: Motor RPM x scaling	·	-2	4

Change of name

_

The name *Profidrive* is generally changed to *Fieldbus profile* including parameter 512.



VLT' 5000 Series

Safety	4
Introduction	6
Technical data General technical data Technical data, Bookstyle IP 20 Technical data, Compact IP 20 and IP 54	8 12 13
Measurements, dimensions	21
Mechanical installation	25
Electrical installation	37 38 39 44
Operation of the VLT frequency converter Control panel Control keys Display Mode Quick Setup via Quick menu Changing data Menu structure	48 49 50 51 52
Application configuration	55 55 56 56 57



. .

VLT' 5000 Series

Special functions	
Shift between local and remote control	
Control with brake function	
Handling of single references	
Handling of multi-references	
Automatic Motor Adaptation	
Control of mechanical brake	
PID for process control	
PID for speed control	
Quick discharge	
Mains failure/quick discharge with mains failure inverse	
Flying start	
Normal/high overload Torque control, open loop	. 74
Programming of Torque limit and stop	74
Description of parameters	76
Operation & Display Parameter 001 - 019	
Load & Motor Parameter 100 - 131	
References & Limits Parameter 200 - 234	
Inputs & Outputs Parameter 300 - 330	102
Special functions	110
Serial communication Parameter 500 - 541	
Technical functions Parameter 600 - 631	
Relay functions Parameter 700 - 711	14/
Fault procedure	
Display texts	
Status messages	152
List of warnings and alarms	152
Warning words 1 + 2 and Alarm word	160
	100
Definitions	16 1
Factory settings	164
Index	171

MG.50.A9.02 - VLT is a registered Danfoss trademark

.

Danfoss

VIT 5000 Series

Operating Instructions Software version: 3.3x

CE

These Operating Instructions can be used for all VLT 5000 Series frequency converters with software version 3.3x. The software version can be seen from parameter 624.

Danfoss



 Intervoltage of the frequency converter

 is dangerous whenever the equipment

 is connected to mains. Incorrect instal

 is motor or the frequency converter may

cause damage to the equipment, serious personal injury or death.

Consequently, the instructions in this manual, as well as national and local rules and safety regulations, must be complied with.

Safety regulations

- The VLT frequency converter must be disconnected from mains if repair work is to be carried out. Check that the mains supply has been disconnected and that the necessary time has passed before removing motor and mains plugs.
- The [STOP/RESET] key on the control panel of the VLT frequency converter does <u>not</u> disconnect the equipment from mains and is thus <u>not to be used</u> <u>as a safety switch.</u>
- Correct protective earthing of the equipment must be established, the user must be protected against supply voltage, and the motor must be protected against overload in accordance with applicable national and local regulations.
- The earth leakage currents are higher than 3.5 mA.
- Protection against motor overload is <u>not</u> included in the factory setting. If this function is desired, set parameter 128 to data value *ETR trip* or data value *ETR warning*.

Note: The function is initialised at 1.16 x rated motor current and rated motor frequency (see page 92).

For the North American market: The ETR functions provide class 20 motor overload protection in accordance with NEC.

- Do not remove the plugs for the motor and mains supply while the VLT frequency converter is connected to mains. Check that the mains supply has been disconnected and that the necessary time has passed before removing motor and mains plugs.
- Please note that the VLT frequency converter has more voltage inputs than L1, L2 and L3, when loadsharing (linking of DC intermediate circuit) and external 24 V DC have been installed. Check that all voltage inputs have been disconnected and that the necessary time has passed before repair work is commenced.

Warning against unintended start

 The motor can be brought to a stop by means of digital commands, bus commands, references or a local stop, while the frequency converter is connected to mains.
 If personal safety considerations make it

necessary to ensure that no unintended start occurs, these stop functions are not sufficient.

- While parameters are being changed, the motor may start. Consequently, <u>the stop key</u> [STOP/ RESET] must always be activated, following which data can be modified.
- A motor that has been stopped may start if faults occur in the electronics of the VLT frequency converter, or if a temporary overload or a fault in the supply mains or the motor connection ceases.

\land Warning:

Touching the electrical parts may be fatal - even after the equipment has been disconnected from mains. Also make sure that other voltage inputs have been disconnected, such as external 24 V DC, load-sharing (linkage of DC intermediate circuit), as well as the motor connection for kinetic back-up.

Using VLT 5001-5006: wait at least 4 minutes Using VLT 5008-5500: wait at least 15 minutes

Dantoss

These Operating Instructions are a tool intended for persons who are to install, operate and program the VLT 5000 Series.

Specific technical publications on the VLT 5000 Series: Operating Instructions, Design Guide and Quick Setup.

Operating Instructions:	Gives instructions in optimum installation, commissio- ning and service.
Design Guide:	Gives all required information for design purposes, and gives a good insight into the technology, pro- duct range, technical data, etc.
Quick Setup:	Helps the great majority of users to quickly get their VLT 5000 Series unit installed and running.

The Operating Instructions and the Quick Setup are delivered with the unit.

When reading these Operating Instructions, you will come across different symbols - that require special attention.

The symbols used are the following:



Indicates a general warning



Indicates something to be noted by the reader



Indicates a high-voltage warning



Why choose Danfoss?

Danfoss manufactured the world's first mass-produced frequency converter back in 1968. We have set the standard for quality drives ever since. That is why our VLT frequency converters are today sold and serviced in more than 100 countries covering six continents.

With the new VLT 5000 Series, we are introducing VVC^{plus}. This is our new Sensorless Vector Drive System for torque and speed control of induction motors.

If compared with a standard voltage/frequency ratio control, VVC^{plus} offers improved dynamics and stability, both when the speed reference and the load torque are changed. We have implemented a fully digitalised protection concept, which ensures reliable operation, even under the worst possible operating conditions. Naturally, the VLT 5000 Series also offers full protection against short-circuiting, earthing fault and overload.

Danfoss drives with the VVC^{plus} control system tolerate load shocks throughout their speed range and react swiftly to changes in reference.

However, it must also be easy to reach this performance. Danfoss is convinced that high-technology drives can be made user-friendly. The VLT 5000 Series proves us right. In order to make programming simple and easy-to-grasp, we have divided the parameters into different groups. The Quick menu guides users quickly through the programming of the few parameters that must be set to get started. The control panel is detachable. It features a four-line alphanumeric display, enabling four measuring values to be displayed at the same time. Via the detachable control panel, the programmed settings can be copied from one VLT frequency converter to the next. This means that there is no time to be spent on programming when changing drives or integrating an extra drive in the installation.


The entire programming process is easier than ever before. The VLT 5000 Series makes most adjustments automatically.

If you have any questions concerning VLT frequency converters, please call us. We have drive specialists all over the world ready to advise you on applications, programming, training and service.



Available literature

The chart below gives an overview of the literature available for the VLT 5000 Series. Please note that variations may occur from one country to the next.





•

■ Ger <u>Mai</u> Si

General technical data

Mains supply (L1, L2, L3): Supply voltage 200-240 V units	
Supply voltage 380-500 V units	
Supply frequency	50/60 Hz +/- 1%
Max. imbalance of supply voltage:	
VLT 5001 - 5011 / 380 - 500 V and VLT 5001 - 5006 / 200 - 240	V ±2.0% of rated supply voltage
VLT 5016 - 5052 / 380 - 500 V and VLT 5008 - 5027 / 200 - 240 V	±1.5% of rated supply voltage
VLT 5060 - 5500 / 380 - 500 V and VLT 5032 - 5052 / 200 - 240	V ±3.0% of rated supply voltage
Power factor / cos. φ	0.90/1.0 at rated load
No. of switches on supply input L1, L2, L3	approx. 1 time/min.
Max. shortcircuit rating	
See the section on special conditions in the Design Guide	

VLT output data (U, V, W):

Output voltage	
Output frequency	
Rated motor voltage, 200-240 V units	
Rated motor voltage, 380-500 V units	
Rated motor frequency	
Switching on output	
Ramp times	

Torque characteristics:

Starting torque, VLT 5001-5027, 200 - 240 V and VLT 5001-5052, 380 - 500 V 160% for 1 n	nin.
Starting torque, VLT 5032 - 5052, 200 - 240 V and VLT 5060-5500, 380 - 500 V 150% for 1 n	nin. ุ
Starting torque	ec.
Acceleration torque 10	0%
Overload torque, VLT 5001-5027, 200 - 240 V and VLT 5001 - 5052, 380 - 500 V 16	0%
Overload torque, VLT 5032 - 5052, 200 - 240 V and VLT 5060-5500, 380 - 500 V 15	0%
Arresting torque at 0 rpm (closed loop) 10	0%
The torque characteristics given are for the VLT frequency converter at the high overload torque level (160%). At the normal overload torque (110%), the values are lower.	

Control card, digital inputs:	
Number of programmable digital inputs	
Terminal nos.	16, 17, 18, 19, 27, 29, 32, 33
Voltage level	
Voltage level, logical '0'	
Voltage level, logical 11	> 10 V DC
Maximum voltage on input	
Input resistance, R _i	approx. 2 kΩ
Scanning time per input	
Reliable galvanic isolation: All digital inputs are galvanically iso	
the digital inputs can be isolated from the other terminals on the	he control card by connecting an external 24 V
DC supply and opening switch 4. See drawing on page 45.	



General technical data

Control card, analogue inputs:	
No. of programmable analogue voltage inputs/thermistor inputs	
Terminal nos	
Voltage level,	0 - ±10 V DC (scalable)
Input resistance, R _i	approx. 10 kΩ
No. of programmable analogue current inputs	
Terminal no.	
Current range	
Input resistance, R	
Resolution	
Accuracy on input	
Scanning time per input	
Terminal no. ground	
Reliable galvariic isolation: All analogue inputs are galvanically isolated as other inputs and outputs.	from the supply voltage (PELV) as well

Control card, pulse/encoder input:

No. of programmable pulse/encoder inputs	
Terminal nos	17, 29, 32, 33
Max. frequency on terminal 17	
Max. frequency on terminals 29, 32, 33	20 kHz (PNP open collector)
Max. frequency on terminals 29, 32, 33	65 kHz (Push-puil)
Voltage level	
Voltage level, logical '0'	
Voltage level, logical '1'	
Maximum voltage on input	
Input resistance, R _i	approx. 2 kΩ
Scanning time per input	
Resolution	
Accuracy (100-1 kHz), terminals 17, 29, 33	
Accuracy (1-5 kHz), terminal 17	
Accuracy (1-65 kHz), terminals 29, 33	Max. error: 0.1% of full scale
Reliable galvanic isolation: All pulse/encoder inputs are galvanically is addition, pulse and encoder inputs can be isolated from the other term an external 24 V DC supply and opening switch 4. See drawing on	minals on the control card by connecting

Control card, digital/pulse and analogue outputs:	
No. of programmable digital and analogue outputs	
Terminal nos.	
Voltage level at digital/pulse output	0 - 24 V DC
Minimum load to ground (terminal 39) at digital/pulse output	
Frequency ranges (digital output used as pulse output)	0-32 kHz
Current range at analogue output	0/4 - 20 mA
Maximum load to ground (terminal 39) at analogue output	
Accuracy of analogue output	Max. error: 1.5% of full scale
Resolution on analogue output	
Reliable galvanic isolation: All digital and analogue outputs are galvanic (PELV) as well as other inputs and outputs.	ally isolated from the supply voltage



×...

General technical data

Control card, 24 V DC supply:	
Terminal nos.	
Max. load (short-circuit protection)	200 mA
Terminal nos. ground	
Reliable galvanic isolation: The 24 V DC supply is galvanically isolated from the su	upply voltage (PELV), but has
the same potential as the analogue outputs.	

Control card, RS 485 serial communication:

Terminal nos	-)
Reliable galvanic isolation: Full galvanic isolation.	

Relay outputs:

No. of programmable relay outputs	
Terminal nos., control card	4-5 (make)
Max. terminal load (AC) on 4-5, control card	50 V AC, 1 A, 60 VA
Max. terminal load (DC) on 4-5, control card	75 V DC, 1 A, 30 W
Max. terminal load (DC) on 4-5, control card for UL/cUL applications	30 V AC, 1 A / 42.5 V DC, 1A
Terminal nos., power card	1-3 (break), 1-2 (make)
Max. terminal load (AC) on 1-3, 1-2, power card and relay card	
Max. terminal load on 1-3, 1-2, power card and relay card	50 V DC, 2 A
Min. terminal load on 1-3, 1-2, power card and relay card24	4 V DC 10 mA, 24 V AC 100 mA

Brake resistor terminals (only SB and EB units):

Terminal nos	, 82

External 24 Volt DC supply:

Terminal nos.	
Voltage range	
Max. voltage ripple	
Power consumption	
Min. pre-fuse	6 Amp
Reliable galvanic isolation: Full galvanic isolation if the external	24 V DC supply is also of the PELV type.

Cable lengths and cross-sections:	
Max. motor cable length, screened cable	150 m
Max. motor cable length, unscreened cable	300 m
Max. motor cable length, screened cable VLT 5011 380-500 V	100 m
Max. brake cable length, screened cable	20 m
Max. loadsharing cable length, screened cable 25 m from frequency converter to DC bar.	
Max. cable cross-section for motor, brake and loadsharing, see next section	
Max. cable cross-section for 24 V external DC supply	4.0 mm ² /10 AWG
Max. cross-section for control cables	. 1.5 mm²/16 AWG
Max. cross-section for serial communication	. 1.5 mm²/16 AWG

Accuracy of display readout (parameters 009-012):

Motor current [6] 0-140% load	Max. error: ±2.0% of rated output current
Torque % [7], -100 - 140% load	
Output [8], power HP [9], 0-90% load	



General technical data

Frequency range	
	±0.003 H
System response time	
	1:100 of synchro. spee
Speed, control range (closed loop)	1:1000 of synchro. spee
	< 1500 rpm: max. error ± 7.5 rpr
	> 1500 rpm: max. error of 0.5% of actual spee
Speed, accuracy (closed loop)	< 1500 rpm: max. error ± 1.5 rpr
	> 1500 rpm: max. error of 0.1% of actual spee
Torque control accuracy (open loop)	0- 150 rpm: max. error ±20% of rated torqu
	150-1500 rpm: max. error ±10% of rated torgu
	> 1500 rpm: max. error ±20% of rated torgu
Torque control accuracy (speed feedback)	Max. error ±5% of rated torqu

l characteristics are based on a 4-pole asynchi

Externals:

Enclosure	
Vibration test 0.7 g RMS 18-1	000 Hz random. 3 directions for 2 hours (IEC 68-2-34/35/36)
Max. relative humidity	95 % non condensing (IEC 721-3-3; class 3K3) for operation
Ambient temperature IP 20 (high overload torque	e 160%) Max. 45°C (24-hour average max. 40°C)
Ambient temperature IP 20 (normal overload tor	que 110%) Max. 40°C (24-hour average max. 35°C)
Ambient temperature IP 54 (high overload torque	e 160%) Max. 40°C (24-hour average max. 35°C)
Ambient temperature IP 54 (normal overload tor	que 110%) Max. 40°C (24-hour average max. 35°C)
Ambient temperature IP 20/54 VLT 5011 500 V.	Max. 40°C (24-hour average max. 35°C)
Derating for high ambient temperature, see pag	e 96 of the Design Guide
Min. ambient temperature in full operation	
Min. ambient temperature at reduced performance	се
	-25 - +65/70°C
Max. altitude above sea level	
Derating for high altitude, see page 96 of the D	esign Guide
EMC standards applied, Emission	EN 50081-1/2, EN 61800-3, EN 55011, EN 55014
Immunity	EN 50082-2, EN 61000-4-2, IEC 1000-4-3, EN 61000-4-4
	EN 61000-4-5, ENV 50140, ENV 50141, VDE 0160/1990.12
Can another an encoded conditions in the Design (

See section on special conditions in the Design Guide

VLT 5000 Series protection:

- Electronic motor thermal protection against overload. .
- Temperature monitoring of heat-sink ensures that the VLT frequency converter cuts out if the temperature reaches 90°C for IP 00 and IP 20. For IP 54, the cut-out temperature is 80°C. An overtemperature can only be reset when the temperature of the heat-sink has fallen below 60°C.
- The VLT frequency converter is protected against short-circuiting on motor terminals U, V, W. .
- The VLT frequency converter is protected against earth fault on motor terminals U, V, W.
- Monitoring of the intermediate circuit voltage ensures that the VLT frequency converter cuts out if the intermediate circuit voltage gets too high or too low.
- If a motor phase is missing, the VLT frequency converter cuts out, see parameter 234 Motor phase ٠ monitor.
- If there is a mains fault, the VLT frequency converter is able to carry out a controlled deramping.
- If a mains phase is missing, the VLT frequency converter will cut out when a load is placed on the motor.



VLT^{*} 5000 Series

Mains supply 3 x 200 - 240 V According to international requirements

dillo oceperi	<u> </u>							
	rnational requirements	VLT type	5001	5002	5003	5004	5005	5006
		· · · · · · · · · · · · · · · · · · ·						
-	Output current	IVLT,N [A]	3.7	5.4	7.8	10.6	12.5	15.2
	I I	IVLT. MAX (60 S) [A]	5.9	8.6	12.5	17	20	24.3
Ĵ	Output (240 V)	SVLT.N [KVA]	1.5	2.2	3.2	4.4	5.2	6.3
	Typical shaft output	P _{VLTN} [kW]	0.75	1.1	1.5	2.2	3.0	3.7
	Typical shaft output	P _{VLT.N} (HP)	1	1.5	2	3	4	5
	Max. cable cross-secti	on to motor,						
	brake and loadsharing	[mm²]/[AWG] ²)	4/10	4/10	4/10	4/10	4/10	4/10
P								
J			•					
	Rated input current	(200 V) I _{L,N} [A]	3.4	4.8	7.1	9.5	11.5	14.5
	Max. cable							
	cross-section power	(mm²)/[AWG] ²)	4/10	4/10	4/10	4/10	4/10	4/10
	Max. pre-fuses	[-]/UL	16/10	16/10	16/15	25/20	25/25	35/30
480	Efficiency 3)		0.95					
	Weight IP 20 EB	[kg]	7	7	7	9	9	9,5
	Power loss at							
	max. load. [W]	Total	58	76	95	126	172	194
A	Enclosure	VLT type IP 20	-					

Mains supply 3 x 380 - 500 V

ccording to in	ternational require	ments	VLT type	5001	5002	5003	5004	5005	5006	5008	5011
	Output current	١	_{LT.N} [A] (380-440 V)	2.2	2.8	4.1	5.6	7.2	10	13	16
	·	IVLT. MAX (60	s) [A] (380-440 V)	3.5	4.5	6.5	9	11.5	16	20.8	25.6
			_{LT.N} [A] (441-500 V)	1.9	2.6	3.4	4.8	6.3	8.2	11	14,5
			s) [A] (441-500 V)	3	4.2	5.5	7.7	10.1	13.1	17.6	23.2
0	Output		(kVA) (380-440 V)	1.7	2.1	3.1	4.3	5.5	7.6	9.9	12.2
╘╮╔═╷	•		[kVA] (441-500 V)	1.6	2.3	2.9	4.2	5.5	7.1	9.5	12.6
┍╸╔╸	Typical shaft ou	itput	P _{VLTN} [kW]	0.75	1.1	1.5	2.2	3.0	4.0	5.5	7.5
2	Typical shaft ou	tput	P _{VLTN} [HP]	1	1.5	2	3	4	5	7.5	10
9	Max. cable cros	ss-section									
	brake and load	sharing	[mm²]/[AWG] ²⁾	4/10	4/10	4/10	4/10	4/10	4/10	4/10	4/10



I _{L,N} [A] (380 V)	2.3	2.6	3.8	5.3	7	9.1	12.2	15.0
I _{LN} [A] (460 V)	1.9	2.5	3.4	4.8	6	8.3	10.6	14.0
[mm²]/[AWG] ^{2]}	4/10	4/10	4/10	4/10	4/10	4/10	4/10	4/10
[-]/UL ¹⁾ [A]	16/6	16/6	16/10	16/10	16/15	25/20	25/25	35/30
	0.96							
[kg]	7	7	7	7.5	7.5	9.5	9.5	9.5
Total	55	67	92	110	139	198	250	295
VLT type	IP 20							
	I_N [A] (460 V) [mm²]/[AWG]² [-]/UL ¹⁾ [A] [kg] Total	I_N [A] (460 V) 1.9 [mm²]/[AWG]²I 4/10 [-]/UL ¹³ [A] 16/6 0.96 [kg] 7 Total 55	I_N [A] (460 V) 1.9 2.5 [mm ²]/[AWG] ²] 4/10 4/10 [-]/UL ¹) [A] 16/6 16/6 0.96 [kg] 7 7 Total 55 67	$[mm^{2}]/[AWG]^{21} $	I_N [A] (460 V) 1.9 2.5 3.4 4.8 [mm ²]/[AWG] ² 4/10 4/10 4/10 4/10 [-]/UL ¹] [A]16/6 16/6 16/10 16/10 0.96 [kg] 7 7 7 7 7.5 Total 55 67 92 110	I_N[A] (460 V) 1.9 2.5 3.4 4.8 6 [mm ²]/[AWG] ²¹ 4/10 4/10 4/10 4/10 4/10 [-]/UL ¹¹ [A] 16/6 16/6 16/10 16/10 16/15 0.96 [kg] 7 7 7 7.5 7.5 Total 55 67 92 110 139	I_N [A] (460 V) 1.9 2.5 3.4 4.8 6 8.3 [mm ²]/[AWG] ²] 4/10 4/10 4/10 4/10 4/10 4/10 [-]/UL ¹] [A] 16/6 16/6 16/10 16/10 16/15 25/20 0.96 [kg] 7 7 7 7 7.5 7.5 9.5 Total 55 67 92 110 139 198	_I_LN [A] (460 V) 1.9 2.5 3.4 4.8 6 8.3 10.6 [mm²]/[AWG]²) 4/10 4/10 4/10 4/10 4/10 4/10 4/10 [-]/UL ¹ [A] 16/6 16/6 16/10 16/10 16/15 25/20 25/25 0.96

If UL/cUL is to be complied with, pre-fuses type Bussmann KTN-R 200 V, KTS-R 500 V or similar must be used. Pre-fuses type gG must be used for VLT 5001 - VLT 5027, 200/240 V and VLT 5001 - VLT 5052, 380/500 V. Pre-fuses type gR must be used for VLT 5032 - 5052, 200/240 V and VLT 5060 - VLT 5500, 380/500 V. Fuses must be designed for protection in a circuit capable of supplying a maximum of 100,000 Amps ms (symmetrical), 500 V maximum.

- 2. American Wire Gauge.
- 3. Measured using 30 m screened motor cables at rated load and rated frequency.

-



Mains supply 3 x 200 - 240 V

j,

<u>Mains supp</u>	<u>iy 3 x 200 - 240 v</u>		_						
According to in	ternational requirements	S VLT type		5001	5002	5003	5004	5005	5006
_	High overload torque	(160 %):	-		•				
<u> </u>	Output current	I _{VLT,N} [A]		3.7	5.4	7.8	10.6	12.5	15.2
		I _{VLT, MAX} (60 s) [A]		5.9	8.6	12.5	17	20	24.3
	Output (240 V)	S _{VLT,N} [kVA]		1.5	2.2	3.2	4.4	5.2	6.3
	Typical shaft output	P _{VLT.N} [kW]		0.75	1.1	1.5	2.2	3.0	3.7
	Typical shaft output	P _{VLT,N} [HP]		1	1.5	2	3	4	5
	Max. cable cross-sec			4/10	4/10	4/10	4/10	4/10	4110
	brake and loadsharing	y [mm-]/[AwG]~		4/10	4/10	4/10	4/10	4/10	4/10
 6	Rated input current	(200 V) ILN [A]		3.4	4.8	7.1	9.5	11.5	14.5
	Max. cable cross-sec					·			
	power	[mm²]/[AWG]²)		4/10	4/10	4/10	4/10	4/10	4/10
1884) 1994	Max. pre-fuses	[-]/UL '' [A]		16/10	16/10	16/15	25/20	25/25	35/30
0000 S	Efficiency 3)	~		0.95					-
	Weight IP 20 EB	[kg]		8	8	8	10	10	10
	Weight IP 54	[kg]		11.5	11.5	11.5	13.5	13.5	13.5
	Power loss at	Tatal		50	30	05	100		404
	max. load. [W]	Total		58 IP 20.	76	95	126	172	194
	Enclosure			IP 20.	/IP 54		·		
Mains sunn	ly 3 x 200 - 240 V								
	ternational requirements	VLT type		5008	5011	5016	5022	5027	
<u> </u>	Normal overload torg	A4							
	Output current	IVLT.N [A]		32	46	61.2	73	88	
	output outlond	IVLT, MAX (60 S) [A]		35.2	50.6	67.3	80.3	96.8	
	Output (240 V)	SVLTN (KVA)		13.3	19.1	25.4	30.3	36.6	
	Typical shaft output	P _{VLT.N} [kW]		7.5	11	15	18.5	22	
	Typical shaft output	P _{VLT.N} [HP]		10	15	20	25	30	······
	High overload torque	(160 %):							
	Output current	Ivlt.n [A]		25	32	46	61,2	73	
		I _{vlt, max} (60 s) [A]		40	51.2	73.6	97.9	116.8	
	Output (240 V)	S _{VLT,N} [kVA]		10	13	19	25	30	
	Typical shaft output	P _{VLT,N} [kW]		5.5	7.5	11	15	18.5	
	Typical shaft output	P _{VLIN} [HP]		7,5	10	15	20	25	
	Max. cable cross-sec		IP 54	16/6	16/6	35/2	35/2	50/0	
	brake and loadsharing		IP 20	16/6	35/2	35/2	35/2	50/0	
	Min. cable cross-sec			10/0	10/0	10/0	10/0	10/0	
	brake and loadsharir	ng */[mm²/AWG]*/		10/8	10/8	10/8	10/8	16/6	
a	Rated input current (2			32	46	61	73	88	
	Max. cable cross-sect		IP 54	16/6	16/6	35/2	35/2	50/0	
	power	[mm²]/[AWG] ²⁾	IP 20	16/6	35/2	35/2	35/2	50/0	
	Max. pre-fuses	[-]/UL ^[1] [A]		50	60	80	125	125	
	Pre-fuse SMPS	[-]/UE ⁺⁺ [A]		4.0/4.0					
	Efficiency 3)			0.95					
	Weight IP 00	[kg]							
	Weight IP 20 EB	[kg]		23	23	30	30	48	
	Weight IP 54	[kg]		35	38	49	50	55	
	Power loss at max. lo								
	 high overload torque 			340	426	626	833	994	
				426					
	- normal overload torg	ue (110 %) [W]			545	783	1042	1243	
	Enclosure			IP 20+N	ema t kit	, IP 54/NE	MA 12	<u> </u>	

1. If UL/cUL is to be complied with, pre-fuses type Bussmann KTN-R or similar must be used. Pre-fuses type gG must be used for VLT 5001 - VLT 5027, 200/240 V and VLT 5001 - VLT 5052, 380/500 V. Pre-fuses type gR must be used for VLT 5032 - 5052, 200/240 V and VLT 5500, 380/500 V. Fuses must be designed for protection in a circuit capable of supplying a maximum of 100,000 Amps ms (symmetrical), 500 V maximum.

2. American Wire Gauge.

3. Measured using 30 m screened motor cables at rated load and rated frequency.

Min. cable cross-section is the smallest cable cross-section allowed to be fitted on the terminals. Always comply with national and local regulations on min. cable cross-section. 4.



ccording to i	nternational requirements	S VLT type	5001	5002	5003	5004	5005	5006	5008	5011
	High overload torque	(160 %):								
	Output current IvL1	(N [A] (380-440 V)	2.2	2.8	4.1	5.6	7.2	10	13	16
-4	IVLT, MAX (60	s) [A] <u>(380-440 V)</u>	3.5	4.5	6.5	9	11.5	16	20.8	25.6
		_N [A] (441-500 V)	1.9	2.6	3.4	4.8	6.3	8.2	11	14.5
	I _{VLT, MAX} (60 :	s) [A] (441-500 V)	3	4.2	5.5	7.7	10.1	13.1	17.6	23.2
	Output <u>Svitin</u>	(kVA) (380-440 V)	1,7	2.1	3.1	4.3	5.5	7.6	9.9	12.2
	S _{VLT.N}	kVA] (441-500 V)	1.6	2.3	2.9	4.2	5.5	7.1	9.5	12.6
	Typical shaft output	P _{VLT.N} [kW]	0.75	1.1	1.5	2.2	3.0	4.0	5.5	7.5
_	Typical shaft output	P _{VLT.N} (HP)	1	1.5	2	3	4	5	7.5	10
	Max. cable cross-sec	tion to motor,								
	brake and loadsharing] [mm²]/[AWG]²]	4/10	4/10	4/10	4/10	4/10	4/10	4/10	4/10
88	Rated input current	I _{LN} [A] (380 V)	2.3	2.6	3.8	5.3	7	9.1	12.2	15.0
		I _{LN} [A] (460 V)	1,9	2.5	3.4	4.8	6	8.3	10.6	14.0
	Max. cable cross-sect	tion,	4/10	4/10	4/10	4/10	4/10	4/10	4/10	4/10
	power	[mm²]/[AWG] ^z)								
0000	Max. pre-fuses	[-]/UL ¹⁾ [A]	16/6	16/6	16/10	16/10	16/15	25/20	25/25	35/30
	Efficiency 3)		0.96							
	Weight IP 20 EB	[kg]	· 8	8	8	8.5	8.5	10.5	10.5	10.5
	Weight IP 54	[kg]	11.5	11.5	11.5	12	12	14	14	14
kd	Power loss at									
	load [W]	Total	55	67	92	110	139	198	250	295
	Enclosure		IP 2	20/IP 54						

 If UL/cUL is to be complied with, pre-fuses type Bussmann KTS-R or similar must be used. Pre-fuses type gG must be used for VLT 5001 - 5027, 200/240 V and VLT 5001 - 5052, 380/500 V. Pre-fuses type gR must be used for VLT 5032 - 5052, 200/240 V and VLT 5060 - 5500, 380/500 V. Fuses must be designed for protection in a circuit capable of supplying a maximum of 100,000 Amps ms (symmetrical), 500 V maximum.

2. American Wire Gauge.

Mains supply 3 x 380 - 500 V

3. Measured using 30 m screened motor cables at rated load and rated frequency.



Mains supply 3 x 380 - 500 V According to international requirement

-

<u>193 x 360 - 500</u>	/ V								
ernational requirem	ents	VLT type		5016	5022	5027	5032	5042	5052
Normal overload t	torque (1	110 %):						_	
Output current	I _{VLT.N} [A	(380-440 V)		32	37.5	44	61	73	90
VLT, MAX	(60 s) (A) (380-440 V)		35.2	41.3	48.4	67.1	80.3	99
	IVLEN (A	(441-500 V)		27.9	34	41.4	54	65	78
VLT, MAX	(60 s) [A] (441-500 V)		30.7	_37.4	45.5	59.4	71 <u>.5</u>	85.8
Output S	_{VLTN} [kVA] (380-440 V)		24.4	28.6	33.5	46.5	55.6	68.6
S	_{VLT.N} [kVA	(441-500 V)		24.2	29.4	35.8	<u>46.8</u>	56.3	67.5
Typical shaft outp	ut	Pvlt,n [kW]		15	18.5	22	30	37	45
Tusiani ala fi autori	117	PVILN (HP)		20	25	30	40	50	60
Typical shaft outp	que (160) %):	–	24	22	27.5			
High overload tore	<u>que (16(</u> І _{унт.»} (А) %): \] (380-440 V)_		24	32	37.5	44	61	73
High overload tore	que (160 _{Турты} (А (60 s) (А) %): \] (380-440 V) .] (380-440 V)		24 38.4	51.2	60	44 70.7	97.6	73 116.8
High overload tord Output current	que (16(І _{УГЛМ} (А (60 s) (А І _{УГЛМ} (А) %): \] (380-440 V) .] (380-440 V) \] (441-500 V)		38.4 21.7	51.2 27.9	60 34	70.7 41.4	97.6 54	116.8 65
High overload tord Output current 	<u>que (160</u> _{УСТ.М} [А (60 s) [А _{УСТ.М} [А (60 s) (А) %): \] (380-440 V) .] (380-440 V) .] (441-500 V) .] (441-500 V)		38.4 21.7 34.7	51.2 27.9 44.6	60 34 54.4	70.7 41.4 66.2	97.6 54 86	116.8 65 104
High overload tord Output current 	<u>que (16(</u> _{VLT.N} [A (60 s) [A _{VLT.N} [A (60 s) [A _{VLT.N} [KVA) %): ((380-440 V) (380-440 V) (441-500 V) (441-500 V) (380-440 V)		38.4 21.7 34.7 18.3	51.2 27.9 44.6 24.4	60 34 54.4 28.6	70.7 41.4 66.2 33.5	97.6 54 86 46.5	116.8 65 104 55.6
High overload tord Output current 	<u>que (16(</u> _{VLT.N} [A (60 s) [A _{VLT.N} [A (60 s) [A _{VLT.N} [KVA) %): (380-440 V) (380-440 V) (441-500 V) (441-500 V) (380-440 V) (441-500 V)		38.4 21.7 34.7 18.3 18.8	51.2 27.9 44.6 24.4 24.2	60 34 54.4 28.6 29.4	70.7 41.4 66.2 33.5 35.9	97.6 54 86 46.5 46.8	116.8 65 104 55.6 56.3
High overload tord Output current 	<u>que (16(</u> <u> _{VLT.N} [A</u> (60 s) [A <u> _{VLT.N} [A</u> (60 s) [A <u>VLT.N [KVA</u> <u>VLT.N [KVA</u>) %): ((380-440 V) (380-440 V) (441-500 V) (441-500 V) (380-440 V)		38.4 21.7 34.7 18.3	51.2 27.9 44.6 24.4 24.2 15	60 34 54.4 28.6	70.7 41.4 66.2 33.5 35.9 22	97.6 54 86 46.5	116.8 65 104 55.6
High overload tord Output current 	que (160 _{VLT.N} [A (60 s) [A (60 s) [A (60 s) [A (60 s) [A VLT.N [KVA VLT.N [KVA Ut) %): (380-440 V) (380-440 V) (441-500 V) (441-500 V) (380-440 V) (441-500 V)		38.4 21.7 34.7 18.3 18.8	51.2 27.9 44.6 24.4 24.2	60 34 54.4 28.6 29.4	70.7 41.4 66.2 33.5 35.9	97.6 54 86 46.5 46.8	116.8 65 104 55.6 56.3
High overload tord Output current	<u>gue (160</u> _{VLTN} [A _{VLTN} [A _{VLTN} [A (60 s) (A (60 s) (A VLTN [kVA VLTN [kVA Ut Ut) %): (380-440 V) (380-440 V) (441-500 V) (441-500 V) (441-500 V) (441-500 V) P _{VLTN} [kW] P _{VLTN} [HP]	IP 54	38.4 21.7 34.7 18.3 18.8 11	51.2 27.9 44.6 24.4 24.2 15	60 34 54.4 28.6 29.4 18.5	70.7 41.4 66.2 33.5 35.9 22	97.6 54 86 46.5 46.8 30	116.8 65 104 55.6 56.3 37
High overload tord Output current	gue (160 I _{VLTM} (A (60 s) (A I _{VLTM} (A (60 s) (A (60 s) (A VLTM (kVA VLTM (kVA Ut ut section) %): (380-440 V) (380-440 V) (441-500 V) (441-500 V) (441-500 V) (441-500 V) P _{VLTN} [kW] P _{VLTN} [HP] to motor,		38.4 21.7 34.7 18.3 18.8 11 15	51.2 27.9 44.6 24.4 24.2 15 20	60 34 54.4 28.6 29.4 18.5 25	70.7 41.4 66.2 33.5 35.9 22 30	97.6 54 86 46.5 46.8 30 40	116.8 65 104 55.6 56.3 37 50
High overload tord Output current	gue (160 I _{VLTN} [A (60 s) [A I _{VLTN} [A (60 s) [A (60 s) [A (60 s) [A (60 s) [A (10 s) [A (10 section aring [r) %): (380-440 V) (380-440 V) (441-500 V) (441-500 V) (441-500 V) (441-500 V) P _{VLTN} [kW] P _{VLTN} [HP] to motor, nm2]/[AWG] ²		38.4 21.7 34.7 18.3 18.8 11 15 16/6	51.2 27.9 44.6 24.4 24.2 15 20 16/6	60 34 54.4 28.6 29.4 18.5 25 16/6	70.7 41.4 66.2 33.5 35.9 22 30 35/2	97.6 54 86 46.5 46.8 30 40 35/2	116.8 65 104 55.6 56.3 37 50 50/0

Rated input current	I _{L,N} [A] (380 V)		32	37.5	44	60	72	89
·····	I _{L.N} (A) (460 V)		27.6	34	41	53	64	77
Max. cable cross-secti	on,	IP 54	16/6	16/6	16/6	35/2	35/2	50/0
power	[mm²]/[AWG]	IP 20	16/6	16/6	35/2	35/2	35/2	50/0
Max. pre-fuses	[-]/UL ⁺⁺ [A]		63/40	63/50	63/60	80/80	100/100	125/125
Pre-fuse SMPS	[-]/UL ¹⁾ [A]		4.0/4.0)				
Efficiency			0.96	-				
Weight IP 20 EB	[kg]		23	23	30	30	48	48
Weight IP 54	[kg]		48	48	51	61	67	70
Power loss at max. loa	id.							
- high overload torque	(160 %) [W]		419	559	655	768	1065	1275
- normal overload torg	ue (110 %) [W]		559	655	768	1065	1275	1571
Enclosure			IP 20/I	P 54				

- If UL/cUL is to be complied with, pre-fuses type Bussmann KTS-R or similar must be used. Pre-fuses type gG must be used for VLT 5001 - 5027, 200/240 V and VLT 5001 - 5052, 380/500 V. Pre-fuses type gR must be used for VLT 5032 - 5052, 200/240 V and VLT 5060 - 5500, 380/500 V. Fuses must be designed for protection in a circuit capable of supplying a maximum of 100,000 Amps ms (symmetrical), 500 V maximum.
- 2. American Wire Gauge.
- 3. Measured using 30 \bar{m} screened motor cables at rated load and rated frequency.
- 4. Min, cable cross-section is the smallest cable cross-section allowed to be fitted on the terminals. Always comply with national and local regulations on min. cable cross-section.



y 3 x 200 - 240 V ernational requirements VLT type	5032	5042	5052
Normal overload torque (110 %):			
Output current IvLIN (A) (200-230 V)	115	143	170
I _{VLT, MAX} (60 s) [A] (200-230 V)	127	158	187
IVLIN [A] (231-240 V)	104	130	154
IVLT. MAX (60 s) [A] (231-240 V)	115	143	170
Output SvLTN [kVA] (200-230 V)	41	52	61
Svitn [kVA] (231-240 V)	41	52	61
Typical shaft output (200-240 V) PvLTN [kW]	30	37	45
Typical shaft output (200-240 V) PvLTN [HP]	40	50	60
High overload torque (150 %):			
Output current I _{VLTN} [A] (200-230 V)	88	115	143
lvLT.max (60 s) [A] (200-230 V)	132	173	215
IVLT. (3) (231-240 V)	80	104	130
	120	156	195
Ivit_Max (60 s) [A] (231-240 V) Output Svit_N [kVA] (200-230 V)	32	41	52
Output <u>SvitN [kVA] (200-230 V)</u> SvitN [kVA] (231-240 V)	32	41	52
	22	30	37
Typical shaft output (200-240 V) P _{VLTN} [kW]	30	<u> </u>	50
Typical shaft output (200-240 V)Pvtt [HP]	30		50
Max. cross-section of copper cable to motor, brake	70	90	120
and loadsharing (200-240 V) [mm ²] ^{5]}		90	120
Max. cross-section of aluminium cable to motor, brake	05		120
and loadsharing (200-240 V) [mm ²] ⁵⁾	95	95	120
Max. cross-section of copper cable to motor, brake	. (0	2/2	4/0
and loadsharing (200-240 V) [AWG] ^{2) 5)}	1/0	3/0	4/0
Max. cross-section of aluminium cable to motor, brake			
and loadsharing (200-240 V) [AWG] ^{2) 5)}	3/0	250mcm	300mcm
Min. cable cross-section to motor,			
brake and loadsharing 4) [mm ^{2/} AWG] ²¹⁵⁾	10/8	10/8	10/8
 Rated input current ILN[A] (230 V)	101.3	126.6	149.9
Max. cross-section of copper cable		120.0	
to power (200-240 V) [mm ²] ⁹	70	90	120
Max. cross-section of aluminium cable		50	120
	95	95	120
			120
Max. cross-section of copper cable to power (200-240 V) [AWG] ^{2) 5)}	1/0	3/0	4/0
	1/0	3/0	4/0
Max. cross-section of aluminium cable	2/0	250mom	200mam
to power (200-240 V) [AWG] ^{2) 5)}	3/0	250mcm	300mcm
Min. cable cross-section to motor,	10/0	40/0	40.0
brake and loadsharing 4) [mm ² /AWG] ²¹⁵	10/8	10/8	10/8
Max. pre-fuses (mains) [-]/UL ¹¹ [A]	150	200	250
 Integral pre-fuses			
(softcharge circuit) [-]/UL 1) [A]	15/15	15/15	15/15
Integral pre-fuses			
(softcharge resistors) [-]/UL 1)[A]	12/12	12/12	12/12
Integral pre-fuses (SMPS) [-]/UL 11[A]	12/12		
Efficiency 3	0.96-0.9		
Weight IP 00 [kg]	90	90	90
Weight IP 20 EB [kg]	101	101	101
Weight IP 54 [kg]	104	104	104
Power loss at max. load [W]	1089	1361	1613
		20/ IP 54	

1. If UL/cUL is to be complied with, pre-fuses type Bussmann FWH and FWX or similar must be used. Pre-fuses type gG must be used for VLT 5001 - 5027, 200/240 V and VLT 5001 - 5052, 380/500 V. Pre-fuses type gR must be used for VLT 5032 - 5052, 200/240 V and VLT 5060 - 5500, 380/500 V. Fuses must be designed for protection in a circuit capable of supplying a maximum of 100,000 Amps ms (symmetrical), 500 V maximum. American Wire Gauge.

2.

3.

Measured using 30 m screened motor cables at rated load and rated frequency. Min. cable cross-section is the smallest cable cross-section allowed to be fitted on the terminals. Always comply with national and local regulations on min. cable cross-section. 4.

Connection stud 1 x M8/2 x M8. 5.



y 3 x 380-500 V VLT type ernational requirements	<u>5060</u>) <u> </u>	5100	5125	5150	<u> 52</u> 00	5250
 Normal overload torque (110 %):							
Output current IvLT,N [A] (380-440 V)	106	147	177	212	260	315	368
		162	195	233	286	347	405
IVLI, MAX (88 5) [74] (885 416 4)		130	160	190	240	302	361
IVLT MAX (60 s) [A] (441-500 V)		143	176	209	264	332	397
Output Svit (kVA) (380-440 V)		143	123	147	180	218	255
SvLtw [kVA] (441-500 V)		113	123	165	208	262	313
Typical shaft output (380-440 V) PvLTN [kW		75	90	110	132	160	200
Typical shaft output (380-440 V) PVLTN [KW		100	125	150	200	250	300
		90	110	130	160		250
Typical shaft output (441-500 V) Pvtt N [kW		125	150	200	250	200	
Typical shaft output (441-500 V) Pvtt N (HP High overload torque (150 %):	<u>j 100</u>	125	150	200	250	300	350
Output current IVLTN [A] (380-440 V)	90.0	106	147	177	212	260	315
		159	221	266	318	390	473
I _{VLTN} [A] (441-500 V)			130	160	190	240	302
IVLT MAX (60 S) [A] (441-500 V)		159	195	240	285	360	453
Output S _{VLT.N} (kVA) (380-440 V)			102	123	147	180	218
S _{VILN} (kVA) (441-500 V)			113	139	165	208	262
Typical shaft output (380-440 V) PVLTN [kW]		55	75	90	110	132	160
Typical shaft output (380-440 V) PVLIN [HP		75	100	125	150	200	250
Typical shaft output (441-500 V) PvLT, N [kW		75	90	110	132	160	200
Typical shaft output (441-500 V) PVLT N [HP		100	125	150	200	250	300
Max. cross-section of copper cable to motor, brake and loadsharing (380-440 V) [mm ^{2]5)}	70	95	120	2x70	2x70	2x95	2x120
Max. cross-section of copper cable to motor, brake and loadsharing (441-500 V) [mm ²] ⁵⁾ Max. cross-section of	70	70	95	2x70	2x70	2x95	<u>2</u> x120
aluminium cable to motor, brake							
and loadsharing (380-440 V) [mm²]5	95	120	150	2x70	2x120	2x120	2x150
Max. cross-section of aluminium cable to motor, brake and loadsharing (441-500 V) [mm ²] ⁵	70	90	120	2x70	2x95	2x120	2x150
Max. cross-section of copper cable to motor, brake and loadsharing (380-440 V) [AWG] ^{2;5} Max. cross-section of	1/0	3/0	4/0	2x1/0	2x2/0	2x3/0	2x250mcm
copper cable to motor, brake and loadsharing (441-500 V) [AWG] ²¹⁵⁾ Max. cross-section of	1/0	2/0	3/0	2x1/0	2x1/0	2x3/0	2x4/0
aluminium cable to motor, brake and loadsharing (380-440 V) [AWG] ^{2 5)} Max. cross-section of	3/0	250mcm	300mcm	2x2/0	2x4/0	2x250mcm	2x350mcm
aluminium cable to motor, brake and loadsharing (441-500 V) [AWG] ^{2) 5]} Min. cable cross-section to motor,	3/0	4/0	250mcm	2x2/0	2x3/0	2x250mcm	2x300mcm
brake and loadsharing ⁴⁾ [mm ^{2/} AWG] ^{2/5)}	10/8	10/8	10/8	10/8	10/8	16/6	

 If UL/cUL is to be complied with, pre-fuses type Bussmann FWH and FWX or similar must be used. Pre-fuses type gG must be used for VLT 5001 - 5027, 200/240 V and VLT 5001 - 5052, 380/500 V. Pre-fuses type gR must be used for VLT 5032 - 5052, 200/240 V and VLT 5060 - 5500, 380/500 V. Fuses must be designed for protection in a circuit capable of supplying a maximum of 100,000 Amps ms (symmetrical), 500 V maximum.

2. American Wire Gauge.

3. Measured using 30 m screened motor cables at rated load and rated frequency.

4. Min. cable cross-section is the smallest cable cross-section allowed to be fitted on the terminals.

Always comply with national and local regulations on min. cable cross-section.

5. Connection stud 1 x M8/2 x M8.



Mains supply 3 x 380-500 V



	ernational requirements	VLT type	5060	5075	5100	5125	5150	5200	5250
According to title	emadonarrequirements	<u>, ici (jpu</u>			0.00		0.00	02.00	
	Rated input current	I _{L,N} [A] (400 V)	87.6	103	145	174	206	256	318
		I _{L,N} [A] (460 V)	77.9	103	128	158	185	236	304
	Max. cross-section of	<u></u> (N [2 ·] (100 ·)							
<u> </u>	copper cable								
	to power (380-440 V)	[mm²] ⁵⁾	70	95	120	2x70	2x70	2x95	2x120
	Max. cross-section of	·							
	copper cable								
0000	to power (441-500 V)	(mm²)\$)	70	70	95	2x70	2x70	2x95	2x120
	Max. cross-section of								
	aluminium cable								
	to power (380-440 V)	[mm²]5)	95	120	150	2x70	2x120	2x120	2x150
kA	Max. cross-section of								
	aluminium cable								
	to power (441-500 V)	[mm²] ^{sy}	70	90	120	2x70	2x95	2x120	2x150
	Max. cross-section of								
	copper cable								
	to power (380-440 V)	[AWG] ^{2) 5)}	1/0	3/0	4/0	2x1/0	2x2/0	2x3/0	2x250mcm
	Max. cross-section of								
	copper cable								
	to power (441-500 V)	[AWG] ^{2) 5)}	1/0	2/0	3/0	2x1/0	2x1/0	2x3/0	2x4/0
	Max. cross-section of								
	aluminium cable								
	to power (380-440 V)	[AWG] ^{2) 5)}	3/0	250mcm	300mcm	2x2/0	2x4/0	2x250mcm	2x350mcm
	Max. cross-section of								
	aluminium cable							•	
	to power (441-500 V)	[AWG] ^{2) 5)}	3/0	4/0	250mcm	2x2/0	2x3/0	2x250mcm	2x300mcm
	Min. cable cross-section to								
	brake and loadsharing 4)	[mm ^{2/} AWG] ²⁾⁵⁾	10/8	10/8	10/8	10/8	10/8	16/6	
	Max. pre-fuses (mains)	[-]/UL ''[A]	150/150	250/220	250/250	300/300	350/350	0 450/400	500/500
	Integral pre-fuses								
	(softcharge circuit)	[-]/UL 가[A]	15/15	15/15	15/15	30/30	30/30	30/30	30/30
	Integral pre-fuses								
	(softcharge resistors)	[-]/UL ¹⁾ [A]	12/12	12/12	12/12	12/12	12/12	12/12	12/12
	Integral pre-fuses (SMPS)	[-]/UL ¹⁾ [A]	5.0/5.0						
	Efficiency		0.96-0.9		100				
	Weight IP 00	(kg)	109	109	109	146	146	146	146
	Weight IP 20 EB	<u>[kg]</u>	121	121	121	161	161	161	161
	Weight IP 54	[kg]	124	124	124	177	177	177	177
	Power loss at max. load	[W]	1430	1970	2380	2860	3810	4770	5720
	Enclosure		IP 00 / IF	20/ IP 54					

1. If UL/cUL is to be complied with, pre-fuses type Bussmann FWH and FWX or similar must be used. Pre-fuses type gG must be used for VLT 5001 - 5027, 200/240 V and VLT 5001 - 5052, 380/500 V. Pre-fuses type gR must be used for VLT 5032 - 5052, 200/240 V and VLT 5060 - 5500, 380/500 V. Fuses must be designed for protection in a circuit capable of supplying a maximum of 100,000 Amps ms (symmetrical), 500 V maximum.

2. American Wire Gauge.

Min. cable cross-section is the smallest cable cross-section allowed to be fitted on the terminals. 4. Always comply with national and local regulations on min. cable cross-section.

5. Connection stud 1 x M8/2 x M8.

Measured using 30 m screened motor cables at rated load and rated frequency. 3.



Mains supply 3 x 380-500 V

international rec	uirements	VLT type	5300	5350	5 <u>45</u> 0	5500
Normal over	rload torque (11)	0 %):				
Output curre		(380-440 V)	480	600	658	745
output curre			528	660	724	820
		(441-500 V)	443	540	590	678
	IVLT, MAX (60 S) [A]		445	<u>540</u> 594		·
Output			333	·	649	746
Ουτροτ		(380-440 V)	<u> </u>	416	456	516
Tunical shaft	output (380-440	(441-500 V)	250	<u>468</u> 315	511	587
	output (380-440		300	350	355	400
			315		450	500
	output (441-500 output (441-500		350	<u>355</u> 450	<u>400</u> 500	500 600
	<u>. outpot (441-300</u>			450		600
	ad torque (150 %			<u> </u>		
Output curre		(380-440 V)	395	480	600	658
	IVIT, MAX (60 S) [A]		593	720	900	987
		(441-500 V)	361	443	540	590
_	I _{VLT, MAX} (60 s) [A]		542	665	810	885
Output	S _{vltn} [kVA]		274	333	416	456
	S _{VLT,N} [kVA]	~ ~ ~ ~	313	384	468	511
	output (380-440		200	250		355
	output (380-440		300	350	_450	500
	output (441-500		250	<u> 3</u> 15	355	400
Typical shaft	output (441-500	V) PVLT N [HP]	350	<u>4</u> 50	500	600
Max. cross-s						
	e to motor, brake		2 x 150	2 x 185	2 x 240	2 x 300
	ring (380-440 V)	[mm²]5)	3 x 70	3 x 95	3 x 120	<u>3 x 150</u>
Max. cross-s						
	e to motor, brake		2 x 120	2 x 150	2 x 185	2 x 300
	ring (441-500 V)	[mm ^{2]5)}	3 x 70	3 x 95	3 x 95	3 x 120
Max. cross-s						
	able to motor, bra		2 x 185	2 x 240	2 x 300	
	ring (380-440 V)	[mm²]5)	<u>3 x 120</u>	3 x 150	<u>3 x 185</u>	3 x 185
Max. cross-s						
	able to motor, bra		2 x 150	2 x 185	2 x 240	
	ring (441-500 V)	[mm²] ⁵⁾	<u>3 x 95</u>	<u>3 x 120</u>	3 x 150	3 x 185
Max. cross-s						
	to motor, brake			2 x 350mcm	2 x 400mcm	2 x 500mcm
	ring (380-440 V)	[AWG] ^{2 5}	3 x 2/0	3 x 3/0	3 x 4/0	<u>3 x 250mcm</u>
Max. cross-s	section of					
••	e to motor, brake		2 x 4/0		2 x 350mcm	2 x 500mcm
-	ring (441-500 V)	[AWG] ^{2) 5)}	3 1/0	3 x 3/0	3 x 3/0	3 x 4/0
Max. cross-s	section of					
aluminium ca	able to motor, bra	ke	2 x 350mcm	2 x 500mcm	2 x 600mcm	2 x 700mcm
and loadsha	ring (380-440 V)	[AWG] ^{2) 5)}	3 x 4/0	3 x 250mcm	3 x 300mcm	3 x 350mcm
Max. cross-s	section of					
aluminium ca	ible to motor, bra	ke	2 x 300mcm	2 x 400mcm	2 x 500mcm	2 x 600mcm
and loadaba	ring (441-500 V)	[AWG] ^{2) 5)}	3 x 3/0	3 x 4/0	3 x 250mcm	3 x 300mcm

- If UL/cUL is to be complied with, pre-fuses type Bussmann FWH and FWX or similar must be used. Pre-fuses type gG must be used for VLT 5001 - VLT 5027, 200/240 V and VLT 5001 - VLT 5052, 380/500 V. Pre-fuses type gR must be used for VLT 5032 - 5052, 200/240 V and VLT 5060 - VLT 5500, 380/500 V. Fuses must be designed for protection in a circuit capable of supplying a maximum of 100,000 Amps ms (symmetrical), 500 V maximum.
- 2. American Wire Gauge.
- 3. Measured using 30 m screened motor cables at rated load and rated frequency.
- Min. cable cross-section is the smallest cable cross-section allowed to be fitted on the terminals, Always comply with national and local regulations on min. cable cross-section.
- 5. Connection stud 2 x M12 / 3 x M12.



Mains supply 3 x 380-500 V



	ernational requirements	VLT type	5300	5350	5450	5500
	•					
	Rated input current	I _{L,MAX} [A] (400 V)	389	467	584	648
	······································	I _{L,MAX} [A] (460 V)	356	431	526	581
	Max. cross-section of					
<u>BB</u>	copper cable		2 x 150	2 x 185	2 x 240	2 x 300
	to power (380-440 V)	(mm²] ⁵⁾	<u>3 x 70</u>	3 x 95	3 x 120	_3 x 150
	Max. cross-section of					
	copper cable		2 x 120	2 x 150	2 x 185	2 x 300
	to power (460-500 V)	[mm²] ⁵⁾	3 x 70	3 x 95	3 x 95	3 x 120
	Max. cross-section of					
	aluminium cable		2 x 185	2 x 240	2 x 300	
<u>م</u> ما	to power (380-440 V)	[mm²]5)	3 x 120	3 x 150	3 x 185	3 x 185
	Max. cross-section of					
	aluminium cable		2 x 150	2 x 185	2 x 240	
	to power (460-500 V)	(mm²) ⁵⁾	<u>3 x 95</u>	3 x 120	3 x 150	<u>3 x 185</u>
	Max. cross-section of					
	copper cable		2 x 250mcm	2 x 350mcm	2 x 400mcm	2 x 500mcm
	to power (380-440 V)	[AWG] ^{2) 5)}	3 x 2/0	3 x 3/0	3 x 4/0	3 x 250mcm
	Max. cross-section of					
	copper cable-		2 x 4/0	2 x 300mcm	2 x 350mcm	2 x 500mcm
	to power (460-500 V)	[AWG] ^{2) 5)}	3 1/0	3 x 3/0	3 x 3/0	<u>3 x 4/0</u>
	Max. cross-section of					
	aluminium cable		2 x 350mcm	2 x 500mcm	2 x 600mcm	2 x 700mcm
	to power (380-440 V)	[AWG] ^{2 3}	3 x 4/0	3 x 250mcm	3 x 300mcm	3 x 350mcm
	Max. cross-section of					
	aluminium cable		2 x 300mcm	2 x 400mcm	2 x 500mcm	2 x 600mcm
	to power (460-500 V)	[AWG] ^{2) 5)}	3 x 3/0	3 x 4/0	3 x 250mcm	3 х 300 лст
	Max. pre-fuses (mains)	[-]/UL ¹⁾ [A]	630/600	700/700	800/800	800/800
	Integral pre-fuses					
	(softcharge circuit)	[-]/UL '')[A]	15/15	15/15	15/15	30/30
	Integral pre-fuses					
	(softcharge resistors)	[-]/UL_')[A]	12/12	12/12	12/12	12/12
	Integral pre-fuses (SMPS)	(-]/UL יי (A)	5.0/5.0			
	Efficiency		0.97			
	Weight IP 00	[kg]	480	515	560	585
	Weight IP 20	[kg]	595	630	675	700
	Weight IP 54	[kg]	_605	640	685	710
	Power loss at max. load	[W]	7500	9450	10650	12000
	Enclosure		IP 00 / IP 20/	IP 54		

1. If UL/CUL is to be complied with, pre-fuses type Bussmann FWH and FWX or similar must be used. Pre-fuses type gG must be used for VLT 5001 - VLT 5027, 200/240 V and VLT 5001 - VLT 5052, 380/500 V. Pre-fuses type gR must be used for VLT 5032 - 5052, 200/240 V and VLT 5060 - VLT 5500 , 380/500 V. Fuses must be designed for protection in a circuit capable of supplying a maximum of 100,000 Amps ms (symmetrical), 500 V maximum.

2. American Wire Gauge.

- Min. cable cross-section is the smallest cable cross-section allowed to be fitted on the terminals. 4. Always comply with national and local regulations on min. cable cross-section.
- 5. Connection stud 2 x M12 / 3 x M12.

^{3.} Measured using 30 m screened motor cables at rated load and rated frequency.



Bookstyle IP 20


IP 20 enclosur	e 200	-240 V					
VLT type	A (mm)	B (mm)	C (mm)	a (mm)	b (mm)	ab/be (m	m) I/r (mm)
5001 - 5003	395	90	260	384	70	100	0
5004 - 5006	395	130	260	384	70	100	0
					-		
IP 20 enclosur	e 380	-500 V		•			
VLT type	A (mm)	B (mm)	C (mm)	a (mm)	b (mm)	ab/be (mm)	l/r (mm)
5001 - 5005	395	90	260	384	70	100	0
5006 - 5011	395	130	260	384	70	100	0

ab:Min. space above enclosure.

be:Min. space below enclosure.

I/r: Min. distance between VLT frequency converter and other plant components, left and right sides.

VLT 5001 - 5006/200-240 V VLT 5001 - 5011/380-500 V






Compact IP 00


IP 00 enclos	ure	200-240 V					
VLT type	A (mm)	B (mm)	C (mm)	a (mm)	b (mm)	ab/be (mm)	l∕r (mm)
5032 - 5052	800	370	335	780	270	225	0
IP 00 enclos	ure	380-500 V		- · · ·			
VLT type	A (mm)	B (mm)	C (mm)	a (mm)	b (mm)	ab/be (mm)	1/r (mm)
VLT type 5060 - 5100	A (mm) 800	B (mm) 370	C (mm) 335	a (mm) 780	b (mm) 270	ab/be (mm) 225	1/r (mm) 0
5.	• •			, ,			

ab:Min. space above enclosure. be: Min. space below enclosure.

I/r: Min. distance between VLT frequency converter and other plant components, left and right sides.



VLT 5060 - 5250/380-500 V



VLT 5300 - 5500/380-500 V

IP 20 bottom	IP 20 bottom cover										
VLT type	A1 (mm)		C1 (mm)	-,							
5060 - 5100	175	370	335								
5125 - 5250	175	420	.400	.1							




■ Compact IP 20

IP 20 enclosure	200-240 \	1					
VLT type	A (mm)	B (mm)	C (mm)	a (mm)	b (mm)	ab/be (mm)	l/r (mm)
5001 - 5003	395	220	160	384	200	100	0
5004 - 5006	395	220	200	384	200	100	0
5008	560	242	260	540	200	200	0
5011 - 5016	700	242	260	680	200	200	0
5022 - 5027	800	308	296	780	270	200	0
5032 - 5052	954	370	335	780	270	225	0

/r (mm)
)
)
)
)
)
)
)
)

ab:Min. space above enclosure. be: Min. space below enclosure.

I/r: Min. distance between VLT frequency converter and other plant components, left and right sides.



DANFOSS 175ZA099.12

VLT 5001 - 5006/200-240 V


VLT 5001 - 5011/380-500 V


VLT 5008 - 5027/200-240 V


VLT 5016 - 5052/380-500 V


8

ь









Danfoss

Compact IP 54


IP 54 enclosure	200	-240 V			_			
VLT type	A (mm)	B (mm)	C (mm)	D (mm)	a (mm)	b (mm)	ab/be (mm)	1/r (mm)
5001 - 5003	460	282	195	85	260	258	100	0
5004 - 5006	530	282	195	85	330	258	100	0
5008 - 5011	810	355	280	70	560	330	200	0
5016 - 5027	940	400	280	70	690	375	200	0
5032 - 5052	937	495	421	-	830	374	225	50

IP 54 enclosure 380-500 V

VLT type	A (mm)	B (mm)	C (mm)	D (mm)	a (mm)	b (m m)	ab/be (mm)	l/r (mm)
5001 - 5005	460	282	195	85	260	258	100	0
5006 - 5011	530	282	195	85	330	258	100	0
5016 - 5027	810	355	280	70	560	330	200	0
5032 - 5052	940	400	280	70	690	375	200	0
5060 - 5100	937	495	421	-	830	374	225	50
5125 - 5250	1572	495	425	-	1465	445	225	0
5300 - 5500	2010	1200	600	-		-	400	0

ab:Min. space above enclosure. be: Min. space below enclosure.

I/r: Min. distance between VLT frequency converter and other plant components, left and right sides.



MG.50.A9.02 - VLT is a registered Danfoss trademark



Mechanical installation

Please pay attention to the requirements that apply to integration and field mounting kit, see the below list. The information given in the list must be observed to avoid serious damage or injury, especially when installing large units.

The VLT frequency converter *must* be installed vertically.

The VLT frequency converter is cooled by means of air circulation. For the unit to be able to release its cooling air, the *minimum* distance over and below the unit must be as shown in the illustration below. To protect the unit from overheating, it must be ensured that the ambient temperature *does not rise above the max. temperature stated for the VLT frequency converter* and that the 24-hour average temperature *is not exceeded.* The max. temperature and 24-hour average can be seen from the General Technical Data on page 11.

If the ambient temperature is in the range of 45° C -55° C, derating of the VLT frequency converter will be required in accordance with the diagram on page 96 of the Design Guide. The service life of the VLT frequency converter will be reduced if no allowance is made for the derating for ambient temperature.

Enclosure protection

Bookstyle	IP 00 -	IP 20 OK	IP 54 -
Compact VLT 5001-5027 200-240 V	_	ок	ОК
VLT 5001-5250 380-500 V	ОК	OK	OK
VLT 5300-5500 380-500 V	ОК	ОК	ŌK


Field mounting IP 00 IP 20

	IP 00	1P 20	IP 54
Bookstyle	-	No	-
Compact			
VLT 5001-5027 200-240 V	-	No	ОК
VLT 5001-5250 380-500 V	No	No	OK
VLT 5300-5500 380-500 V	No	No	OK


Compact w/IP 4x top co	ver .		
VLT 5001-5006 200 V	-	OK	OK
VLT 5001-5011 500 V	-	OK	OK

Compact w/IP 20 terminal cover				
VLT 5008-5027 200 V	-	OK	OK	
VLT 5016-5052 500 V	-	OK	OK	

Installation of VLT 5001-5006 200-240 V, VLT 5001-5011 380-500 V Bookstyle IP 20



Side-by-side




DANFOSS 1752A006.10

All Bookstyle units require a minimum space of 100 mm above and below the enclosure.


All Bookstyle units can be installed side by side without any space between them, since the units do not require any cooling on the sides.

Installation of VLT 5001-5006 200-240 V, VLT 5001-5011 380-500 V Compact IP 20 and IP 54 Cooling Side-by-side


Mechanical installation




All Compact units require a minimum space of 100 mm above and below the enclosure and must be installed on a plane, vertical surface (no spacers). This applies to both IP 20 and IP 54 units.




All Compact units can be installed side-by-side without any space between them, since the units do not require any cooling on the sides.





All Compact units in the above-mentioned series require a minimum space of 200 mm above and below the enclosure and must be installed on a plane, vertical surface (no spacers). This applies to both IP 20 and IP 54 units.




All IP 20 and IP 54 units in the above-mentioned series can be installed side by side without any space between them, since these units do not require cooling on the sides.

ā.




VLT' 5000 Series

Installation of VLT 5060-5100 380-500 V, VLT 5032-5052 200-240 V Compact IP 00, IP 20 and IP 54



All Compact units in the above-mentioned series require a minimum space of 225 mm above and below the enclosure and must be installed on a plane, vertical surface (no spacers). This applies to both IP 00, IP 20 and IP 54 units.




All IP 00 and IP 20 units in the above-mentioned series can be installed side by side without any space between them.


■ Installation of VLT 5125-5250 380-500 V Compact IP 00, IP 20 and IP 54

Cooling


Cooling



All Compact units in the above-mentioned series require a minimum space of 225 mm above and below the enclosure and must be installed on a plane, vertical surface (no spacers). This applies to both IP 00, IP 20 and IP 54 units.



Compact IP 00 and IP 20




Compact IP 54 All IP 00, IP 20 and IP 54 units in the abovementioned series can be installed side by side without any space between them, since these units do not require cooling on the sides.

MG.50.A9.02 - VLT is a registered Danfoss trademark

. .



■ Installation of VLT 5300-5500 380-500 V Compact IP 00, IP 20 and IP 54 Side-by-side



75ZA464.10

All units in the above-mentioned series require a minimum space of 400 mm above the enclosure and must be installed on a plane floor. This applies to both IP 00, IP 20 and IP 54 units. Gaining access to the VLT 5300-5500 requires a minimum space of 605 mm in front of the VLT frequency converter.

Compact IP 00, IP 20 and IP 54 All IP 00, IP 20 and IP 54 units in the abovementioned series can be installed side by side without any space between them, since these units do not require cooling on the sides.



Electrical installation


The voltage on the frequency converter is dangerous when the unit is connected to mains. Incorrect installation of the motor or VLT frequency converter may lead to

material damage or serious injury or it may be fatal. Consequently, the instructions in this manual as well as national and local rules and safety regulations must be complied with.

Touching the electrical parts may be fatal, even after the mains supply has been disconnected. Wait at least 4 minutes if using VLT 5001-5006 and at least 15 minutes if using VLT 5008-5500.

NB! It is the user's or certified electrician's ļ responsibility to ensure correct earthing and protection in accordance with applicable national and local norms and standards.

All terminals for the control cables are located under the protective cover of the VLT frequency converter. The protective cover (see drawing) can be removed by means of a pointed object - a screwdriver or similar.



Once the protective cover has been removed, the actual EMC-correct installation can start. See drawings on pages 30-32.


ς.


MG.50.A9.02 - VLT is a registered Danfoss trademark















Electrical installation, power cables










MG.50.A9.02 - VLT is a registered Danfoss trademark








33

Electrical installation, enclosures











Electrical installation, enclosures




.

Compact IP 20 VLT 5125-5250, 380-500 V




Compact IP 54 VLT 5032-5052, 200-240 V VLT 5060-5100, 380-500 V



VLT 5125-5250, 380-500 V

÷.,



Compact IP 20 / IP 54 VLT 5300-5500, 380-500 V




EMC-correct electrical installation

General points to be observed to ensure EMC-correct electrical installation:

- Use only braided screened/armoured motor cables and braided screened/armoured control cables.
- Connect the screen to earth at both ends.
- Avoid installation with twisted screen ends (pigtails), since this ruins the screening effect at high frequencies. Use cable clamps instead.
- It is important to ensure good electrical contact from the installation plate through the installation screws to the metal cabinet of the VLT frequency converter.
- Use starwashers and galvanically conductive installation plates.
- Do not use unscreened/unarmoured motor cables in the installation cabinets.

The illustration below shows EMC-correct electrical installation; the VLT frequency converter has been fitted in an installation cabinet and connected to a PLC.





Use of EMC-correct cables


Braided screened/armoured cables are recommended to optimise EMC immunity of the control cables and the EMC emission from the motor cables.

The ability of a cable to reduce the in- and outgoing radiation of electric noise depends on the transfer impedance (Z_T). The screen of a cable is normally designed to reduce the transfer of electric noise; however, a screen with a lower transfer impedance (Z_T) value is more effective than a screen with a higher transfer impedance (Z_T).

Transfer impedance (Z_T) is rarely stated by cable manufacturers, but it is often possible to estimate transfer impedance (Z_T) by assessing the physical design of the cable.

Transfer impedance (Z_T) can be assessed on the basis of the following factors:

- The conductibility of the screen material.
- The contact resistance between the individual screen conductors.
- The screen coverage, i.e. the physical area of the cable covered by the screen often stated as a percentage value.
- Screen type, i.e. braided or twisted pattern.







Earthing of braided screened/armoured control cables


Generally speaking, control cables must be braided screened/armoured and the screen must be connected by means of a cable clamp at both ends to the metal cabinet of the unit.

The drawing below indicates how correct earthing is carried out and what to be done if in doubt. **PLC etc.**







PLC etc.



PLC etc.





Correct earthing

Control cables and cables for serial communication must be fitted with cable clamps at both ends to ensure the best possible electrical contact.

Wrong earthing

Do not use twisted cable ends (pigtails), since these increase the screen impedance at high frequencies.

Protection with respect to earth potential between PLC and VLT

If the earth potential between the VLT frequency converter and the PLC (etc.) is different, electric noise may occur that will disturb the whole system. This problem can be solved by fitting an equalising cable, to be placed next to the control cable. Minimum cable cross-section: 16 mm².

For 50/60 Hz earth loops

If very long control cables are used, 50/60 Hz earth loops may occur. This problem can be solved by connecting one end of the screen to earth via a 100nF capacitor (keeping leads short).

Cables for serial communication

Low-frequency noise currents between two VLT frequency converters can be eliminated by connecting one end of the screen to terminal 61. This terminal is connected to earth via an internal RC link. It is recommended to use twisted-pair cables to reduce the differential mode interference between the conductors.



I Tightening-up torques and screw sizes

The table shows the torque required when fitting terminals to the VLT frequency converter. For VLT 5001-5027 200-240 V, VLT 5001-5052 380-500 V the cables must be fastened with screws. For VLT 5032 - 5052 200-240 V, VLT 5060-5500 380-500 V the cables must be fastened with bolts.


These figures apply to the following terminals:

Mains terminals		1, 92, 93
Motor terminals	Nos 9	5, 97, 98 J, V, W
Earth terminal	No 95	31, 82
Brake resistor		
terminals	_	20.00
		88, 89
Loadsharing VLT type	.Tightening-up	Screw
<u>3 x 200-240 V</u>	torque	size
VLT 5001-5006	0.5 - 0.6 Nm	M3 -
VLT 5008-5011	1.8 Nm	M4
VLT 5016-5022	3.0 Nm	M5
VLT 5027	4.0 Nm	M6
VLT type	Tightening-up	Screw
3 x 200-240 V	torque	size
VLT 5032-5052 ¹⁾	11.3 Nm	M8
VLT type	Tightening-up	Screw
3 x 380-500 V	torque	size
VLT 5001-5011	0.5 - 0.6 Nm	M3
VLT 5016-5027	1.8 Nm	M4
VLT 5032-5042	3.0 Nm	M5
VLT 5052	4.0 Nm	M6
VLT type	Tightening-up	Bolt
3 x 380-5 <u>00 V</u>	torque	size
VLT 5060-5100 1)	11.3 Nm	M8
VLT 5125-5250	11.3 Nm	M8
VLT 5300-5500 2)	42 Nm	M12

- Por the brake terminals, the tightening-up torque is 3.0 Nm and the bolt size M6.
- ²⁾ For the brake terminals, the tightening-up torque is 42 Nm and the bolt size M8.

Connection of mains

Connect the three mains phases to terminals $L_1, L_2, L_3.$



High voltage test

A high voltage test can be carried out by shortcircuiting terminals U, V, W, L₁, L₂ and L₃ and energizing by max. 2.15 kV DC for one second between this short-circuit and the chassis.



The RFI switch must be closed (position ON) when high voltage tests are carried out (see

pages 33-36, RFI switch). The mains and motor connection must be interrupted

in the case of high voltage tests of the total installation if the leakage currents are too high.

Safety earthing:



Ш¢ The VLT frequency converter has a high leakage current and must be earthed appropriately for safety reasons. Use earth terminal (see drawing pages 30-32), which enables reinforced earthing.

Apply national safety regulations.

Motor thermal protection

The electronic thermal relay in UL-approved VLT frequency converters has received the UL-approval for single motor protection when parameter 128 has been set for ETR Trip and parameter 105 has been programmed to the rated motor current (see motor nameplate).

Extra protection (RCD)

ELCB relays, multiple protective earthing or earthing can be used as extra protection, provided that local safety regulations are complied with.

In the case of an earth fault, a DC content may develop in the faulty current.

If ELCB relays are used, local regulations must be observed. Relays must be suitable for protection of 3phase equipment with a bridge rectifier and for a brief discharge on power-up.

See also the section Special Conditions in the Design Guide.

Mains supply isolated from earth:

If the VLT frequency converter is supplied from an isolated mains source (IT mains), the RFI switch can be turned off (OFF). In OFF position, the internal RFI capacities (filter capacitors) between the chassis and the intermediate circuit are cut off to avoid damage to the intermediate circuit and to reduce the earth capacity (according to IEC 1800-3). See position of RFI switch on pages 33-36.



The RFI switch is not to be operated with mains connected to the unit. Check that the mains supply has been disconnected before operating the RFI switch.



NB!

Open RFI switch is only allowed at factory set switching frequencies.



NB!

The RFI switch disconnects the capacitors galvanically; however, transients higher than approx. 1,000 V will be bypassed by a spark gap.

Mains supply connected to earth:

The RFI switch must be in ON position in order for the frequency converter to comply with the EMCstandard.

Installation of motor cables



If an unscreened cable is used, some EMC requirements are not complied with, see the Design Guide chapter 11: Special conditions.

If the EMC specifications regarding emission are to be complied with, the motor cable must be screened, unless otherwise stated for the RFI filter in question. It is important to keep the motor cable as short as possible so as to reduce the noise level and leakage currents to a minimum.

The motor cable screen must be connected to the metal cabinet of the frequency converter and to the metal cabinet of the motor. The screen connections are to be made with the biggest possible surface (cable clamp). This is enabled by different installation devices in the different VLT frequency converters.


Mounting with twisted screen ends (pigtails) is to be avoided, since these spoil the screening effect at higher frequencies.

If it is necessary to break the screen to install a motor isolator or motor contactor, the screen must be continued at the lowest possible HF impedance.

The frequency converter has been tested with a given length of cable and a given cross-section of that cable. If the cross-section is increased, the cable capacitance - and thus the leakage current increases, and the cable length must be reduced correspondingly.

Connection of motor

All types of 3-phased asynchronous standard motors can be used with the VLT 5000 Series.




Normally, small motors are star-connected (200/400 V, Δ/Y).

Large motors are delta-connected (400/690 V, Δ /Y).

Danfoss

Direction of motor rotation




The factory setting is for clockwise rotation with the VLT frequency transformer output connected as follows.

Terminal 96 connected to U-phase Terminal 97 connected to V-phase Terminal 98 connected to W-phase

The direction of rotation can be changed by switching two phases in the motor cable.

Parallel coupling of motors



VLT 5000 Series is able to control several motors connected in parallel. If the motors are to have different rpm values, the motors must have different rated rpm values. Motor rpm is changed simultaneously, which means that the ratio between the rated rpm values is maintained across the range. The total current consumption of the motors is not to exceed the maximum rated output current $I_{VLT,N}$ for the VLT frequency converter.

Problems may arise at the start and at low rpm values if the motor sizes are widely different. This is because the relatively high ohmic resistance in small motors calls for a higher voltage at the start and at low rpm values.

In systems with motors connected in parallel, the electronic thermal relay (ETR) of the VLT frequency converter cannot be used as motor protection for the individual motor. Consequently, additional motor protection is required, such as thermistors in each motor (or individual thermal relays).

Please note that the individual motor cable for each motor must be summed and is not to exceed the total motor cable length permitted.

Installation of brake cable

No.	Function			
81, 82 🕚	Brake resistor terminals			
The connec	tion cable to the brake resistor must be			
screened. (Connect the screen by means of cable			
clamps to the conductive back plate at the VLT				
frequency converter and to the metal cabinet of the				
brake resist	Or.			
Size the bra	ake cable cross-section to match the			

Size the brake cable cross-section to match the brake torque.



NB!

Please note that voltages up to 850 V DC may occur on the terminals.

Electrical installation

Installation of loadsharing

No.

Loadsharing

Function

ction cable must be screened and the max. 89 length from the VLT frequency converter to the DC bar is 25 metres.

Load sharing enables linking of the DC intermediate circuits of several VLT frequency converters.



NB! Please note that voltages up to 850 V DC will

occur on the terminals.

Load sharing calls for extra equipment. For further information please consult Loadsharing Instructions MI.50.NX.XX.

Installation of relay terminals:

Torque: 0.5 - 0.6 Nm Screw size: M3


No.	Function
1-3	Relay output, 1+3 break, 1+2 make See parameter 323 of the Operating Instructions. See also <i>General technical</i> <i>data</i> .
4, 5	Relay output, 4+5 make See parameter 326 of the Operating Instructions. See also <i>General technical</i> <i>data</i> .

■ Installation of 24 Volt external DC supply:

Torque: 0.5 Screw size:		
<u>No.</u>	Function	
35, 36	24 V external DC supply	

24 V external DC supply can be used as low-voltage supply to the control card and any option cards installed. This enables full operation of the LCP (incl. parameter setting) without connection to mains. Please note that a warning of low voltage will be given when 24 V DC has been connected; however, there will be no tripping. If 24 V external DC supply is connected or switched on at the same time as the mains supply, a time of min. 200 msec. must be set in parameter 120 Start delay.

A pre-fuse of min. 6 Amp, slow-blow, can be fitted to protect the external 24 V DC supply. The power consumption is 15-50 W, depending on the load on the control card.



Installation of brake resistor temperature switch: Torque: 0.5-0.6 Nm

Screw	size:	М3	

Function Nos.

106, 104, 105 Brake resistor temperature switch.




NB!:

This function is only available on VLT 5032-5052 200-240 V and VLT 5060-5500 380-500 V.

If the temperature of the brake resistor gets too high and the KLIXON switch drops out, the VLT frequency converter will stop braking. The motor will start coasting.


A KLIXON switch must be installed that can either be 'normally closed' or 'normally open'. If this function is not used, 106 and 104 must be short-circuited together.



Bus connection

The serial bus connection in accordance with the RS 485 (2-conductor) norm is connected to terminals 68/69 of the frequency converter (signals P and N). Signal P is the positive potential (TX+,RX+), while signal N is the negative potential (TX-,RX-).

If more than one frequency converter is to be connected to a given master, use parallel connections.



In order to avoid potential equalizing currents in the screen, the cable screen can be earthed via terminal 61, which is connected to the frame via an RC-link.

Bus termination


The bus must be terminated by a resistor network at both ends. For this purpose, set switches 2 and 3 on the control card for "ON".

Danfoss

Switches 1-4:

The dipswitch is located on the control card. It is used for serial communication, terminals 68 and 69.

The switching position shown is the factory setting.



Switch 1 has no function.

Switches 2 and 3 are used for terminating an RS 485 interface, serial communication.

Switch 4 is used for separating the common potential for the internal 24 V DC supply from the common potential of the external 24 V DC supply.




NB!

Please note that when Switch 4 is in position "off", the external 24 V DC supply is galvanically isolated from the VLT frequency converter.

Installation of control cables

Tightening-up torque: 0.5-0.6 Nm Screw size: M3 See page 39 for correct earthing of screened control cables.



A OUT

A IN A IN COM A Di A IN


OUT

COM

A OUT

DANFOSS 175KA379.10


RELAY




Function Nos.

12,13	Voltage supply to digital inputs For the internal 24 V DC to be usable for the digital inputs, switch 4 on the control card must be closed. position "ON".
16-33	Digital inputs/encoder inputs
20	Ground for digital inputs
39	Ground for analogue/digital outputs
42, 5	Analogue/digital outputs for indicating frequency, reference, current and torque
50	Supply voltage to potentiometer and thermistor 10 V DC
53,54	Analogue input, voltage 0 - ±10 V
55	Ground for analogue inputs
60	Analogue input, current 0/4-20 mA
61	Termination for serial communication. See page 34. This terminal is normally not to be used.
68, 69	RS 485 interface, serial communication. Where the VLT frequency converter is connected to a bus, switches 2 and 3


(switches 1-4) must be closed on the first and the last VLT frequency converter. On the remaining VLT frequency converters, switches 2 and 3 must be open. The factory setting is closed (position "ON").



Electrical installation




Connection examples 2-wire start/stop




- Start/stop using terminal 18. Parameter 302 = *Start* [1]
- Quick-stop using terminal 27.
 Parameter 304 = Coasting stop inverted [0]








Connection examples, cont. Setup change




Selection of setup using terminals 32 and 33.
 Parameter 306 = Selection of setup, lsb [10]
 Parameter 307 = Selection of setup, msb [10]
 Parameter 004 = Multi-setup [5].

Digital speed up/down





Speed up and down using terminals 32 and 33.
 Parameter 306 = Speed up [9]
 Parameter 307 = Speed down [9]
 Parameter 305 = Freeze reference [9].

Potentiometer reference




Parameter 309 = Terminal 53, min. scaling Parameter 310 = Terminal 53, max. scaling






Parameter 314 = *Reference* [1], *Feedback* [2] Parameter 315 = *Terminal 60, min. scaling* Parameter 316 = *Terminal 60, max. scaling*



Encoder connection



Parameter 306 = Encoder input B [24] Parameter 307 = Encoder input A [25]

If an encoder is connected that only has one output to *Encoder input A* [25], *Encoder input B* [24] must be set to *No function* [0].

Danfoss

Cross-reference for terminals/parameter functions.

Digital inputs	Terminal no.	16	17	18	19	27	29	32	33
	parameter	300	301	302	303	304	305	306	307
Value:									
No function	(NO OPERATION)	[0]	[0]	[0]	[0]		[0]	[0]	[0]
Reset	(RESET)	[1]★	[1]				[1]	[1]	[1]
Coasting stop, inverse	(COAST INVERSE)					[0]★			
Reset and coasting stop, i	nverse								
	(COAST & RESET INVERS)					[1]			
Quick-stop, inverse	(QSTOP INVERSE)					[2]			
DC-braking, inverse	(DCBRAKE INVERSE)					[3]			
Stop inverse	(STOP INVERSE)	[2]	[2]			[4]	[2]	[2]	[2]
Start	(START)			[1]★					
Latched start	(LATCHED START)			[2]					
Reversing	(REVERSING)				[1]★				
Start reversing	(START REVERSE)				[2]			· · · ·	
Only start clockwise, on	(ENABLE START FWD.)	[3]		[3]			[3]	[3]	
Only start anti-clockwise, or			[3]		[3]		[4]		[3]
Jog	(JOGGING)	[4]	[4]				[5]★	[4]	[4]
Preset reference, on			[5]				[6]	[5]	[5]
Preset reference, Isb	(PRESET REF. SEL. LSB)	<u>[5]</u> [6]					[7]	[6]	
Preset reference, msb	(PRESET REF. MSB)		[6]				[8]		[6]
Freeze reference	(FREEZE REFERENCE)	[7]	[7]★				[9]	[7]	[7]
Freeze output	(FREEZE OUTPUT)	[8]	[8]				[10]	[8]	[8]
Speed up	(SPEED UP)	[9]					[11]	[9]	
Speed down	(SPEED DOWN)		[9]				[12]		[9]
Choice of Setup, Isb	(SETUP SELECT LSB)	[10]					[13]	[10]	
Choice of Setup, msb	(SETUP SELECT MSB)		[10]				[14]		[10]
Choice of Setup, msb/spe	ed up								
• •	(SETUP MSB/SPEED UP)							[11] ★	
Choice of Setup, Isb/spee	d down								
• • •	(SETUP LSB/SPEED DOWN)								[11] ★
Catch-up	(CATCH UP)	[11]					[15]	[12]	
Slow-down	(SLOW DOWN)		[11]				[16]	_•	[12]
Ramp 2	(RAMP 2)	[12]	[12]				[17]	[13]	[13]
Mains failure inverted	(MAINS FAILURE INVERSE)		[13]				[18]	[14]	[14]
Pulse reference	(PULSE REFERENCE)	[13]	[23]			1.	[28] ¹		
Pulse feedback	(PULSE FEEDBACK)								[24]
Encoder feedback input, A	(ENCODER INPUT 2A)								[25]
Encoder feedback input, B	(ENCODER INPUT 2B)							[24]	<u>_</u> .
							11		

1) If this function is selected for terminal 29, the same function for terminal 17 will not be valid, even if it has been selected to be active.

Dantoss

VLT' 5000 Series

Control panel

The front of the VLT frequency converter features a control panel - LCP (Local Control Panel), which makes up a complete interface for operation and monitoring of the VLT 5000 Series.

The control panel is detachable and can - as an alternative - be installed up to 3 metres away from the VLT frequency converter, e.g. on a front panel, by means of a mounting kit option.

The functions of the control panel can be divided into three groups:

- display
- keys for changing program parameters
- keys for local operation


All data are indicated by means of a 4-line alphanumeric display, which in normal operation is able to show 4 measurements and 3 operating conditions continuously. During programming, all the information required for quick, effective parameter Setup of the VLT frequency converter will be displayed. As a supplement to the display, there are three LEDs for voltage (power or 24 V external), warning and alarm. All program parameters of the VLT frequency converter can be changed immediately from the control panel, unless this function has been blocked via parameter 018.

DISPLAY QUICK MENU STATUS MENU CHANGE CANCEL oк DATA OWARNING Oon FWD. REV. STOP RESET JOG STAR

DANFOSS 1752A004.10

Display

The LCD-display has rear lighting and a total of 4 alpha-numeric lines together with a box that shows the direction of rotation (arrow) and the chosen Setup as well as the Setup in which programming is taking place if that is the case.



1st line shows up to 3 measurements continuously in normal operating status or a text which explains the 2 nd line.

2nd line shows a measurement with related unit continuously, regardless of status (except in the case of alarm/warning).

.


3rd line is normally blank and is used in the menu mode to show the selected parameter number or parameter group number and name.


4th line is used in operating status for showing a status text or in data change mode for showing the mode or value of the selected parameter.

An arrow indicates the direction of rotation of SETUP the motor. Furthermore, the Setup which has been selected as the Active Setup in parameter 004 is shown. When programming another Setup than the Active Setup, the number of the Setup which is being programmed will appear to the right. This second Setup number will flash.

■ LEDs

At the bottom of the control panel is a red alarm LED and a yellow warning LED, as well as a green voltage LED.








If certain threshold values are exceeded, the alarm and/or warning LED lights up together with a status and alarm text on the control panel.


The voltage LED is activated when the VLT frequency converter receives voltage, or 24 V external supply; at the same time the rear lighting of the display will be on.

Control keys

The control keys are divided into functions. This means that the keys between display and indicator lamps are used for parameter Setup, including choice of display indication during normal operation.



Keys for local control are found under the indicator LEDs.



Control key functions



[DISPLAY / STATUS] is used for selecting the mode of display or for changing back to Display mode from either the Quick menu mode or the Menu mode.



[QUICK MENU] is used for programming the parameters that belong under the Quick menu mode. It is possible to switch directly between Quick menu mode and Menu mode.

MENU

[MENU] is used for programming all parameters. It is possible to switch directly between Menu mode and Quick menu mode.



[CHANGE DATA] is used for changing the parameter selected either in the Menu mode or the Quick menu mode.

[CANCEL] is used if a change of the se-

lected parameter is not to be carried out.



[OK] is used for confirming a change of the parameter selected.

[+/-] is used for selecting parameter and for changing the chosen parameter or for changing the read out in line 2.

[<>] is used for selecting group and to move the cursor when changing numerical parameters.

[STOP / RESET] is used for stopping the motor connected or for resetting the VLT frequency converter after a dropout (trip). Can be selected via parameter 014 to be active or inactive. If stop is activated, line 2 will flash, and [START] must be activated.

[JOG] overrides the output frequency to

a preset frequency while the key is kept

down. Can be selected via parameter

015 to be active or inactive.

be active or inactive.

JOG

STOP



[FWD / REV] changes the direction of rotation of the motor, which is indicated by means of the arrow on the display although only in Local. Can be selected via parameter 016 to

START

[START] is used for starting the VLT frequency converter after stop via the "Stop" key Is always active, but cannot override a stop command given via the terminal strip.

NB!



If the keys for local control have been selected as active, they will remain active both when the VLT frequency has been set for Local Control and for Remote Control via parameter 002, although

with the exception of [FWD/REV], which is only active in Local operation.

NB!

If no external stop function has been selected and the [STOP] key has been selected as inactive, the motor can be started and can only be stopped by disconnecting the voltage to the motor.



Display read-out state

The display read-out state can be varied - see the list below - depending on whether the VLT frequency converter is in normal operation or is being programmed.

Display mode

In normal operation, up to 4 different operating variables can be indicated continuously: 1.1 and 1.2 and 1.3 and 2, and in line 4 the present operating status or alarms and warnings that have arisen.



Display mode - selection of read-out state

There are three options in connection with the choice of read-out state in the Display mode - I, II and III. The choice of read-out state determines the number of operating variables read out.

Read-out state:	l:	II:	III:
Line 1	Description	Data value	Description
	for operating	for 3 operating	for 3 operating
	variable in line 2	variables in line 1	variables in line 1


The table below gives the units linked to the variables in the first and second line of the display.

In the first and second line of the t	nspiay.
Operating variable:	Unit:
Reference	(%)
Reference	[unit]
Feedback	[unit]
Frequency	[Hz]
Frequency x scaling	[-]
Motor current	[A]
Torque	[%]
Power	[kW]
Power	[HP]
Output energy	[kWh]
Motor voltage	[V]
DC-link voltage	[V]
Motor thermal load	[%]
VLT thermal load	[%]
Hours run	[Hours]
Input status, dig. Input	[Binary code]
Input status, analogue terminal 53	[V]
Input status, analogue terminal 54	[V]
Input status, analogue terminal 60	[mA]
Pulse reference	[Hz]
External reference	[%]
Status word	[Hex]
Brake effect/2 min.	[kW]
Brake effect/sec.	[kW]
Heat sink temp.	[°C]
Alarm word	[Hex]
Control word	[Hex]
Warning word 1	[Hex]
Extended status word	(Hex)
Communication option card warning	[Hex]

Operating variables 1.1 and 1.2 and 1.3 in the first line, and operating variable 2 in the second line are selected via parameter 009, 010, 011 and 012.

· Read-out state I:


This read-out state is standard after starting up or after initialisation.



Line 2 gives the data value of an operating variable with related unit, and line 1 provides a text which explains line 2, cf. table. In the example, Frequency has been selected as variable via parameter 009. During normal operation another variable can immediately be read out by using the [+/-] keys.

Read-out state II:

Switching between read-out states I and II is effected by pressing the [DISPLAY / STATUS] key.




In this state, data values for four operating values are shown at the same time, giving the related unit, cf. table. In the example, Reference, Torque, Current and Frequency are selected as variables in the first and second line.

VLT^{*} 5000 Series

Read-out state III:


This read-out state can be held as long as the [DIS-PLAY/STATUS] key is pressed. When the key is released, the system switches back to Read-out state II, unless the key is pressed for less that approx. 1 sec., in which case the system always reverts to Read-out state I.



This is where parameter names and units for operating variables in the first and second line are given operating variable 2 remains unchanged.

· Display state IV:

This display state can be produced during operation if another setup is to be changed without stopping the VLT frequency converter. This function is activated in parameter 005, *Programming Setup*.



The selected programming setup number will flash to the right of the active setup.

Parameter Setup

The VLT 5000 Series can be used for practically all assignments, which is why the number of parameters is quite large. Also, this series offers a choice between two programming modes - a Menu mode and a Quick menu mode.

The former provides access to all parameters. The latter takes the user through a few parameters which make it possible in most cases to start operating the VLT frequency converter.

Regardless of the mode of programming, a change of a parameter will take effect and be visible both in the Menu mode and in the Quick menu mode.

Structure for the Quick menu mode versus the Menu mode

In addition to having a name, each parameter is linked up with a number which is the same regardless of the programming mode. In the Menu mode, the parameters are divided into groups, with the first digit of the parameter number (from the left) indicating the group number of the parameter in question.

- The quick menu takes the user through a number of parameters that may be enough to get the motor to run nearly optimally, if the factory setting for the other parameters takes the desired control functions into account, as well as the configuration of signal inputs/outputs (control terminals).
- The Menu mode makes it possible to select and change all parameters at the user's option.
 However, some parameters will be "missing", depending on the choice of configuration (parameter 100), e.g. open loop hides all the P.I.D. parameters.

Quick Setup via Quick menu

The Quick Setup starts with pressing the [QUICK MENU] key, which brings out the following read-out on the display:



At the bottom of the display, the parameter number and name are given together with the status/value of the first parameter under Quick Setup. The first time the [Quick Menu] key is pressed after the unit has been switched on, the read-outs always start at pos. 1 - see table below.

Parameter selection


The selection of parameter is effected by means of the [+/-] keys. The following parameters are accessible:

Pos.:	No.:	Parameter:	Unit:
1	001	Language	Unit.
2	102	Motor output	[kW]
3	103	Motor voltage	M
4	104	Motor frequency	[Hz]
5	105	Motor current	[A]
6	106	Rated motor speed	(rpm)
7	107	Automatic motor adaptation, AMA	
8	204	Minimum reference	Hz
9	205	Maximum reference	(Hz)
10	207	Ramp-up time 1	[sec.]
11	208	Ramp-down time 1	[sec.]
12	002	Local/remote control	
13	003	Local reference	

Dantoss

Menu mode

The Menu mode is started by pressing the [MENU] key, which produces the following read-out on the display:



Line 3 on the display shows the parameter group number and name.


Parameter selection

In the Menu mode the parameters are divided into groups. Selection of parameter group is effected by means of the [<>] keys.

The following parameter groups are accessible:

Group no.	Parameter group:
0	Operation & Display
1	Load & Motor
2	References & Limits
3	Inputs & Outputs
4	Special functions
5	Serial communication
6	Technical functions

When the desired parameter group has been selected, each parameter can be chosen by means of the [+/-] keys:



The 3rd line of the display shows the parameter number and name, while the status/value of the selected parameter are shown in line 4.

Changing data

Regardless of whether a parameter has been selected under the Quick menu or the Menu mode, the procedure for changing data is the same. Pressing the [CHANGE DATA] key gives access to changing the selected parameter, following which the underlining in line 4 will flash on the display. The procedure for changing data depends on whether the selected parameter represents a numerical data value or a text value.

Changing a text value


If the selected parameter is a text value, the text value is changed by means of the [+/-] keys.



The bottom display line shows the text value that will be entered (saved) when acknowledgement is given [OK].

Change of group of numeric data values

If the chosen parameter represents a numeric data value, the chosen data value is changed by means of the [+/-] keys.



The chosen data value is indicated by the digit flashing.

The bottom display line shows the data value that will be entered (saved) when signing off with [OK].

Manual initialisation


Disconnect from mains and hold the [DISPLAY/ STATUS] + [CHANGE DATA] + [OK] keys down while at the same time reconnecting the mains supply. Release the keys; the VLT frequency converter has now been programmed for the factory setting.

The following parameters are not zeroed by means of manual initialisation:


parameter 600, Operating hours

- 601, Hours run
- 602, kWh counter
- 603, Number of power-ups
- 604, Number of overtemperatures
- 605, Number of overvoltages

It is also possible to carry out initialisation via parameter 620, see page 144 regarding procedure. Infinitely variable change of numeric data value If the chosen parameter represents a numeric data value, a digit is first selected by means of the [<>] keys.



Then the chosen digit is changed infinitely variably by means of the [+/-] keys:




The chosen digit is indicated by the digit flashing. The bottom display line shows the data value that will be entered (saved) when signing off with [OK].

Changing of data value, step-by-step

Certain parameters can be changed step by step or infinitely variably. This applies to Motor power (parameter 102). Motor voltage (parameter 103) and Motor frequency (parameter 104).

This means that the parameters are changed both as a group of numeric data values and as numeric data values infinitely variably.



MG.50.A9.02 - VLT is a registered Danfoss trademark

Dantoss

VLT' 5000 Series

Using this parameter enables the choice of a configuration (setting) of the VLT frequency converter that fits the application in which the VLT frequency converter is to be active.



First, the motor nameplate data must be set in parameters 102-106.

Setting of parameters

Select *Speed control, open loop* if a normal speed adjustment without external feedback signals is required (the internal slip compensation is operating) from motor or unit.

Set the following parameters in order shown:

Speed control, open loop:

1 3000 Series

There is a choice of the following configurations:

- Speed control, open loop
- Speed control, closed loop
- Process control, closed loop
- Torque control, open loop
- Torque control, speed feedback

The selection of special motor characteristics can be combined with any application configuration.

 Parameter
 Setting
 Data value;

 100
 Configuration
 Speed control open loop.
 [0]

 200
 Output frequency range/direction
 [0]

 201
 Output frequency low limit.
 Only if [0] or [2] in par. 200.

 202
 Output frequency high limit.
 Only if [0] in par. 203.

 203
 Reference/feedback range

 204
 Minimum reference.

 205
 Maximum reference

Select *Speed control, closed loop* if the application has a feedback signal and the accuracy in *Speed control, open loop* is not sufficient or a full holding torque is required.

Set the following parameters in order shown:

Speed control, closed loop (PID):

Setting: Data value: Parameter 100 Configuration 200 Output frequency range/direction Output frequency low limit 202 Output frequency high limit Reference/feedback_range 414 Minimum feedback Only if [0] or [2] in par-200 415 Maximum feedback 204 Minimum reference Only if [0] in part 205 Maximum reference 417 Speed PID proportional gain 418 Speed PID integration time 419 Speed PID differentiation time Speed RID diff- gain limit 421 Speed PID lowpass filter time



Setting of parameters, cont.

Select *Process control, closed loop* if the application has a feedback signal that is not directly related to motor speed (rpm/Hz), but some other unit, such as temperature, pressure, etc. Set the following parameters in the order shown:

Process	control,	closed	loop	(Process	PID):	
Doromoto	<u></u>					0

Parameter:		Setting:	Data value:	
100	Configuration	Process control, closed loop	[3]	
200	Output frequency range/direction			
201	Output frequency low limit			
202	Output frequency high limit			
203	Reference/feedback range			
414	Minimum feedback	Only if [0] or [2] in par. 200		
415	Maximum feedback			
204	Minimum reference	Only if [0] in par. 203		
205	Maximum reference			
416	Process units			
437	Process PID normal/inverse			
438	Process PID anti-windup			
439	Process PID start frequency			
440	Process PID proportional gain			
441	Process PID integration time			
442	Process PID differentiation time			
443	Process PID diff. gain limit			
444	Process PID lowpass filter			

Select *Torque control, open loop* if PI control is required, to change the motor frequency in order to maintain the torque reference (Nm). This is relevant for winding and extrusion

Torque control, open loop, is to be selected if the speed direction is not to be changed during operation; this means that either a positive or a negative torque reference is used at all times.

Set the following parameters in order shown:

Torque	e control, open loop:		
Parameter:		Setting:	Data value:
100	Configuration	Torque control, open loop	[4]
200	Output frequency range/direction		
201	Output frequency low limit		
202	Output frequency high limit		
203	Reference/feedback range		· .
204	Minimum reference	Only if [0] in par. 203	
205	Maximum reference		
414	Minimum feedback		· · · · · ·
415	Maximum feedback		
433	Torque proportional gain		
434	Torque integration time		

applications.

Torque control, speed feedback, is selected if it is to be possible to change the speed direction, while at the same time maintaining the torque reference. Set the following parameters in order shown:

		51	
Torque	e control, speed feedback:		
Param	eter:	Setting: D	ata value:
100	Configuration	Torque control, speed feedback	[5]
200	Output frequency, range/direction		
201	Output frequency, low limit		
202	Output frequency, high limit		
203	Reference/feedback range		
204	Minimum reference	Only if [0] in par. 203	
205	Maximum reference		
414	Minimum feedback		
415	Maximum feedback		
306	Encoder feedback, input B		[24]
307	Encoder feedback, input A		[25]
329	Encoder feedback, pulse/rev.		
421	Speed PID low-pass filter time		
0	On the second	e provincia de la construcción de l	

448 Gear ratio

Setting of parameters, cont.

Select *Torque control, speed feedback*, if an encoder feedback signal is to be generated. This is

relevant in winder and extruder applications.

- 447 Torque control, speed feedback
- 449 Friction loss

After *Torque control, speed feedback,* has been selected, the VLT frequency converter should be calibrated to ensure that the current torque equals the torque of the VLT frequency converter. For this to be ensured, a torque gauge must be fitted to the shaft so as to enable accurate adjustment of parameter 447, *Torque compensation,* and parameter 449, *Friction loss.* It is recommended to run an AMA before torque calibration. Proceed as follows before beginning to use the system:

1. Fit a torque gauge to the shaft.

Special motor characteristics

2. Start the motor with a positive torque reference and a positive direction of rotation.

frequency converter is to be adapted to a synchronous motor, parallel motor operation or if slip-

Select Special motor characteristics if the VLT

Read the torque gauge.

- Using the same torque reference, change the direction of rotation from positive to negative. Read the torque and adjust it to the same level as for the positive torque reference and direction of rotation. This can be done by means of parameter 449, *Friction loss*.
- 4. Using a warm motor and approx. 50% load, set parameter 447, *Torque compensation*, to match the torque gauge. The VLT frequency converter is now ready for operation.

Set the following parameters in order shown:

Special motor	characteristics:		
Parameter:	Setting:	Data value:	
101	Torque characteristics	Special motor characterist	tics [5] or [15]
432+431	F5 frequency/U5 voltage		
430+429	F4 frequency/U4 voltage	··· ·· · · · · · · · · · · · · · · · ·	••••••
428+427	F3 frequency/U3 voltage		
426+425	F2 frequency/U2 voltage		
424+423	F1 frequency/U1 voltage		
422	U0 voltage		

Danfoss

Shift between local and remote control

The VLT can be operated manually or remotely. The following is a list of the functions/commands given via the control panel, the digital inputs or the serial communication port in the two situations (modes).

If parameter 002 is set to Local [1]:

On the LCP, the following keys can be used for local control:

Кеу:	Parameter:	Data value:
[STOP]	014	[1] Enable
[JOG]	015	[1] Enable
[RESET]	017	[1] Enable
[FWD/REV]	016	[1] Enable

Set parameter 013 for LCP control and open loop [1] or LCP control as parameter 100 [3]:

- 1. Local reference is set in parameter 003; can be changed via the "+/-" keys.
- 2. Reversing can be effected by means of the [FWD/REV] key.

Set parameter 013 for *LCP digital control and open loop* [2] or *LCP digital control as parameter 100* [4]: For the above parameter setting, it is now possible to control the VLT frequency converter as follows: <u>Digital inputs:</u>

- 1. Local reference set in parameter 003 can be changed via the "+/--" keys.
- 2. Reset via digital terminal 16, 17, 29, 32 or 33.
- 3. Stop inverse via digital terminal 16, 17, 27, 29, 32 or 33.
- 4. Choice of Setup, Isb via digital terminal 16, 29 or 32.
- 5. Choice of Setup, msb via digital terminal 17, 29 or 33.
- 6. Ramp 2 via digital terminal 16, 17, 29, 32 or 33.
- 7. Quick-stop via digital terminal 27.
- 8. DC braking via digital terminal 27.
- 9. Reset and motor coasting stop via digital terminal 27.
- 10. Motor coasting stop via digital terminal 27.
- 11. Reversing via digital terminal 19.
- 12. Choice of Setup, msb/speed up via digital terminal 32.
- 13. Choice of Setup, Isb/speed down via digital terminal 33.

The serial communication port:

1.	Ramp 2	2. Res	et
----	--------	--------	----

- 3. Choice of Setup, lsb 4. Choice of Setup, msb
- 5. Relay 01

6. Relay 04

If parameter 002 is set to Remote control [0]:

Кеу:	Parameter:	Data value:
[STOP]	014	[1]
[JOG]	015	[1]
[RESET]	017	[1]

Control with brake function

The function of the brake is to limit the voltage in the intermediate circuit when the motor is acting as a generator. This occurs, for example, when the load drives the motor and the power enters the intermediate circuit. The brake is built up in the form of a chopper circuit with the connection of an external brake resistor. Placing the brake resistor externally offers the following advantages:

- The brake resistor can be selected on the basis of the application in question.
- The brake energy is dissipated outside the control panel, i.e. where the energy can be utilized.
- The electronics of the VLT frequency converter will not be overheated if the brake resistor is overloaded.

The brake is protected against short-circuiting of the brake resistor, and the brake transistor is monitored to ensure that short-circuiting of the transistor is detected. By using a relay/digital output, the latter can be used for protecting the brake resistor against overloading in connection with a fault in the VLT frequency converter.

In addition, the brake makes it possible to read out the momentary power and the mean power for the latest 120 seconds, as well as to monitor that the power energizing does not exceed a monitoring limit selected via parameter 402. In parameter 403 select the function to be carried out when the power transmitted to the brake resistor exceeds the limit set in parameter 402.



NB!

Monitoring of the brake power is not a safety function; a thermal switch is required for that purpose. The brake resistor circuit is not earth leakage protected.

Selection of brake resistor

In order to select the right brake resistor, the application must be known through-and-through, i.e. it must be known how often to brake and by how much power braking is effected.

The resistor ED, which is often used by motor suppliers when stating the permissible load, is an indication of the duty cycle at which the resistor is working.

The resistor ED is calculated as follows:

ED (duty cycle) =
$$\frac{tb}{(t2-t1)}$$

in which t2-t1 = cycle time in seconds and tb is the braking time in seconds (of the cycle time).

The maximum permissible load on the brake resistor is stated as a peak power at a given ED. That is why the peak power for the brake resistor and the resistor value must be determined.

The following example and formula apply to VLT 5000 only. The peak power can be calculated on the basis of the highest brake resistance required for braking:

$$P_{PEAK} = P_{MOTOR} \times M_{BR(%)} \times \eta_{MOTOR} \times \eta_{VLT}$$

[W]

where M_{BR/%} is expressed as a percentage of the rated torque. The brake resistance is calculated as follows:

$$R_{REC} = \frac{U_{OC}^{2}}{P_{PEAK}} \qquad [\Omega]$$

As can be seen, the brake resistance depends on the intermediate circuit voltage (UDC).

With VLT 5000 frequency converters that have a mains voltage of 3 x 380-500 Volts, the brake will be active at 822 Volts (UDC); if the frequency converter has a mains voltage of 3 x 200-240 Volts, the brake will be active at 397 Volts (UDC).



NB! Remember to check whether the brake

resistor used is able to cope with a voltage of 850 Volts or 430 Volts - unless Danfoss brake resistors are used.

R_{RFC} is the brake resistance recommended by Danfoss, i.e. one that guarantees the user that the frequency converter is able to brake at the highest braking torque (M_{br}) of 160%.

 η_{MOTOR} is typically at 0.90, while η_{VLT} is typically at 0.98. For 500 V and 200 V VLT frequency converters, respectively, R_{REC} at 160% braking torque can be written as:

$$R_{REC} = \frac{478801}{P_{MOTOR}} \qquad [\Omega]$$

$$\mathsf{R}_{\mathsf{REC}} = \frac{111684}{\mathsf{P}_{\mathsf{NOTOR}}} \qquad [\Omega]$$



NB!

The max, brake resistance selected should have an ohmic value max. 10% lower than that recommended by Danfoss.

If a brake resistor with a higher ohmic value is selected, the 160% braking torque will not be achieved and there is a risk that the VLT 5000 Series will cut out for safety reasons. For further information, please consult Brake Instructions MI.50.DX.XX.

NB!



If a short circuit in the brake transistor occurs, power dissipation in the brake resistor can only be prevented by using a mains switch or contactor to disconnect the mains for the VLT. (The contactor can be controlled by the VLT).




Handling of single references

Using a single reference, only one active reference signal is connected, either in the form of an external or in the form of a preset (internal) reference. The external reference can be voltage, current, frequency (pulse) or binary via the serial port. Two examples are given below of the way the single references are handled by VLT 5000 Series.

Example 1:


I	
External reference signal =	1 V (min) - 5 V (max)
Reference =	5 Hz - 50 Hz
Configuration (parameter 100) - Speed control, open loop.



Setti	ng:		
Parameter:		Setting:	Data value:
100	Configuration	Speed control, open loop	[0]
308	Funct. of analogue input	Reference	. [1]
309	Min. reference signal	Min.	1 V
310	Max. reference signal	Max.	5 V
203	Reference range	Reference range	Min - Max [0]
204	Minimum reference	Min. reference	5 (Hz)
205	Maximum reference	Max. reference	50 (Hz)
The fo	llowing can be used:	 Catch-up/slow-down via digital inp Freeze reference via digital input t 	

Example 2:

External reference signal =	0 V (min) - 10 V (max)
Reference =	50 Hz ccw - 50 Hz cw
Configuration (parameter 10	00) = Speed control, open loop.



		1/52/4037.12	
Settir	ng:		
Parar	neter:	Setting:	Data value:
100	Configuration	Speed control, open loop	[0]
308	Funct. of analogue input	Reference	[1]
309	Min. reference signal	Min.	0 V
310	Max. reference signal	Max.	10 V
203	Reference range	Reference range	- Max - + Max [1]
205	Max. reference		1 00 Hz
214	Reference type	Sum	[0]
215	Preset reference		-50%
200	Output frequency range/direction	Both directions, 0-132 Hz	[1]
The following can be used:		 Catch-up/slow-down via digital input Freeze reference via digital input 	

MG.50.A9.02 - VLT is a registered Danfoss trademark



۰,

VLT' 5000 Series

[%] 🛦 a/b/c/d

100

0

Min. PAR.309 PAR.312 PAR.315 U 53/U54/160/f19/29

DANFOSS 175ZA135.10

Mox. PAR.310 PAR.313 PAR.316 PAR.327

Handling of multi-references


If the multi-reference is used, two or more reference signals are connected, either in the form of external or preset reference signals. Via parameter 214 these can be combined in three different ways:

Multi-ref.

Sum Relative External/preset


In the following, each reference type (sum, relative and external/preset) is shown:








■ RELATIVE



EXTERNAL/PRESET




,



VLT' 5000 Series

List of handling of multi-references



MG.50.A9.02 - VLT is a registered Danfoss trademark

2.

3.

4.

5. 6.

Automatic Motor Adaptation, AMA

Automatic motor adaptation is a test algorithm that measures the electrical motor parameters at motor standstill. This means that AMA itself does not supply any torque.

AMA is useful when commissioning systems, where the user wants to optimise the adjustment of the VLT frequency converter to the motor applied. This feature is used in particular where the factory setting does not adequately cover the motor in question.

There are two motor characteristics which are of primary significance in automatic motor adaptation:

- Stator resistance, R_s
- Reactance at normal magnetising level, X_s.

For the best adjustment of the VLT frequency converter, it is recommended to carry out AMA on a cold motor.

It must be noted that repeated AMA runs may lead to a heating of the motor that will result in an increase of the stator resistance Rs. However, in most cases this is not critical.

Parameter 107 allows a choice of automatic motor adaptation, with determination of both Xs and Rs, or reduced automatic motor adaptation with determination of only Rs.

Please note the following with respect to the AMA function and its use:

VLT' 5000 Series

- If a LC filter has been inserted between the VLT frequency converter and the motor, it will only be possible to carry out a reduced test. If an overall setting is required, remove the LC filter while running a total AMA. After completion of the AMA, re-insert the LC filter.
- For AMA to be able to determine the motor parameters optimally, the correct nameplate data for the motor connected to the VLT frequency converter must be entered in parameters 102 to 106.
- The duration of a total automatic motor adaptation varies from a few minutes to approx. 10 minutes, depending on the rating of the motor used (the time for a 7.5 kW motor, for example, is approx. 4 minutes).
- Alarms and warnings will be shown in the display if faults occur during motor adaptation.
- AMA can only be carried out if the rated motor current is min. 35% of the rated output current of the VLT frequency converter. AMA can be carried out up to one oversize motor.
- AMA cannot be carried out on synchronous or parallel-coupled motors.
- If automatic motor adaptation is to be discontinued, press the [STOP/RESET] key.

Procedure for automatic motor adaptation:

- Press the [STOP/RESET] key. 1.
 - Set motor power as per motor nameplate data parameter 102 parameter 103 Set motor voltage as per motor nameplate data Set motor frequency as per motor nameplate data parameter 104 Set motor current as per motor nameplate data parameter 105 Set rated motor speed as per motor nameplate data parameter 106

Danfoss

- 7 8.
- Press the [START] key or connect terminal 18 (start) to terminal 12 (24 V DC). 9.

If automatic motor adaptation is to be stopped:

Press the [STOP/RESET] key. 1.

After normal sequence the display shows:


Press the [STOP/RESET] key. The VLT frequency converter is now ready for operation. 1.

In the case of fault, the display shows:

- 1. Press the [STOP/RESET] key.
- 2. Check possible causes of fault relating to alarm given. See page 154.

If Warning is given, the display shows:

- Check possible fault causes in accordance with the warning. See page 154. 1.
- Press the [CHANGE DATA] key and select "Continue" if AMA is to continue despite the warning, 2. or press the [STOP/RESET] key to discontinue the automatic motor adaptation.



ALARM 21





Automatic motor adaptation, AMA, via VLT Software Dialog

Automatic motor adaptation can also be activated by means of the VLT Software Dialog. This can be done locally or in the form of remote-control via a modem:

Procedure for automatic motor adaptation via VLT Software Dialog:

Start Parameter Setup and select "Start new setting".
 Select VLT type and voltage. Then choose "Off-line".
 Start "Wizard" which quickly sets up relevant motor parameters.
 When "Wizard" has been completed, select total or reduced motor adaptation in parameter 107.
 Save the parameter setup file and finish the parameter setup.
 Start Parameter Setup again and select "Open existing setting".
 Open the saved file and select "On-line".
 Send the file to the VLT frequency converter(s) that is/are to run the automatic motor adaptation programme.
 End Parameter Setup

Start of automatic motor adaptation, AMA:

Start Test-run
 Scan for VLT frequency: converters and select the relevant frequency converter that has been
 prepared for automatic motor adaptation
 Press the "Start" button in Test-run mode Automatic motor adaptation is now in progress

After normal cycle and completion:

Wait until a trip message appears
 Press the [RESET] button in the Test-run mode
 AMA has now been completed and the VET frequency converter is ready for operation.

If Alarm is given, the display shows: ALARM 22

Press the [RESET] button
 Check for possible fault causes in accordance with the alarm message



Control of mechanical brake

For hoisting applications, it is necessary to be able to control an electro-magnetic brake.

For controlling the brake, a relay output (01 or 04) is required. This output must be kept closed (voltagefree) during the time when the VLT frequency converter is not able to 'hold' the motor, e.g. because of too high load. In parameter 323 or 326 (relay outputs 01, 04), select Mechanical brake control [32] or Extended mechanical brake control [34] for applications with an electro-magnetic brake. During start/stop and ramp-down, the output current is monitored. If Mechanical brake control [32] is selected and the current is below the level selected in parameter 223 Warning: Low current, the mechanical brake is closed (voltage-free). As a point of departure, a current can be selected which is approx. 70% of the magnetising current. Parameter 225 Warning: Low frequency states the frequency during ramp-down at which the mechanical brake is to close again.


If *Extended mechanical brake control* [34] is selected the mechanical brake is closed (voltage-free) during start until the output current is above the level selected in parameter 223 *Warning: Low Current*. During stop mechanical brake is released until the frequency is below the level selected in parameter 225 *Warning: Low frequency*.

Notice by *Extended mechanical brake control* [34] that the brake does not close if the output current gets under parameter 223 *Warning: Low current*


If the VLT frequency converter is brought into an alarm condition or an overcurrent or overvoltage situation, the mechanical brake will immediately cut in.




NB! The application shown is only for hoisting without counterweight.









<u>Danfoss</u>

VLT' 5000 Series

Control of mechanical brake

Control of mechanical brake:

Parameter:SettingData value:323Relay 01 or par. 326 relay 04Mechanical brake control[32]323Relay 01 or par. 326 relay 04Extended mechanical brake control[34]223Warning: Low currentapprox. 70% of magnetising current¹⁾225Warning: Low frequency3-5 Hz 2)122Function at stopPre-magnetisation[3]120Start delay time0-1:0.3 sec121Start functionStart frequency/voltage clockwise 3[3]130Start frequencySet to slip frequency131Extra voltage at startSet to rated motor current line (not higher than 160% of line)

- During start and stop, the current limit in parameter 223 decides the switching level.
- This value indicates the frequency during rampdown at which the mechanical brake is to be closed again. This assumes that a stop signal has been given.
- 3) It must be ensured that the motor starts clockwise (hoist), since otherwise the VLT frequency converter may drop the load. Switch U, V, W connections, if required.

Control of mechanical brake



PID for process control Every back

Feedback

The feedback signal must be connected to a terminal on the frequency converter. Use the list below to decide which terminal is to be used and which parameters are to be programmed.

Feedback type	<u>Terminal</u>	Parameters
Pulse	33	307
Voltage	53	308, 309, 310
Current	60	314, 315, 316

Furthermore, the minimum and maximum feedback (parameters 414 and 415) must be set to a value in the process unit that corresponds to the minimum and maximum value on the terminal.

Select process unit in parameter 416.

<u>Reference</u>

A minimum and a maximum reference can be set (204 and 205), which limit the sum of all references. The reference range cannot exceed the feedback range.

If one or several setpoint references are required, the simplest way is to set such reference directly in parameters 215 to 218. Select between the preset references by connecting terminals 16, 17, 29, 32 and/or 33 to terminal 12. Which terminals that are used depends on the choice made in the parameters of the various terminals (parameters 300, 301, 305, 306 and/or 307). Use the table below when selecting preset references.

	Preset ref. msb	<u>Preset</u>
<u>ref. Isb</u>		
Preset ref. 1 (par. 215)	0	0
Preset ref. 2 (par. 216)	0	1
Preset ref. 3 (par. 217)	1	0
Preset ref. 4 (par. 218)	1	1

If an external reference is required, this can either be an analogue or a pulse reference. If current is used as a feedback signal, only voltage can be used as an analogue reference. Use the following list to decide which terminal to use and which parameters to program.

Reference type	<u>Terminal</u>	Parameters
Pulse	17 or 29	301 or 305
Voltage	53 or 54	308, 309, 310 or
		311, 312, 313
Current	60	314, 315, 316

Relative references can be programmed. A relative reference is a percentage value (Y) of the sum of the external references (X). This percentage value is added to the sum of the external references, which produces the active reference (X + XY). See drawing on pages 62 and 63.

If relative references are to be used, parameter 214 is to be set to *Relative* [1]. This makes the preset references relative. Furthermore, *Relative reference* [4] can be programmed on terminal 54 and/or 60. If an external relative reference is selected, the signal on the input will be a percentage value of the full range of the terminal. The relative references are added with signs.



Terminals that are not in use should preferably be set to *No function* [0].

Inverse control

Normal control means that the motor speed increases when the feedback signal is low. If there is a need to use inverse control, in which the speed is reduced when the feedback signal is low, *Inverse* must be programmed in parameter **437**.

Anti Windup

The process regulator comes with the anti windup function in active position. This function ensures that when either a frequency limit or a torque limit is reached, the integrator will be set to a gain that corresponds to the actual frequency. This avoids integrating on an error that cannot in any case be compensated for by means of a speed change. This function can be disabled in parameter 438.

Start-up conditions

In some applications, optimum setting of the process regulator will mean that it takes an excessive time for the desired process value to be reached. In such applications it might be an advantage to fix a motor frequency to which the frequency converter is to bring the motor before the process regulator is activated. This is done by programming a *Process PID* start frequency in parameter 439.

Danfoss

VLT' 5000 Series

PID for process control, cont.

Differentiator gain limit

If there are quick changes in reference or feedback in a given application - which means that the error changes swiftly - the differentiator may soon become too dominant. This is because it reacts to changes in the error. The quicker the error changes, the stronger the differentiator gain is. The differentiator gain can thus be limited to allow setting of the reasonable differentiation time for slow changes and a suitably quick gain for quick changes. This is done in parameter 443, *Process PID Differentiator gain limit.*

Lowpass filter

If there are oscillations of the current/voltage feedback signal, these can be dampened by means of a lowpass filter. Set a suitable lowpass filter time constant. This time constant represents the limitfrequency of the ripples occurring on the feedback signal. If the lowpass filter has been set to 0.1s, the limit frequency will be 10 RAD/sec., corresponding to $(10/2 \times \pi) = 1.6$ Hz. This will mean that all currents/voltages that vary by more than 1.6 oscillations per second will be removed by the filter. In other words, control will only be carried out on a feedback signal that varies by a frequency of less than 1.6 Hz. Choose a suitable time constant in parameter 444, *Process PID Lowpass filter*.

Optimisation of the process regulator

The basic settings have now been made; all that needs to be done is to optimise the proportional gain, the integration time and the differentiation time (parameters 440, 441, 442). In most processes, this can be done by following the guidelines given below.

- 1. Start the motor
- Set parameter 440 (proportional gain) to 0.3 and increase it until the feedback signal again begins to vary continuously. Then reduce the value until the feedback signal has stabilised. Now lower the proportional gain by 40-60%.
- Set parameter 441 (integration time) to 20s and reduce the value until the feedback signal again begins to vary continuously. Increase the integration time until the feedback signal stabilises, followed by an increase of 15-50%.

4. Only use parameter 442 for very fast-acting systems only (differentiation time). The typical value is four times the set integration time. The differentiator should only be used when the setting of the proportional gain and the integration time has been fully optimised.



NB!

If necessary, start/stop can be activated a number of times in order to provoke a variation of the feedback signal.

See also the examples of connection given in the Design Guide.



PID for speed control

<u>Feedback</u>

Use the list below to decide which terminal to use for the feedback signal and which parameters to program.

<u>Feedback type</u>	<u>Terminal</u>	Parameters
Pulse	32	306
Pulse	33	307
Feedback pulse/rev.		329
Voltage	53	308, 309, 310
Current	60	314, 315, 316

Furthermore, the minimum and maximum feedback (parameters 414 and 415) are to be set to values in the process unit that correspond to the actual minimum and maximum process feedback values and units. The minimum feedback cannot be set to a value lower than 0. Choose unit in parameter 416.

<u>Reference</u>

A minimum and a maximum reference can be set (204 and 205) which limit the sum of all references. The reference range cannot exceed the feedback range.

If one or several preset references are required, the simplest way of doing this is by setting such references directly in parameters 215 to 218. Choose between the preset references by connecting terminals 16,17,29,32 and/or 33 to terminal 12. Which of them that are to be used depends on the choice in the parameters of the terminals in question (parameters 300, 301, 305, 306 and/or 307). The table below can be used to select the preset references.

	Preset ref. msb	<u>Preset ref. lsb</u>
Preset ref. 1 (par. 21:	5) O	0
Preset ref. 2 (par. 21)	6) 0	1
Preset ref. 3 (par. 21)	7) 1	0
Preset ref. 4 (par. 21)	3) 1	1

If an external reference is required, this can either by an analogue reference or a pulse reference. If current is used as a feedback signal, voltage can be used as an analogue reference. Use the list below to decide which terminal to use and which parameters to program.

Reference type	<u>Terminal</u>	Parameters
Pulse	17 or 29	301 or 305
Voltage	53 or 54	308, 309, 310 or
		311, 312, 313
Current	60	314, 315, 316

Relative references can be programmed. A relative reference is a percentage value (Y) of the sum of the external references (X). This percentage value is added to the sum of the external references, which produces the active reference (X + XY). See drawing on pages 62 and 63.

If relative references are to be used, parameter 214 is to be set to *Relative* [1]. This makes the preset references relative. Furthermore, Relative reference [4] can be programmed on terminal 54 and/or 60. If an external relative reference is selected, the signal on the input will be a percentage value of the full range of the terminal. The relative references are added with signs.



NB! Terminals that are not in use should preferably be set to *No function* [0].

Differentiator gain limit

If there are quick changes in reference or feedback in a given application - which means that the error changes swiftly - the differentiator may soon become too dominant. This is because it reacts to changes in the error. The quicker the error changes, the stronger the differentiator gain is. The differentiator gain can thus be limited to allow setting of the reasonable differentiation time for slow changes and a suitably quick gain for quick changes. This is done in parameter 420, Speed PID Differentiator gain limit.

Lowpass filter

If are oscillations of the current/voltage on the feedback signal, these can be dampened by means of a lowpass filter. Set a suitable lowpass filter time constant. This time constant represents the limit frequency of the ripples occurring on the feedback signal. If the lowpass filter has been set to 0.1s, the break frequency will be 10 RAD/sec., corresponding to $(10/2 \times \pi) = 1.6$ Hz. This will mean that all currents/ voltages that vary by more than 1.6 oscillations per second will be removed by the filter. In other words, control will only be carried out on a feedback signal that varies by a frequency of less than 1.6 Hz. Choose a suitable time constant in parameter 421, *Speed PID Lowpass filter*.



Quick discharge

This function calls for a VLT of type EB. This function is used for discharging the capacitors in the intermediate circuit after the mains supply has been interrupted. This is a useful function for servicing the VLT frequency converter and/or the motor installation. The motor must be stopped before quick discharge is activated. If the motor acts as a generator, quick discharge is not possible.

The quick discharge function can be selected via parameter 408. The function starts when the intermediate circuit voltage has declined to a given value and the rectifier has stopped.

In order to obtain the possibility of a quick discharge, the VLT frequency converter requires an external 24 V DC supply to terminals 35 and 36, as well as a suitable brake resistor on terminals 81 and 82, see page 43.

Parameter 408 = [1]

For sizing of the discharge resistor for quick discharge, see Brake Instructions MI.50.DX.XX.



NB!

Quick discharge is only possible if the VLT frequency converter has 24 Volts external DC supply and if an external brake/discharge resistor has been connected.




Before servicing the installation (VLT frequency converter + motor), it must be checked that the intermediate circuit voltage is below 60 V DC. This is done by measuring

terminals 88 and 89, load-sharing.



NB!

The power dissipation during quick discharge does not form part of the power monitoring function, parameter 403. When sizing resistors, this fact should be taken into consideration.





Mains failure/quick discharge with mains failure inverse

The first column in the table shows Mains failure, which is selected in parameter 407. If no function is selected, the mains failure procedure will not be carried out. If Controlled ramp-down [1] is selected. the VLT frequency converter will take the motor down to 0 Hz. If Enable [1] has been selected in parameter 408, a quick discharge of the intermediate circuit voltage will be carried out after the motor has stopped.

Using a digital input, it is possible to activate mains failure and/or quick discharge. This is done by selecting Mains failure inverse on one of the control terminals (16, 17, 29, 32, 33). Mains failure inverse is active in the logical '0' situation.



NB!

The VLT frequency converter can be completely damaged if the Quick-discharge function is repeated, using the digital input while mains voltage is on.

Mains failure par. 407	Quick discharge par. 408	Mains failure inverse digital input	Function
No function [0]	Disable [0]	Logical '0'	1
No function [0]	Disable [0]	Logical '1'	2
No function [0]	Enable [1]	Logical '0'	3
No function [0]	Enable [1]	Logical '1'	4
[1]-[4]	Disable [0]	Logical '0'	5
[1]-[4]	Disable [0]	Logical '1'	6
[1]-[4]	Enable]1]	Logical '0'	7
[1]-[4]	Enable [1]	Logical '1'	8

Function no. 1

Mains failure and quick discharge are not active.

Function no. 2

Mains failure and quick discharge are not active.

Function no. 3

The digital input activates the quick discharge function, regardless of the intermediate circuit voltage level and regardless of whether the motor is running.

Function no. 4

Quick discharge is activated when the intermediate circuit voltage has dropped to a given value and the inverters have stopped. See procedure on previous page.

Function no. 5

The digital input activates the mains failure function, regardless of whether the unit receives any supply voltage. See the different functions in parameter 407.

Function no. 6

The mains failure function is activated when the intermediate circuit voltage has dropped to a given value. The selected function in case of mains failure is selected in parameter 407.

Function no. 7

The digital input activates both the quick discharge and the mains failure function, regardless of the intermediate circuit voltage level and regardless of whether the motor is running. First the mains failure function will be active; subsequently there will be a quick discharge.

Function no. 8

Quick discharge and mains failure function are activated when the intermediate circuit level drops to a given level.

First the mains failure function will be active: subsequently there will be a quick discharge.



E Flying start


This function makes it possible to "catch" a motor that is spinning freely and for the VLT to take control of the motor speed. This function can be enabled or disabled via parameter 445.

If *flying start* has been selected, there will be four situations in which the function is activated:

- 1. After a coast has been given via terminal 27.
- 2. After power-up.
- If the VLT frequency converter is in a trip state and a reset signal has been given.
- 4. If the VLT frequency converter releases the motor because of a fault state and the fault disappears before a trip, the VLT frequency converter will catch the motor and go back to the reference.

The search sequence for the spinning motor depends on Rotation, frequency/direction (parameter 200). If only clockwise is selected, the VLT frequency converter will start looking from Maximum frequency (parameter 202) down to 0 Hz. If the VLT frequency converter does not find the spinning motor during the search sequence, it will carry out a DC braking so as to try to bring the speed of the spinning motor down to 0 rpm. This requires that the DC brake is active via parameters 125 and 126. If Both directions is selected, the VLT frequency converter will first find out in which direction the motor rotates and then search for the frequency. If the motor is not found, the system assumes that the motor is at a standstill or is rotating at a low speed, and the VLT frequency converter will start the motor in the normal way after searching.

The VLT frequency converter trips



3 and Flying start is active.

 [rpm]


 Motor

 speed

 fs]


Reset

The VLT frequency converter momentarily releases the motor. *Flying start* is activated and catches the motor again.



4.

2. Flying start is active.





The choice between a normal or a high overload torque characteristic is made in parameter 101.

This is also where to choose between a high/normal constant torque characteristic (CT) or a high/normal VT torque characteristic.

If a *high torque characteristic* is chosen, a rated motor with the VLT frequency converter obtains up to 160% torque for 1 min. in both CT and VT. If a *normal torque characteristic* is chosen, an oversize motor allows up to 110% torque performance for up to 1 min. in both CT and VT. This function is used mainly for pumps and fans, since these applications do not require an overload torque.

The advantage of choosing a normal torque characteristic for an oversize motor is that the VLT frequency converter will be able constantly to yield 100% torque, without derating as a result of a bigger motor.

NB!



This function <u>cannot</u> be chosen for VLT 5001-5006, 200-240 Volts, and VLT 5001-5011, 380-500 Volts.

Internal current regulator

The VLT 5000 features an integral current limit regulator which is activated when the motor current, and thus the torque, is higher than the torque limits set in parameters 221 and 222.

When VLT 5000 Series is at the current limit during motor operation or regenerative operation, the VLT frequency converter will try to get below the preset torque limits as quickly as possible without losing control of the motor.

While the current regulator is active, the VLT frequency converter can *only* be stopped by means of terminal 27 if set to *Coasting stop, inverse* [0] or *Reset and coasting stop, inverse* [1]. A signal on terminals 16-33 will *not* be active until the VLT frequency converter has moved away from the current limit.

Please note that the motor will not use the rampdown time, since terminal 27 must be programmed for *Coasting stop, inverse* [0] or *Reset and coasting stop, inverse* [1].

Programming of Torque limit and stop


In applications with an external electro-mechanical brake, such as hoisting applications, it is possible to stop the VLT frequency converter via a 'standard' stop command, while at the same time activating the external electro-mechanical brake.

The example given below illustrates the programming of VLT frequency converter connections. The external brake can be connected to relay 01 or 04, see Control of mechanical brake on page 66. Program terminal 27 to *Coasting stop, inverse* [0] or *Reset and coasting stop, inverse* [1], as well as terminal 42 to *Torque limit and stop* [27].

Description:

If a stop command is active via terminal 18 and the VLT frequency converter is not at the torque limit, the motor will ramp down to 0 Hz.

If the VLT frequency converter is at the torque limit and a stop command is activated, terminal 42 *Output* (programmed to *Torque limit and stop* [27]) will be activated. The signal to terminal 27 will change from 'logic 1' to 'logic 0' and the motor will start coasting.



- Start/stop via terminal 18. Parameter 302 = *Start* [1].
- Quickstop via terminal 27.
 Parameter 304 = Coasting stop, inverse [0].
- Terminal 42 Output
- Parameter 319 = *Torque limit and stop* [27]. Terminal 01 Relay output
- Parameter 323 = Mechanical brake control [32].

Danfoss

.

VLT¹ 5000 Series

Danfoss

001	Language
	(LANGUAGE)
Valu	e:

★ English (ENGLISH)	[0]
German (DEUTSCH)	[1]
French (FRANCAIS)	[2]
Danish (DANSK)	[3]
Spanish (ESPAÑOL)	[4]
Italian (ITALIANO)	[5]

State when delivered may vary from factory setting.

Function:

The choice in this parameter defines the language to be used on the display.

Description of choice:

There is a choice of *English* [0], *German* [1], *French* [2], *Danish* [3], *Spanish* [4] and *Italian* [5].

002 Local/remote control	
(OPERATION SITE)	
Value:	
★ Remote control (REMOTE)	[0]
Local control (LOCAL)	[1]

Function:

There is a choice of two methods of controlling the VLT frequency converter: *Remote control* [0] and *Local control* [1].

Description of choice:

If *Remote control* [0] is selected, the VLT frequency converter can be controlled via:

- 1. The control terminals or the serial communication port .
- The [START] key However, this cannot overrule Stop commands (also start-disable) entered via the digital inputs or the serial communication port.
- The [STOP], [JOG] and [RESET] keys, provided that these are active (see parameters 014, 015 and 017).

If *Local control* [1] is selected, the VLT frequency converter can be controlled via:

- The [START] key. However, this cannot override Stop commands on the digital terminals (if [2] or [4] has been selected in parameter 013).
- 2. The [STOP], [JOG] and [RESET] keys, provided that these are active (see parameters 014, 015 and 017).

- The [FWD/REV] key, provided that this has been activated in parameter 016 and that in parameter 013 a choice of [1] or [3] has been made.
- Via parameter 003 the local reference can be controlled by means of the "Arrow up" and "Arrow down" keys.
- An external control command that can be connected to terminal 16, 17, 19, 27, 29, 32 or 33. However, [2] or [4] must be selected in parameter 013.

See also the description on page 58.

003 Local reference (LOCAL REFERENCE) Value: Par 013 set for [1] or [2]: $0 - f_{MAX}$ \pm 000.000 Par 013 set for [3] or [4] and par. 203 = [0] set for: Ref_{MIN} - Ref_{MAX} \pm 000.000 Par 013 set for [3] or [4] and par. 203 = [1] set for: $-Ref_{MAX} - + Ref_{MAX}$

Function:

This parameter allows manual setting of the desired reference value (speed or reference for the selected configuration, depending on the choice made in parameter 013).

The unit follows the configuration selected in parameter 100, provided *Process control, closed loop* [3] or *Torque control, open loop* [4] has been selected.

Description of choice:

Local [1] must be selected in parameter 002 for this parameter to be used.

The set value is saved in the case of a voltage dropout, see parameter 019.

In this parameter Data Change Mode is not exited automatically (after time out).

Local reference cannot be set via the serial communication port.

Warning: Since the value set is remembered after the power has been cut, the motor

may start without warning when the power is reinstated; if parameter 019 is changed to *Auto restart,* use *saved ref.* [0].

Dantos

004 Active Setup (ACTIVE SETUP)

Value:

	Factory Setup (FACTORY SETUP)	[0]
*	Setup 1 (SETUP 1)	[1]
	Setup 2 (SETUP 2)	[2]
	Setup 3 (SETUP 3)	[3]
	Setup 4 (SETUP 4)	[4]
	MultiSetup (MULTI SETUP)	[5]

Function:

The choice in this parameter defines the Setup number you want to control the functions of the VLT frequency converter.

All parameters can be programmed in four individual parameter Setups, Setup 1 - Setup 4. In addition, there is a pre-programmed Setup, called Factory Setup, that cannot be modified.

Description of choice:

Factory Setup [0] contains the data set at the works. Can be used as a data source if the other Setups are to be returned to a known state. Parameters 005 and 006 allow copying from one Setup to one or more of the other Setups. *Setups* 1-4 [1]-[4] are four individual Setups that can

be selected as required. *Multi-Setup* [5] is used if remote-mounting switching between Setups is desired. Terminals 16/17/29/32/33 as well as the serial communication port can be used for switching between Setups.

005 Programming Setup (EDIT SETUP)

Value:

	Factory Setup	(FACTORY SETUP)	[0]
	Setup 1 (SETUP	1)	[1]
	Setup 2 (SETUP	2)	[2]
	Setup 3 (SETUP	3)	[3]
	Setup 4 (SETUP	4)	[4]
r	Active Setup (AC	CTIVE SETUP)	[5]

Function:

The choice is of the Setup in which programming (change of data) is to occur during operation (applies both via the control panel and via the serial communication port). It is possible to programme the 4 Setups independently of the Setup selected as the active Setup (selected in parameter 004).

Description of choice:

The Factory Setup [0] contains the data set at the works and can be used as a data source if the other Setups are to be returned to a known state. Setups 1-4 [1]-[4] are individual Setups which can be used as required. They can be programmed freely, regardless of the Setup selected as the active Setup and thus controlling the functions of the VLT frequency converter.



NB!

If a general change of data or a copying to the active Setup is effected, this immediately affects the functioning of the unit.

006 Copying of Setups (SETUP COPY)

Value:

*	No copying (NO COPY)	[0]
	Copy to Setup 1 from # (COPY TO SETUP 1)	[1]
	Copy to Setup 2 from # (COPY TO SETUP 2)	[2]
	Copy to Setup 3 from # (COPY TO SETUP 3)	[3]
	Copy to Setup 4 from # (COPY TO SETUP 4)	[4]
	Copy to Setup all from # (COPY TO ALL)	[5]

= the Setup selected in parameter 005

Function:

A copy is made from the Setup selected in parameter 005 to one of the other Setups or to all the other Setups simultaneously. The setup copying function does not copy parameters 001, 004, 005, 500 and 501.

Copying is only possible in Stop Mode (motor stopped on a Stop command).

Description of choice:

The copying starts when the desired copying function has been entered and confirmed by pressing the [OK] key.

The display indicates when copying is in progress.

Dantoss

007 LCP copy (LCP COPY)

Value:

*	No copying (NO COPY)	[0]
	Upload all parameters (UPLOAD ALL PARAM)	[1]
	Download all parameters (DOWNLOAD ALL)	[2]
	Download power-independent par.	
	(DOWNLOAD SIZE INDEP.)	[3]

Function:

Parameter 007 is used if it is desired to use the integrated copying function of the control panel. The control panel is detachable. You can therefore easily copy parameter value(s) from one VLT to another.

Description of choice:

Select *Upload all parameters* [1] if all parameter values are to be transmitted to the control panel. Select *Download all parameters* [2] if all transmitted parameter values are to be copied to the VLT frequency converter on which the control panel has been mounted.

Select *Download power-independent par.* [3] if only the power-independent parameters are to be downloaded. This is used if downloading to a VLT frequency converter that has a different rated power that the one from where the parameter Setup originates.

Please note that the power-dependent parameters 102-106 must be programmed after copying.

NB!

Uploading/Downloading can only be carried out in the Stop mode.

008 Display scaling of motor frequency (FREQUENCY SCALE)

Value:

0.01 - 100.00

Function:

This parameter chooses the factor to be multiplied by the motor frequency, f_M , for presentation in the display, when parameters 009-012 have been set for Frequency x Scaling [5].

± 1

Description of choice: Set the desired scaling factor.

009 Display line 2 (DISPLAY LINE 2)

Value:

	Reference [%] (REFERENCE [%])	[1]
	Reference [unit] (REFERENCE [UNIT])	[2]
	Feedback [unit] (FEEDBACK [UNIT])	[3]
k	Frequency [Hz] (FREQUENCY [Hz])	[4]
	Frequency x Scaling [-] (FREQUENCY X SCALE) [5]
	Motor current [A] (MOTOR CURRENT [A])	[6]
	Torque [%] (TORQUE [%])	[7]
	Power [kW] (POWER [kW])	[8]
	Power [HP] (POWER [hp] [US])	[9]
	Output energy [kWh] (OUTPUT ENERGY [kWh])	[10]
	Motor voltage [V] (MOTOR VOLTAGE [V])	[11]
	DC link voltage [V] (DC LINK VOLTAGE [V])	[12]
	Thermal load, motor [%] (MOTOR THERMAL [%]	[13]
	Thermal load, VLT [%] (VLT THERMAL [%])	[14]
	Hours run [Hours] (RUNNING HOURS)	[15]
	Digital input (Binary code) (DIGITAL INPUT (BIN))	[16]
	Analogue input 53 [V] (ANALOG INPUT 53 [V])	[17]
	Analogue input 54 [V] (ANALOG INPUT 54 [V])	[18]
	Analogue input 60 [mA]	
	(ANALOG INPUT 60 [mA])	[19]
	Pulse reference [Hz] (PULSE REF. [Hz])	[20]
	External reference [%] (EXTERNAL REF [%])	[21]
	Status word [Hex] (STATUS WORD [HEX])	[22]
	Brake effect/2 min. [KW]	
	(BRAKE ENERGY/2 min)	[23]
	Brake effect/sec. [kW]	
	(BRAKE ENERGY/s)	[24]
	Heat sink temp. [°C] (HEATSINK TEMP [°C])	[25]
	Alarm word [Hex] (ALARM WORD [HEX])	[26]
	Control word [Hex] (CONTROL WORD [HEX])	[27]
	Warning word 1 [Hex]	
	(WARNING WORD 1 [HEX])	[28]
	Extended status word [Hex]	
	(EXT STATUS WORD[HEX])	[29]
	Communication option card warning	
	(COMM OPT WARN [HEX])	[30]

Function:

This parameter allows a choice of the data value to be displayed in line 2 of the display. Parameters 010-012 enable the use of three additional data values to be displayed in line 1.



Description of choice:

Reference [%] corresponds to the total reference (sum of digital/analogue/preset/bus/freeze ref./ catch-up and slow-down).

Reference [unit] gives the status value of terminals 17/ 29/53/54/60 using the unit stated on the basis of configuration in parameter 100 (Hz, Hz and rpm). *Feedback* [unit] gives the status value of terminal 33/ 53/60 using the unit/scale selected in parameter 414, 415 and 416.

Frequency [Hz] gives the motor frequency, i.e. the output frequency from the VLT frequency converter. **Frequency x Scaling** [-] corresponds to the present motor frequency f_M (without resonance dampening) multiplied by a factor (scaling) set in parameter 008. **Motor current** [A] states the phase current of the motor measured as effective value.

Torque [%] gives the current motor load in relation to the rated motor torque.

Power [kW] states the actual power consumed by the motor in kW.

Power [HP] states the actual power consumed by the motor in HP.

Output energy [kWh] states the energy consumed by the motor since the latest reset was made in parameter 618.

Motor voltage [V] states the voltage supplied to the motor.

DC link voltage [V] states the intermediate circuit voltage in the VLT frequency converter.

Thermal load, motor [%] states the calculated/ estimated thermal load on the motor. 100% is the cut-out limit.

Thermal load, VLT [%] states the calculated/estimated thermal load on the VLT frequency converter. 100% is the cut-out limit.

Hours run [Hours] states the number of hours that the motor has run since the latest reset in parameter 619. *Digital input* [Binary code] states the signal states

from the 8 digital terminals (16, 17, 18, 19, 27, 29, 32 and 33) Input 16 corresponds to the bit at the far left. '0' = no signal, '1' = connected signal.

Analogue input 53 [V] states the signal value on terminal 53.

Analogue input 54 [V] states the signal value on terminal 54.

Analogue input 60 [V] states the signal value on terminal 60.

Pulse reference [Hz] states the possible frequency in Hz connected to the terminals 17 or 29.

External reference [%] gives the sum of the external reference as a percentage (the sum of analogue/ pulse/bus).

Status word [Hex] gives the status word sent via the serial communication port in Hex code from the VLT frequency converter.

Brake power/2 min. [KW] states the brake power transferred to an external brake resistor. The mean power is calculated continuously for the latest 120 seconds.

It is assumed that a resistor value has been entered in parameter 401.

Brake power/sec. [kW] states the present brake power transferred to an external brake resistor. Stated as an instantaneous value.

It is assumed that a resistor value has been entered in parameter 401.

Heat sink temp. [°C] states the present heat sink temperature of the VLT frequency converter. The cut-out limit is 90 ± 5 °C; cutting back in occurs at 60 ± 5 °C.

Alarm word [Hex] indicates one or several alarms in a Hex code. See page 160 for further information. *Control word*. [Hex] indicates the control word for the VLT frequency converter. See *Serial communication* in the Design Guide.

Warning word 1. [Hex] indicates one or more warnings in a Hex code. See page 160 for further information.

Extended status word [Hex] indicates one or more status states in a Hex code. See page 160 for further information.

Communication option card warning [Hex] gives a warning word if there is a fault on the communication bus. Is only active if communication options have been installed. Without communication options, 0 Hex is displayed.

010 Display line 1.1 (DISPLAY LINE 1.1) Value:

See parameter 009.

★ Reference [%]

Function:

This parameter enables a choice of the first of three data values to be shown on the display, line 1, position 1.

For display read-outs, press the [DISPLAY/STATUS] button, see also page 50.

Description of choice:

There is a choice of 30 different data values, see parameter 009.

Danfoss

011 Display line 1.2 (DISPLAY LINE 1.2)

Value:

See parameter 009 ★ Motor current [A] Function:

This parameter enables a choice of the second of the three data values to be shown on the display, line 1, position 2.

For Display read-outs, press the [DISPLAY/STATUS] button, see also page 50.

Description of choice:

There is a choice of 30 different data values, see parameter 009.

012 Display line 1.3 (DISPLAY LINE 1.3)

Value: See parameter 009 ★ Power [kW]

Function:

This parameter enables a choice of the third of the three data values to be shown on the display, line 1, position 3.

This is a useful function, i.a. when setting the PID regulator.

Display read-outs are made by pressing the [DISPLAY/STATUS] button, see also page 50.

Description of choice:

There is a choice of 30 different data values, see parameter 009.

013	13 Local Control/Configuration as		
	parameter 100 (LOCAL CTRL/CONFIG.)		
Valu	e'		

٠	dide.	
	Local not active (DISABLE)	[0]
	LCP control and open loop.	
	(LCP CTRL/OPEN LOOP)	[1]
	LCP digital control and open loop.	
	(LCP+DIG CTRL/OP.LOOP)	[2]
	LCP control/as parameter 100.	
	(LCP CTRL/AS P100)	[3]
r	LCP digital control/as parameter 100.	
	(LCP+DIG CTRL/AS P100)	[4]

Function:

This is where the desired function is to be selected if Local control has been chosen in parameter 002. See also the description of parameter 100.

Description of choice:

If *Local not active* [0] is selected, a possible setting of *Local reference via parameter* 003 is blocked. It is only possible to change to *Local not active* [0] from one of the other setting options in parameter 013, when the VLT frequency converter has been set to *Remote control* [0] in parameter 002.

LCP control and open loop [1] is used when the speed is to be adjustable (in Hz) via parameter 003, when the VLT frequency converter has been set to *Local control* [1] in parameter 002.

If parameter 100 has not been set to Speed control open loop [0], switch to Speed control open loop [0].

LCP digital control and open loop [2] functions as *LCP control and open loop* [1], the only difference being that when parameter 002 has been set to *Local operation* [1], the motor is controlled via the digital inputs, according to the list on page 58.

LCP control/as parameter 100 [3] is selected if the reference is to be set via parameter 003.

LCP digital control/as parameter 100 [4] functions as *LCP control/as parameter 100* [3], although, when parameter 002 has been set to *Local operation* [1], the motor may be controlled via the digital inputs in accordance with the list on page 58.



NB!

Shift from Remote control to LCP digital control and open loop:

The present motor frequency and direction of rotation must be maintained. If the present direction of rotation does not correspond to the reversing signal (negative reference), the motor frequency f_M will be set at 0 Hz.

Shift from LCP digital control and open loop to Remote control:

The selected configuration (parameter 100) will be active. Shifts are effected without any abrupt movement.

Shift from Remote control to LCP control/as parameter 100 or LCP digital control/as parameter 100.

The present reference will be maintained. If the reference signal is negative, the local reference will be set at 0.

Shift from LCP control/as parameter 100 or LCP remote control as parameter 100 to Remote control.

The reference will be replaced by the active reference signal from the remote control.

Dantosa

[0] [1]

014 Local stop (LOCAL STOP)

Va	lue:

	Not possible (DISABLE)	[0]
k	Possible (ENABLE)	[1]

Function:

This parameter disables/enables the local stop function in question from the control panel.

This key is used when parameter 002 has been set for Remote control [0] or Local [1].

Description of choice:

If Disable [0] is selected in this parameter, the [STOP] key will be inactive.



NB!

If Enable is selected, the [STOP] key overrules all Start commands.

0	15 Local jog	(LOCAL JOGGING)	
V	alue:		
\star	Not possible ([DISABLE)	[0]
	Possible (ENA	BLE)	[1]

Function:

In this parameter, the jog function can be enabled/ disabled on the control panel.

The key can be used when parameter 002 has been set for Remote control [0] or Local [1].

Description of choice:

If Disable [0] is selected in this parameter, the [JOG] key will be inactive.

016 Local reversing	
(LOCAL REVERSING)	
Value:	
Not possible (DISABLE)	
Possible (ENABLE)	

Function:

In this parameter, the reversing function can be enabled/disabled on the control panel.

This key can only be used if parameter 002 has been set to Local operation [1] and parameter 013 to LCP control with open loop [1] or LCP control as parameter 100 [3].

Description of choice:

If Disable [0] is selected in this parameter, the [FWD/ REV] key will be inactive. See Parameter 200.

017	Local	reset	of	trip	(LOCAL	RESET)

V	alue:	
	Not possible (DISABLE)	[0]
×	Possible (ENABLE)	[1]

Function:

In this parameter, the reset function can be selected/ removed from the keyboard.

This key can be used when parameter 002 has been set for Remote control [0] or Local control [1].

Description of choice:

If Disable [0] is selected in this parameter, the [RESET] key will be inactive.



NB!

Only select Disable [0] if an external reset signal has been connected via the digital inputs.

018 Lock for data change	
(DATA CHANGE LOCK)	
Value:	
★ Not locked (NOT LOCKED)	[O]
Locked (LOCKED)	[1]
From entire and	

Function:

In this parameter, the software can "lock" the control, which means that data changes cannot be made via LCP (however, this is still possible via the serial communication port).

Description of choice:

If Locked [1] is selected, data changes cannot be made.

Danfoss

019 Operating state at power up, local control (POWER UP ACTION) Value: Auto restart, use saved ref (AUTO RESTART)

	Auto restart, use saved ref.(AUTO RESTART)	[0]
★	Forced stop, use saved ref. (LOCAL=STOP)	[1]
	Forced stop, set ref. to 0	
	(LOCAL=STOP, REF=0)	[2]

Function:

Setting of the desired operating mode when the mains voltage is reconnected.

This function can only be active in connection with *Local control* [1] in parameter 002.

Description of choice:

Auto restart, use saved ref. [0] is selected if the unit is to start up with the same local reference (set in parameter 003) and the same start/stop conditions (given via the [START/STOP] keys) that the frequency converter had before it was switched off. *Forced stop, use saved ref.* [1] is used if the unit is to remain stopped when the mains voltage is connected, until the [START] key is pressed. After the start command, the local reference used is set in parameter 003.

Forced stop, set ref. to 0 [2] is selected if the unit is to remain stopped when the mains voltage is connected. Local reference (parameter 003) is reset.

NB!

In remote controlled operation (parameter 002), the start/stop condition at power up will depend on the external control signals. If *Pulse start* [2] is selected in parameter 302, the motor will remain stopped at power-up.

100 Configuration

(CONFIG. MODE)

Value:
★ Speed control, open loop
(SPEED OPEN LOOP)
Speed control, closed loop
(SPEED CLOSED LOOP)
Process control, closed loop
(PROCESS CLOSED LOOP)
Torque control, open loop
(TORQUE OPEN LOOP)
Torque control, speed feedback
(TORQUE CONTROL SPEED)

Function:

This parameter is used for selecting the configuration to which the VLT frequency converter is to be adapted. This makes adaptation to a given application simple, because the parameters that are not used in the given configuration are covered up (not active). By changing between the different application configurations, bumpless transfer (frequency only) is ensured.

Description of choice:

If *Speed control, open loop* [0] is selected, a normal speed control (without feedback signal) is obtained, but with automatic slip compensation, ensuring a nearly constant speed at varying loads. Compensations are active, but may be disabled as required in parameter group 100.

If *Speed control, closed loop* [1] is selected, a full holding torque is obtained at 0 rpm, in addition to increased speed accuracy. A feedback signal must be provided and the PID controller must be set. (See also connection examples in the Design Guide).

If *Process control, closed loop* [3] is selected, the internal process regulator will be activated, thereby enabling accurate control of a process with respect to a given process signal. The process signal can be set using the actual process unit or as a percentage. A feedback signal must be supplied from the process, and the process setpoint must be adjusted (See also connection examples in the Design Guide).

If *Torque control, open loop* [4] is selected, the speed is regulated and the torque is kept constant. This is done without a feedback signal, since VLT 5000 accurately calculates the torque on the basis of the current measurement (See also connection examples in the Design Guide).

If *Torque control, speed feedback* [5] is selected, an encoder speed feedback signal must be connected to the digital terminals 32/33.

Parameter 205 *Maximum reference* and parameter 415 *Maximum feedback* must be adapted to the application if [1], [3], [4] or [5] is selected.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

[0]

[1]

[3]

[4]

[5]

Dantos

101 Torque characteristics (TORQUE CHARACT)

Value:

v	aiue.	
	High overload torque (150/160%) - one size do	wn
\star	High-constant torque	
	(H-CONSTANT TORQUE)	[1]
	High-variable torque low (H-VAR.TORQ.: LOW) [2]
	High-variable torque medium	
	(H-VAR.TORQ.: MEDIUM)	[3]
	High-variable torque high	
	(H-VAR.TORQ.: HIGH)	[4]
	High-special motor characteristics	
	(H-SPEC MOTOR CHARACT)	[5]
	High-variable torque with low starting torque	
	(H-VT LOW W. CT-START)	[6]
	High-variable torque with medium starting torq	ue
	(H-VT MED W. CT-START)	[7]
	High-variable torque with high starting torque	
	(H-VT HIGH W. CT-START)	[8]
	Normal overload torgue (110%)	
	Normal-constant torque	
	(N-CONSTANT TORQUE)	[11]
	Normal-variable torque low	
	(N-VAR.TORQ.: LOW)	[12]
	Normal-variable torque medium	
	(N-VAR.TORQ.: MEDIUM)	[13]
	Normal-variable torque high	
	(N-VAR.TORQ.: HIGH)	[14]
	Normal-special motor characteristics	
	(N-SPEC MOTOR CHARACT)	[15]
	Normal-variable torque with low constant	
	starting torque (N-VT LOW W. CT-START)	[16]
	Normal-variable torque with medium constant	
	starting torque (N-VT MED W. CT-START)	[17]
	Normal-variable torque with high constant	
	starting torque (N-VT HIGH W. CT-START)	[18]

Function:

In this parameter, the principle for adjusting the U/f characteristics of the VLT frequency converter to the torque characteristics of the load is selected. By changing between the different torque characteristics, bumpless transfer (voltage only) is ensured.

Description of choice:



NB! For VLT 5001-5006, 200-240 V, and VLT 5001-5011, 380-500 V, it is only possible to choose torque characteristics from [1] to [8].


If a high torque characteristic [1]-[5] is selected, the VLT frequency converter is able to provide 160% torque. If a normal torque characteristic [11]-[15] is selected, the VLT frequency converter is able to provide 110% torque. The normal mode is used for oversize motors. See description on page 74.

Please note that the torque can be limited in parameter 221.

If Constant torque is selected, a load-dependent U/f characteristic is obtained in which the output voltage is increased in the case of an increasing load (current) so as to maintain constant magnetisation of the motor

Select Variable torque low, Variable torque medium or Variable torque high if the load is variable (centrifugal pumps, fans).

Select High-variable torque with low [6], medium [7] or high [8] starting torque if a higher breakaway torque is required than that obtainable with the three first-mentioned characteristics, see fig. below.



Choose the torque characteristics giving the most reliable operation, the lowest possible energy consumption and the lowest acoustic noise. Select Special motor characteristics if a special U/f setting is required to match the motor in question. Set the break points in parameters 422-432.



NB! Slip compensation is not active if a variable torque or special motor characteristics are used. Load & Motor

Danfoss

It is important for the set values to correspond to the motor coupling (star or delta) 10

102 Motor power (MOTOR POWER)	
Value:	
0.18 kW (0.18 KW)	[18]
0.25 kW (0.25 KW)	[25]
0.37 kW (0.37 KW)	[37]
0.55 kW (0.55 KW)	[55]
0.75 kW (0.75 KW)	[75]
1.1 kW (1.10 KW)	[110]
1.5 kW (1.50 KW)	[150]
2.2 kW (2.20 KW)	[220]
3 kW (3.00 KW)	[300]
4 kW (4.00 KW)	[400]
5.5 kW (5.50 KW)	[550]
7.5 kW (7.50 KW)	[750]
11 kW (11.00 KW)	[1100]
15 kW (15.00 KW)	[1500]
18.5 kW (18.50 KW)	[1850]
22 kW (22.00 KW)	[2200]
30 kW (30.00 KW)	[3000]
37 kW (37.00 KW)	[3700]
45 kW (45.00 KW)	[4500]
55 kW (55.00 KW)	[5500]
75 kW (75.00 KW)	[7500]
90 kW (90.00 KW)	[9000]
110 kW (110.00 KW)	[11000]
132 kW (132.00 KW)	[13200]
160 kW (160.00 KW)	[16000]
200 kW (200.00 KW)	[20000]
250 kW (250.00 KW)	[25000]
280 kW (280.00 KW)	[28000]
315 kW (315.00 KW)	[31500]
355 kW (355.00 KW)	[35500]
400 kW (400.00 KW)	[40000]
450 kW (450.00 KW)	[45000]
500 kW (500.00 KW)	[50000]

★ Depends on the unit

Function:

This is where to select the kW value that corresponds to the rated power of the motor. At the works, a rated kW value has been selected that depends on the type of unit.

Description of choice:

Select a value that equals the nameplate data on the motor. There are 4 possible undersizes or 1 oversize in comparison with the factory setting. Also, alternatively it is possible to set the value for motor power as an infinitely variable value, see the procedure on page 53.

The set value automatically changes the values of the motor parameters in parameter 108-118.



NB! If the setting in parameter 102-109 is changed, the parameters 110-118 will return to factory setting.

103 Motor	voltage	(MOTOR	VOLTAGE)	
Value:				
200 V				[200]
208 V				[208]
220 V				[220]
230 V				[230]
240 V				[240]
<u>- 380 v</u>				[380]
400 V				[400]
415 V				[415]
440 V				[440]
460 V				[460]
480 V				[480]
500 V				[500]

★ Depends on the unit

Function:

Select a value that equals the nameplate data on the motor.



NB!

The motor will always see the peak voltage, corresponding to the connected supply voltage, in case of regenerative operation, the voltage can be higher.

5000 Series

Description of choice:

Select a value that equals the nameplate data on the motor, regardless of the mains voltage of the VLT frequency converter.

Furthermore, alternatively it is possible to set the value of the motor voltage infinitely variably, see also the procedure on page 53.

The value set automatically changes values for the motor parameters in parameters 108-118.

For 87 Hz operation with 230/400 V motors, set the nameplate data for 230 V. Adapt parameter 202 Output frequency high limit and parameter 205 Maximum reference to the 87 Hz application.

NB!

If a delta connection is used, the rated motor 1115 frequency for the delta connection must be selected.



NB!

If the setting in parameter 102-109 is changed, the parameters 110-118 will return to factory setting.

104 Motor frequency	
(MOTOR FREQUENCY)	;
Value:	
★ 50 Hz (50 HZ)	[50]
60 Hz (60 HZ)	[60]

Max. motor frequency 1000 Hz.

Function: This is where the rated motor frequency $f_{M,N}$ is selected (nameplate data).

Description of choice:

Select a value that equals the nameplate data on the motor.

Alternatively it is also possible to set the value for motor frequency infinitely variably, see procedure on page 53.

If a value different from 50 Hz or 60 Hz is selected, it is necessary to correct parameters 108 and 109.

For 87 Hz operation with 230/400 V motors, set the nameplate data for 230 V. Adapt parameter 202 Output frequency high limit and parameter 205 Maximum reference to the 87 Hz application.



NB!

If a delta connection is used, the rated motor frequency for the delta connected must be selected.



If the setting in parameter 102-109 is

changed, the parameters 110-118 will return to factory setting.

105 Motor current (MOTOR CL	JRRENT)
Value:	
0.01 - I _{VLT,MAX}	[0.01 - XXX.X]

★ Depends on the choice of motor.

Function The rated motor current $I_{M,N}$ forms part of the VLT frequency converter calculations i.a. of torque and motor thermal protection.

Description of choice: Select a value that equals the nameplate data on the motor.

Enter the value in Ampere.



NB!

It is important to enter the correct value, since this forms part of the VVCplus control feature.

NB!

If the setting in parameter 102-109 is changed, the parameters 110-118 will return to factory setting.

Dantos

5000 Series VLT'

106 Rated motor speed (MOTOR NOM. SPEED) Value:

100 - 60000 rpm

[100 - 60000]

★ Depends on the choice of motor.

Function:

This is where the value is selected that corresponds to the rated motor speed n_{M.N}, which can be seen from the nameplate data.

Description of choice:

The rated motor speed n_{MN} is used i.a. for calculating the optimal slip compensation.



NB!

It is important to enter the correct value, since this forms part of the VVCphus control feature.

The max, value equals f_{M.N} x 60. Set f_{M,N} in parameter 104.



NB!

If the setting in parameter 102-109 is changed, the parameters 110-118 will return to factory setting.

107 Automatic motor adaptation, AMA (AUTO MOTOR ADAPT)

Value:

\star	Adaptation off (OFF)	[0]
	Adaptation on, R _s and X _s (ENABLE (RS,XS))	[1]
	Adaptation on, R _s (ENABLE (RS))	[2]

Function:

If this function is used, the VLT frequency converter automatically sets the necessary control parameters (parameters 108/109) with the motor stationary. Automatic motor adaptation ensures optimum use of the motor.

For the best possible adaptation of the VLT frequency converter, it is recommended to run AMA on a cold motor.

The AMA function is activated by pressing the [START] key after selecting [1] or [2].

See also the description given of automatic motor adaptation on page 64.

Page 65 shows how automatic motor adaptation can be activated by means of VLT Software Dialog. After a normal sequence, the display will read "ALARM 21". Press the [STOP/RESET] key. The VLT frequency converter is now ready for operation.

Description of choice:

Select Enable, Rs and Xs [1] if the VLT frequency converter is to be able to carry out automatic motor adaptation of both the stator resistance Rs and the stator reactance X_s.

Select Optimisation on, R_s [2] if a reduced test is to be carried out, in which only the ohmic resistance in the system is determined.



It is important to set motor parameters 102-106 correctly, since these form part of the AMA algorithm. In most applications, correct entering of motor parameters 102-106 is sufficient. For optimum dynamic motor adaptation, an AMA must be carried out.

Motor adaptation may take up to 10 minutes, depending on the output of the motor in question.



NB!

There must not be any externally generating torque during automatic motor adaptation.



NB!

If the setting in parameter 102-109 is changed, the parameters 110-118 will return to factory setting.

Dantos

Normally, this parameter is not to be set if the nameplate data have been entered.

108 Stator resistor (STATOR RESIST) Value:

★ Depends on the choice of motor

Function:

After setting motor data in parameters 102-106, a number of adjustments of various parameters are made automatically, including the stator resistance R_s. A manually entered R_s must apply to a cold motor. The shaft performance can be improved by fine-tuning R_s and X_s, see procedure below.

Description of choice:

Rs can be set as follows:

- Automatic motor adaptation, where the VLT frequency converter measures on the motor to determine the value. All compensations are reset to 100%.
- 2. The values are stated by the motor supplier.
- 3. The values are obtained by means of manual measurements:
 - R_s can be calculated by measuring the resistance R_{PHASE-to-PHASE} between two phase terminals.

If $R_{PHASE-to-PHASE}$ is lower than 1-2 ohm (typically motors > 4-5.5 kW, 400 V), a special ohm-meter should be used (Thomson bridge or similar). $R_s = 0.5 \times R_{PHASE-to-PHASE}$

 The factory settings of R_s, selected by the VLT frequency converter itself on the basis of the motor nameplate data, are used.

NB!

If the setting in parameter 102-109 is changed, the parameters 110-118 will return to factory setting.

Normally, this parameter is not to be set if the nameplate data have been entered.

109 Stator reactance

(STATOR REACT.)

Value:

★ depends on the choice of motor

Function:

After setting motor data in parameters 102-106, a number of adjustments of various parameters are made automatically, including the stator resistance X_s . The shaft performance can be improved by fine-tuning R_s and X_s , see procedure below.

Description of choice:

- X_s can be set as follows:
- Automatic motor adaptation, where the VLT frequency converter measures on the motor to determine the value. All compensations are reset to 100%.
- 2. The values are stated by the motor supplier.
- 3. These values are obtained by means of manual measurements:
 - X_s can be calculated by connecting a motor to mains and measuring the phase-to-phase voltage U_L as well as the idling current I_e. Alternatively, these values can be recorded during operation in idle running state at the rated motor frequency f_{M,N}, slip compensation (par. 115) = 0% and load compensation at high speed (par. 114) = 100%.

$$X_{s} = \frac{U_{L}}{\sqrt{3} \times I_{\varphi}}$$

 The factory settings of X_s, selected by the VLT frequency converter itself on the basis of the motor nameplate data, are used.



NB!

If the setting in parameter 102-109 is changed, the parameters 110-118 will return to factory setting.

Dantoss

Normally, this parameter is not to be set if the
nameplate data have been entered.

3	IU	IVIOLOI	magneuzing, v	ιμι
		(MOT	MACNETIZING	

Value:


0 - 300 %

★ 100 %

Function:

This parameter can be used if a different thermal load on the motor is desired when running at low speed.

This parameter is used in connection with parameter 111.



Description of choice:

Enter a value stated as a percentage of the rated magnetizing current.

Too low setting may lead to a reduced torque on the motor shaft.

Normally, this parameter is not to be set if the nameplate data have been entered.

	,
111 Min. frequency r	normal magnetizing
(MIN FR NORM	MAGN)
Value:	
0.1 - 10.0 Hz	★ 1.0 Hz

0.1 - 10.0 Hz

Function:

This parameter is used in connection with parameter 110. See drawing in parameter 110.

Description of choice:

Set the required frequency (for normal magnetizing current). If the frequency is set lower than the motor slip frequency, parameters 110 and 111 are of no significance.

Normally, this parameter is not to be set if the

nameplate data have been entered.

113 Load compensatio	n at low speed	
(LO SPD LOAD CO	OMP)	
Value:		
0 - 300 %	★ 100 %	


Function:

This parameter enables compensation of voltage in relation to load when the motor is running at low speed.

Description of choice:

Optimum U/f characteristics are obtained, i.e. compensation for the load at low speed. The frequency range within which Load compensation at low speed is active, depends on the motor size. This function is active for:





Dantosa

Normally, this parameter is not to be set if the nameplate data have been entered.

114	Load compensation	on at high speed
	(HI SPD LOAD CO	MP)
Value	e:	
0 -	300 %	★ 100 %

Function:

This parameter enables compensation of voltage in relation to load when the motor is running at high speed.

Description of choice:

In Load compensation at high speed it is possible to compensate for the load from the frequency where Load compensation at low speed stopped working to max. frequency.

This function is active for:

Motor size	<u>Change-over</u>
0.5 kW - 7.5 kW	> 10 Hz
11 kW - 37 kW	> 5 Hz
45 kW - 355 kW	> 3-4 Hz

115 Slip compensation	
(SLIP COMPENSAT.)	
Value:	
-500 - 500 %	★ 100 %

Function:

Slip compensation is calculated automatically, i.e. on the basis of the rated motor speed n_{M.N}.

In parameter 115, slip compensation can be adjusted in detail, which compensates for tolerances in the value of n_{M.N}.

This function is not active together with Variable torque (parameter 101 - variable torque graphs), Torque control, Speed feedback and Special motor characteristics.

Description of choice:

Enter a %-value of the rated motor frequency (parameter 104).

Normally, this parameter is not to be set if the nameplate data have been entered.

116	Slip compensation time	constant
	(SLIP TIME CONST.)	
Value	e:	
0.0	05 - 5.00 sec.	★ 0.50 sec.

0.05 - 5.00 sec.

Function:

This parameter determines the slip compensation reaction speed.

Description of choice:

A high value results in slow reaction. Conversely, a low value results in quick reaction.

If low-frequency resonance problems are encountered, the time set must be longer.

Normally, this parameter is not to be set if the nameplate data have been entered.

1 17	Resonance dampening	
	(RESONANCE DAMP.)	
Valu	e:	
0.	- 500 %	★ 100 %

Function:

High-frequency resonance problems can be eliminated by setting parameters 117 and 118.

Description of choice:

For less resonance oscillation, the value of parameter 118 must be increased.

Danfords

Normally, this parameter is not to be set if the nameplate data have been entered.

118 Resonance dampening time constant (DAMP.TIME CONST.)

Value:

5 - 50 ms

★ 5 ms

Function:

High-frequency resonance problems can be eliminated by setting parameters 117 and 118.

Description of choice:

Choose the time constant that provides the best dampening.

119 High starting torque (HIGH START TORQ.)

Value:

0.0 - 0.5 sec. ★ 0.0 sec.

Function:

In order to secure a high starting torque, approx. $2 \times I_{VLTN}$ for max. 0.5 sec. is allowed. However, the current is limited by the protection limit of the VLT frequency converter (inverter).

Description of choice:

Set the necessary time in which a high starting torque is desired.

120 Start delay (START DELAY)

Value:

0.0 - 10.0 sec.

★ 0.0 sec.

Function:

This parameter enables a delay of the starting time. The VLT frequency converter begins with the start function selected in parameter 121.

Description of choice: Set the desired time until acceleration is to begin.

121 Start function (START FUNCTION)

Value:

4

	DC hold in start delay time	
	(DC HOLD/DELAY TIME)	[0]
	DC brake in start delay time	
	(DC BRAKE/DELAY TIME)	[1]
ł	Coasting in start delay time (COAST/DELAY TIME)	[2]
	Start frequency/voltage clockwise.	
	(CLOCKWISE OPERATION)	[3]
	Start frequency/voltage in reference direction	
	(HORIZONTAL OPERATION)	[4]
	VVCPLUS clockwise (VVC+ CLOCKWISE)	[5]

Function:

This is where the desired state during start delay (parameter 120) is selected.

Description of choice:

Select *DC* hold in the start delay time [0] so as to energize the motor with a DC holding current (parameter 124) in the start delay time.

Select *DC* brake in the start delay time [1] so as to energize the motor with a DC braking current (parameter 125) in the start delay time.

Select *Coasting in the start delay time* [2] and the motor will not be controlled by the VLT frequency converter during the start delay time (inverter off).

Start frequency/voltage clockwise [3] and VVC^{PLUS} clockwise [5] is typically used in hoisting applications. Start frequency/voltage in reference direction [4] is used especially in applications with counterweight.

Select *Start frequency/voltage clockwise* [3] so as to have the function described in parameter 130 and 131 in the start delay time.

The output frequency will equal the setting of the start frequency in parameter 130, and the output voltage will equal the setting of the start voltage in parameter 131. Regardless of the value assumed by the reference signal, the output frequency will equal the setting of the start frequency in parameter 130 and the output voltage will correspond to the setting of the start voltage in parameter 131.

This functionality is used typically in hoisting applications.

This is used especially in applications with a cone armature motor, where the start is to be clockwise, followed by rotation in the reference direction.



Select *Start frequency/voltage in reference direction* [4] in order to obtain the function described in parameters 130 and 131 during the start delay time. The motor will always rotate in the reference direction. If the reference signal equals zero (0) parameter 130 *Start frequency* will be ignored and the output frequency will equal zero (0). The output voltage will correspond to the setting of the start voltage in parameter 131 *Start voltage*.

Select *VVC^{PLUS} clockwise* [5] so as to have only the function described in parameter 130 *Start frequency* in the start delay time. The start voltage will be calculated automatic. Notice that this function only uses the start frequency in the start delay time. Regardless of the value assumed by the reference signal, the output frequency will equal the setting of the start frequency in parameter 130.

122 Function at stop (FUNCTION AT STOP) Value:

•	2,00	
★	Coasting (COAST)	[0]
	DC hold (DC-HOLD)	[1]
	Motor check (MOTOR CHECK)	[2]
	Pre-magnetizing (PREMAGNETIZING)	[3]

Function:

Here it is possible to select the function of the VLT frequency converter after a stop command or when the frequency has been ramped down to 0 Hz. See parameter 123 with respect to activation of this parameter regardless of whether the stop command is active.

Description of choice:

Select *Coasting* [0] if the VLT frequency converter is to 'let go' of the motor (inverter closed).

Select *DC hold* [1] when a DC holding current set in parameter 124 is to be activated.

Select *Motor check* [2] if the VLT frequency converter is to check whether or not a motor has been connected.

Select *Pre-magnetizing* [3]. The magnetic field is built up in the motor while it remains stopped. This ensures that the motor can produce torque as quickly as possible on starting.

123	Min. frequency for activating
	function at stop
	(MIN.F. FUNC.STOP)
Valu	e:
0.0) - 10.0 Hz ★ 0.0 Hz

Function:

This parameter sets the frequency at which the function selected in parameter 122 is to be activated.

Description of choice: Enter the desired frequency.

124 DC holding current	
(DC-HOLD CURRENT)	
Value:	
0 (OFF) - ^I VILN x 100 %	★ 50 %

The maximum value depends on the rated motor current.

If the DC holding current is active, the VLT frequency converter has a switching frequency of 4 kHz.


Function:

This parameter is used to uphold the motor function (holding torque) or to pre-heat the motor.

Description of choice:

This parameter can only be used if *DC* hold [1] has been selected in parameter 121 or 122. Set it as a percentage value in relation to the rated motor current $I_{M,N}$ set in parameter 105.

100% DC holding current corresponds to I_{M.N}.



125 DC braking current	
(DC BRAKE CURRENT)	
Value:	
0 (OFF) - ^{- I} VILIMAX I _{M.N} x 100 %	★ 50 %
The maximum value depends on the rate	ed motor

current.

If the DC braking current is active, the VLT frequency converter has a switching frequency of 4 kHz.

Danfoss


Function:

This parameter is used for setting the DC brake current that is activated upon a stop when the DC brake frequency set in parameter 127 has been reached, or if the DC brake inverse is active via digital terminal 27 or via a serial communication port. The DC braking current will be active for the duration of the DC braking time set in parameter 126.

Description of choice:

To be set as a percentage value of the rated motor current $I_{M,N}$ set in parameter 105.

100% DC braking current corresponds to I_{M.N}.



126 DC braking time (DC BRAKING TIME)

Value:

0.0 (OFF) - 60.0 sec.

Function:

This parameter is for setting the DC braking time for which the DC braking current (parameter 125) is to be active.

★ 10.0 sec.

Description of choice: Set the desired time.

127 DC brake cut-in frequency (DC BRAKE CUT-IN)

Value:

0.0 - parameter 202 * 0.0 Hz (OFF)

Function:

This parameter is for setting the DC brake cut-in frequency at which the DC braking current (parameter 125) is to be active, in connection with a stop command.

Description of choice: Set the desired frequency.

128 Motor thermal protection

(MOT.THERM PROTEC)

Value:

★	No protection (NO PROTECTION)	[0]
	Thermistor warning (THERMISTOR WARN)	[1]
	Thermistor trip (THERMISTOR TRIP)	[2]
	ETR Warning 1 (ETR WARNING1)	[3]
	ETR Trip 1 (ETR TRIP1)	[4]
	ETR Warning 2 (ETR WARNING2)	[5]
	ETR Trip 2 (ETR TRIP2)	[6]
	ETR Warning 3 (ETR WARNING3)	[7]
	ETR Trip 3 (ETR TRIP3)	[8]
	ETR Warning 4 (ETR WARNING 4)	[9]
	ETR Trip 4 (ETR TRIP4)	[10]

Function:

The VLT frequency converter is able to monitor the motor temperature in two different ways:

- Via a thermistor sensor connected to one of the analogue inputs, terminals 53 and 54 (parameters 308 and 311).
- Calculation of the thermal load, based on the current load and the time. This is compared with the rated motor current I_{M.N} and the rated motor frequency f_{M.N}. The calculations made take into account the need for a lower load at lower speeds because of less cooling from the fan.

ETR functions 1-4 do not start calculating the load until there is a switch-over to the Setup in which they were selected. This enables the use of the ETR function, even where two or several motors alternate. For the North American market: The ETR functions provide class 20 motor overload protection in accordance with NEC.

Description of choice:

Select *No protection* if no warning or tripping is required when the motor is overloaded. Select *Thermistor warning* if a warning is desired when the connected thermistor - and thus the motor - gets too hot.


Select *Thermistor trip* if cutting out (trip) is desired when the connected thermistor - and thus the motor - overheats.



Description of choice, cont.:

Select *ETR Warning 1-4*, if a warning is to come up on the display when the motor is overloaded according to the calculations.

Select *ETR Trip 1-4* if tripping is desired when the motor is overloaded according to the calculations. The VLT frequency converter can also be programmed to give off a warning signal via one of the digital outputs, in which case the signal is given both for warning and for trip (thermal warning).



129 External motor fan (MOTOR EXTERN FAN) Value:


×	No	(NO)	[O]
	Yes	(YES)	[1]

Function:

This parameter makes it possible to tell the VLT frequency converter whether the motor has an external separately supplied fan on the motor (external ventilation), indicating that derating at low speed is unnecessary.

Description of choice:

If Yes [1] is selected, the graph in the drawing below is followed if the motor frequency is lower. If the motor frequency is higher, the time will still derate as if no fan had been installed.



130 Start frequency (START FREQUENCY)

Value:

0.0 - 10.0 Hz

Function:

This parameter allows setting of the output frequency at which the motor is to start.

★ 0.0 Hz

★ 0.0 Volt

The output frequency 'leaps' to the set value. This parameter can be used e.g. for hoist applications (cone rotor motors).

Description of choice:

Set the desired start frequency.

It is assumed that the start function in parameter 121 has been set to [3] or [4] and that a start delay time has been set in parameter 120; also; a reference signal must be present.

131 Initial voltage (INITIAL VOLTAGE)

Value:		
0.0 -	parameter	103

Function:

Some motors, such as cone rotor motors, need extra voltage/starting frequency (boost) when starting, so as to disengage the mechanical brake. For this purpose use parameters 130/131.

Description of choice:

Set the desired value required to disengage the mechanical brake.

It is assumed that the start function in parameter 121 has been set to [3] or [4] and that a start delay time has been set in parameter 120; also, a reference signal must be present.

Dantos

200	Output frequency range/directio
	(OUT FREQ RNG/ROT)
Valu	e:

×	Only clockwise, 0-132 Hz	
	(132 Hz CLOCK WISE)	[0]
	Both directions, 0-132 Hz	
	(132 Hz BOTH DIRECT)	[1]
	Only clockwise, 0-1000 Hz	
	(1000 Hz CLOCK WISE)	[2]
	Both directions, 0-1000 Hz	
	(1000 Hz BOTH DIRECT)	[3]

Function:

This parameter guarantees protection against unwanted reversing. Furthermore, the maximum output frequency can be selected that is to apply, regardless of the settings of other parameters.

NB!

The output frequency of the VLT frequency converter can never assume a value higher than 1/10 of the switching frequency, see parameter 411.

Is <u>not</u> to be used together with *Process control,* closed loop (parameter 100).


Description of choice:

Select the desired direction as well as output frequency

Note that if *Clockwise*, *0-132 Hz* [0] or *Clockwise*, *0-1000 Hz* [2] is selected, the output frequency will be limited to the range $f_{MIN} - f_{MAX}$.

If Both directions, 0-132 Hz [1] or Both directions, 0-1000 Hz [3] is selected, the output frequency will be limited to the range $\pm f_{MAX}$ (the minimum frequency is of no significance).

Example:



Parameter 200 Output frequency range/direction = both directions.

VLT' 5000 Series

201	Output frequency low I	imit (F _{MIN})
	(OUT FREQ LOW LIM)	
Valu	e:	
0.0) - f _{MAX}	★ 0.0 Hz

Function:

In this parameter, a minimum motor frequency limit can be selected that corresponds to the minimum frequency at which the motor is to run.

The minimum frequency can never be higher than the maximum frequency, $f_{\text{MAX}}.$

If *Both directions* has been selected in parameter 200, the minimum frequency is of no significance.

Description of choice:

A value from 0.0 Hz to the max. frequency selected in parameter 202 (f_{MAX}) can be chosen.

202 Output frequency high limit (F_{MAX}) (OUT FREQ HI LIM) Value:

f_{MIN} - 132/1000 Hz (parameter 200) ★ depends on unit

Function:

In this parameter, a maximum motor frequency can be selected that corresponds to the highest frequency at which the motor is to run. The factory setting is 132 Hz for VLT 5001-5052 380-500 V and 5001-5027 200-240 V. For VLT 5060-5250 380-500 V and 5032-5052 200-240 V the factory setting is 66 Hz.

See also parameter 205.



NB!

The output frequency of the VLT frequency converter can never assume a value higher than 1/10 of the switching frequency.

Description of choice:

A value from f_{MIN} to the choice made in parameter 200 can be selected.

NB!



If the maximum motor frequency is set at more than 500 Hz, parameter 446 must be set at *60° AVM* [0] switching pattern.

★ 50.000

203	Reference/feedback area
	(REF/FEEDB. RANGE)
1/011	A :

value.	
🛨 Min - Max (MIN - MAX)	·[0]
- Max - + Max (-MAX-+MAX)	[1]

Function:

This parameter decides whether the reference signal and the feedback signal are to be positive or can be both positive and negative.

The minimum limit may be a negative value, unless Speed control, closed loop has been selected (parameter 100).

Choose Min - Max [0] if Process control, closed loop has been selected in parameter 100.

Description of choice:

Choose the desired range. See drawing on page 63.

204 Minimum reference (MIN. REFERENCE)

Value:

-100,000.000 - Ref_{MAX}

★ 0.000

Depends on parameter 100.

Function:

The Minimum reference gives the minimum value that can be assumed by the sum of all references. Minimum reference is only active if Min - Max [0] has been set in parameter 203; however, it is always active in Process control, closed loop (parameter 100).

Description of choice:

Is only active when parameter 203 has been set to Min - Max [0]. Set the desired value. The unit follows the choice of configuration in parameter 100. Speed control, open loop: Hz Speed control, closed loop: rpm Torque control, open loop: Nm Torque control, speed feedback: Nm Process control, closed loop: Process units

(par. 416)

Special motor characteristics, activated in parameter 101, use the unit selected in parameter 100.

See drawing on page 63.

205 Maximum reference (MAX. REFERENCE)

Value: Ref_{MIN} - 100,000.000

Function:

The Maximum reference gives the highest value that can be assumed by the sum of all references. If closed loop has been selected in parameter 100, the maximum reference cannot be set higher than the maximum feedback (parameter 415).

Description of choice:

Set the desired value.

The unit follows the choice of configuration in parameter 100.

Speed control, open loop:	Hz
Speed control, closed loop:	rpm
Torque control, open loop:	Nm
Torque control, speed feedback:	Nm
Process control, closed loop:	Process units
	(par. 416)

Special motor characteristics, activated in parameter 101, use the unit selected in parameter 100. See drawing on page 63.

Danfoss


206 Ramp type (RAMP TYPE)	
Value:	
★ Linear (LINEAR)	[0]
Sinusoidal (S1)	[1]
Sin² (S2)	[2]
Sin ³ (S3)	[3]

Function:

There is a choice of 4 different ramp types.

Description of choice:

Select the desired ramp type, depending on requirements concerning acceleration/deceleration.



207 Ramp-up time 1 (RAMP UP TIME 1)


Value:

0.05 - 3600 sec.

★ depends on unit

Function:

The ramp-up time is the acceleration time from 0 Hz to the rated motor frequency $f_{M,N}$ (parameter 104) or the rated motor speed n_{M,N} (if Speed control, closed loop has been selected in parameter 100). This presupposes that the output current does not reach the torque limit (to be set in parameter 221).



Description of choice: Program the desired ramp-up time.

208 Ramp-down tir	me 1
(RAMP DOWN	TIME 1)
Value:	
0.05 - 3600 sec.	★ depends on unit

Function:

The ramp-down time is the deceleration time from the rated motor frequency f_{M.N} (parameter 104) to 0 Hz or from the rated motor speed n_{M.N}, provided there is no over-voltage in the inverter because of regenerative operation of the motor, or if the generated current reaches the torque limit (to be set in parameter 222).

Description of choice:

Program the desired ramp-down time.

209 Ramp-up time 2	
(RAMP UP TIME 2)	
Value:	
0.05 - 3600 sec.	\star depends on unit

Function:

See description of parameter 207.

Description of choice:

Program the desired ramp-up time. Switching from ramp 1 to ramp 2 is effected via a signal on digital input terminal 16, 17, 29, 32 or 33.

★ depends on unit

210	Ramp-o	down ti	me 2	
	(RAMP	DOWN	TIME	2

Value:

0.05 - 3600 sec.

Function:

See description of parameter 208.

Description of choice:

Program the desired ramp-down time. Switching from ramp 1 to ramp 2 is effected via a signal on digital input terminal 16, 17, 29, 32 or 33.

Dantoss

211 Jog ramp time (JOG RAMP TIME)


Value:

0.05 - 3600 sec.

🛨 depends on unit

Function:

The jog ramp time is the acceleration/deceleration time from 0 Hz to the rated motor frequency $f_{M,N}$ (parameter 104). It is assumed that the output current is not higher than the torque limit (set in parameter 221).



The jog ramp time starts if a jog signal is given via the control panel, the digital inputs or the serial communication port.

Description of choice: Set the desired ramp time.

212 Quick stop ramp-down time (Q STOP RAMP TIME)

Value:

0.05 - 3600 sec.

★ depends on unit

Function:

The ramp-down time is the deceleration time from the rated motor frequency to 0 Hz, provided no overvoltage arises in the inverter because of generating operation of the motor or if the generated current becomes higher than the torque limit (set in parameter 222).

Quick-stop is activated by means of a signal on digital input terminal 27, or via the serial communication port.

Description of choice: Program the desired ramp-down time.

213 Jog frequency (JOG FREQUENCY)

Value:

0.0 - parameter 202 * 10.0 Hz

Function:

The jog frequency f_{JOG} is the fixed output frequency at which the VLT frequency converter is running when the jog function is activated.

Description of choice: Set the desired frequency.

214 Reference function	
(REF FUNCTION)	
Value:	
★ Sum (SUM)	[0]
Relative (RELATIVE)	[1]
External/preset (EXTERNAL/PRESET)	[2]

Function:

It is possible to define how the preset references are to be added to the other references. For this purpose, *Sum* or *Relative* is used. It is also possible - by using the *External/preset* function - to select whether a shift between external references and preset references is desired.

Description of choice:

If *Sum* [0] is selected, one of the adjusted preset references (parameters 215-218) is added as a percentage of the maximum possible reference. If *Relative* [1] is selected, one of the adjusted preset references (parameters 215-218) is added to the external references as a percentage of the actual reference.

In addition, it is possible to use parameter 308 to select whether the signals on terminals 54 and 60 are to be added to the sum of the active references. If *External/preset* [2] is selected, it is possible to shift between external references or preset references via terminal 16, 17, 29, 32 or 33 (parameter 300, 301, 305, 306 or 307). Preset references will be a percentage value of the reference range. External reference is the sum of the analogue references, pulses and bus references.

See also drawings on pages 61-63.




If *Sum* or *Relative* is selected, one of the preset references will always be active. If the preset references are to be without influence, they should be set to 0 % (as in the factory setting).



The example shows how to calculate the output frequency if using *Preset references* together with *Sum* and *Relative* in parameter 214.

Parameter 205 Maximum reference has been set to 50 Hz.

Par. 204	Increase	Frequency	Par. 215	Par 214 Reference	Par. 214 Reference
Min. reference	[Hz/V]	by 4.0 V	Preset ref.	type = <u>Sum</u> [0]	type = Relative [1]
				Output frequency	Output frequency
1) 0	5	20 Hz	15 %	00+20+7.5 = 27.5 Hz	00+20+3 = 23.0 Hz
2) 10	4	16 Hz	15 %	10+16+6.0 = 32.0 Hz	<u>10+16+2.4 = 28.4 Hz</u>
3) 20	3	12 Hz	15 %	20+12+4.5 = 36.5 Hz	<u> 20+12+1.8 = 33.8 Hz</u>
4) 30	2	8 Hz	15 %	30+8+3.0 = 41.0 Hz	30+8+1.2 = 39.2 Hz
5) 40	1	4 Hz	15 %	40+4+1.5 = 45.5 Hz	40+4+0.6 = 44.6 Hz



215	Preset reference 1 (PRESET REF. 1)
216	Preset reference 2 (PRESET REF. 2)
217	Preset reference 3 (PRESET REF. 3)
218	Preset reference 4 (PRESET REF. 4)

Value:

-100.00 % - +100.00 % **±** 0.00% of the reference range/external reference

Function:

Four different preset references can be programmed in parameters 215-218.

The preset reference is stated as a percentage of the value Ref_{MAX} or as a percentage of the other external references, depending on the choice made in parameter 214. If a $\text{Ref}_{MIN} \neq 0$ has been programmed, the preset reference as a percentage will be calculated on the basis of the difference between Ref_{MAX} and Ref_{MIN} , following which the value is added to Ref_{MIN} .

Description of choice:

Set the fixed reference(s) that is/are to be the options.

To use the fixed references, it is necessary to have selected Preset ref. enable on terminal 16, 17, 29, 32 or 33.

Choices between fixed references can be made by activating terminal 16, 17, 29, 32 or 33 - see the table below.

Terminals 17/29/33 Terminals 16/29/32

preset ref. msb preset ref. lsb

0	0	Preset ref. 1
0	1	Preset ref. 2
1	0	Preset ref. 3
1	1	Preset ref. 4

See drawings on pages 56-58.

219 Catch up/slow down value (CATCH UP/SLW DWN)

Value:

0.00-100% of the current reference \pm 0.00 %

Function:

This parameter enables the entry of a percentage value (relative) which will either be added to or deducted from the actual reference.

Description of choice:

If *Catch up* has been selected via one of the terminals 16, 29 or 32 (parameters 300, 305 and 306), the percentage (relative) value selected in parameter 219 will be added to the total reference.

If *Slow down* has been selected via one of the terminals 17, 29 or 33 (parameters 301, 305 and 307), the percentage (relative) value selected in parameter 219 will be deducted from the total reference.

Danfoss

221 Torque limit for motor mode (TORQ LIMIT MOTOR) Value:


0.0 % - xxx.x % of T_{MN} ★ 160 % of T_{MN}

The max. torque depends on the unit and the motor size selected.

Function:

This function is relevant for all application configurations; speed, process and torque control. This is where to set the torque limit for motor operation. The torque limiter is active in the frequency range up to the rated motor frequency (parameter 104). In the oversynchronous range, where the frequency is higher than the rated motor frequency, this function acts as a current limiter.

See fig. below.



Description of choice:

In order to protect the motor from reaching pull-out torque, the factory setting is 1.6 x the rated motor torque (calculated value).

If a synchronous motor is used, the torque limit must be increased in relation to the factory setting. If a setting in parameters 101-106 is changed, parameters 221/222 are not automatically reversed to the factory setting.

222 Torque limit for generating operation (TORQ LIMIT GENER)

Value:

0.0 % - xxx.x % of T_{M.N} ★ 160 %

The max. torque depends on the unit and the motor size selected.

Function:

This function is relevant for all application configurations; speed, process and torque control.

This is where to set the torque limit for generating operation. The torque limiter is active in the frequency range up to the rated motor frequency (parameter 104).

In the oversynchronous range, where the frequency is higher than the rated motor frequency, this function acts as a current limiter.

See fig. for parameter 221.

Description of choice:

If *Resistor brake* [1] has been selected in parameter 400, the torque limit is changed to 1.6 x the rated motor torque.

223 Warning: Low current (WARN. CURRENT LO)

Value:

. 0.0 - parameter 224 * 0.0 A

Function:

When the motor current is below the limit, ${\sf I}_{\sf LOW},$ programmed in this parameter, the display indicates CURRENT LOW.

The signal outputs can be programmed to transmit a status signal via terminal 42 or 45 as well as via relay output 01 or 04 (parameter 319, 321, 323 or 326).


★ = factory setting. () = display text [] = value for use in communication via serial communication port

MG.50.A9.02 - VLT is a registered Danfoss trademark

Danfoss

Description of choice:

The lower signal limit I_{LOW} of the motor current must be programmed within the normal working range of the frequency converter.



224 Warning: High current (WARN. CURRENT HI)

Value:

Parameter 223 - I_{VLT,MAX} * I_{VLT,MAX}

Function:

If the motor current gets above the limit programmed in this parameter, $I_{\rm HIGH},$ the display will indicate CURRENT HIGH.

The signal outputs can be programmed to transmit a status signal via terminal 42 or 45 and via relay output 01 or 04 (parameter 319, 321, 323 or 326).

Description of choice:

The upper signal limit of the motor current, I_{HIGH} , must be programmed within the normal working range of the frequency converter. See drawing at parameter 223.

225 Warning: Low frequency (WARN. FREQ. LOW)

Value:

0.0 - parameter 226

Function:

When the motor frequency is below the limit programmed in this parameter, f_{LOW} , the display indicates FREQUENCY LOW.

★ 0.0 Hz

The signal outputs can be programmed to transmit a status signal via terminal 42 or 45 and via relay output 01 or 04 (parameter 319, 321, 323 or 326).

Description of choice:

The lower signal limit of the motor frequency, f_{LOW} , is to be programmed within the normal working range of the frequency converter.

See drawing at parameter 223.

226 Warning: High frequency	
(WARN. FREQ. HIGH)	
Value:	
parameter 225 - parameter 202	★ 132.0 Hz

Function:

When the motor frequency is above the limit programmed in this parameter, f_{HIGH} , the display will indicate FREQUENCY HIGH.

The signal outputs can be programmed to transmit a status signal via terminal 42 or 45 and via relay output 01 or 04 (parameter 319, 321, 323 or 326).

Description of choice:

The upper signal limit of the motor frequency, f_{HIGH} , must be programmed within the normal working range of the frequency converter. See drawing at parameter 223.

References & Limits



★ -4000.000

228 Warning: High feedback	
(WARN. FEEDB HIGH)	,
Value:	
parameter 227 - 100,000.000	★ 4000.000

If the connected feedback signal gets below the value

grammed to transmit a status signal via terminal 42 or

45 and via relay output 01 or 04 (parameter 319, 321,

set in this parameter, the signal outputs can be pro-

227 Warning: Low feedback

Value:

Function:

323 or 326).

Function:

Description of choice: Set the desired value.

(WARN, FEEDB, LOW)

-100,000.000 - parameter 228.

If the connected feedback signal gets above the value set in this parameter, the signal outputs can be programmed to transmit a status signal via terminal 42 or 45 and via relay output 01 or 04 (parameter 319, 321, 323 or 326).

Description of choice:	ecan.	•		" - †
	•••		~~~	+
Set the desired value.				

229 Erequency bypass, bandwidth			
(FREQ BYPASS B.W.)			
, Value:			
0 (OFF) - 100%	★ 0 (OFF) %		

Function:

Some systems call for some output frequencies to be avoided because of resonance problems in the system.

In parameters 230-233 these output frequencies can be programmed for bypassing (Frequency bypass). In this parameter (229), a bandwidth can be defined on either side of these frequency bypasses.

The frequency bypass function is not active if par. 002 is set to *Local* and par. 013 is set to *LCP ctrl/Open loop* or *LCP+dig ctrl/Open loop*.

Description of choice:

VLT' 5000 Series

<u> Jantos</u>

The bypass bandwidth is set as a percentage of the bypass frequency which is selected in parameter 230-233.

The bypass bandwidth indicates max. variation of the bypass frequency.

Example: A bypass frequency of 100 Hz and a bypass bandwidth of 1% are selected. In this case the bypass frequency can vary between 99.5 Hz and 100.5 Hz i.e. 1% of 100 Hz.

230 Frequency bypass 1 (FREQ. BYPASS 1)
231 Frequency bypass 2 (FREQ. BYPASS 2)
232 Frequency bypass 3 (FREQ. BYPASS 3)
233 Frequency bypass 4 (FREQ. BYPASS 4)
Value:
0.0 - parameter 200 + 0.0 Hz
Function:
Some systems call for some output frequencies to be
avoided because of resonance problems in the system.
Description of choice:

Enter the frequencies to be avoided. See also parameter 229.

234 Motor phase monitor	
(MOTOR PHASE MON)	
Settings:	
★ Enable (ENABLE)	[0]
Disable (DISABLE)	[1]

Function: In this parameter it is possible to select monitoring of the motor phases.

Description of choice: If *Enable* is selected, the frequency converter will react on a missing motor phase which will result in alarm 30, 31 or 32.

If *Disable* is selected, **no** alarm is given if a motor phase is missing. The motor can be damaged/ overheated if it runs on only two phases. It is therefore recommended to keep the missing motor phase function ENABLED.

Danfoss

300 Terminal 16, input (DIGITAL INPUT 16)

Digital inputs	Terminal no.	16	17	18	19	27	29		33
	parameter	300	301	302	303	304	305	306	307
Value:									
No function	(NO OPERATION)	[0]	[0]	[0]	[0]		[0]	[0]	[0]
Reset	(RESET)	[1] ★	[1]				[1]	[1]	[1]
Coasting stop, inverse	(COAST INVERSE)					_0 ★	<u>.</u>		
Reset and coasting stop, in	iverse								
	(COAST & RESET INVERS)					[1]			
Quick-stop, inverse	(QSTOP INVERSE)	-				[2]			
DC-braking, inverse	(DCBRAKE INVERSE)					[3]			
Stop inverse	(STOP INVERSE)	[2]	[2]			[4]	[2]	[2]	[2]
Start	(START)			<u>[1]</u>					
Latched start	(LATCHED START)			[2]					
Reversing	(REVERSING)				<u>[1]</u> ★				
Start reversing	(START REVERSE)				[2]				
Only start clockwise, on	(ENABLE START FWD.)	[3]		[3]			[3]	[3]	
Only start anti-clockwise, on	(ENABLE START REV)		[3]		[3]		[4]		[3]
Jog	(JOGGING)	[4]	[4]				<u>[5]</u> ★	[4]	[4]
Preset reference, on	(PRESET REF. ON)	[5]	[5]				[6]	[5]	[5]
Preset reference, Isb	(PRESET REF. SEL. LSB)	[6]					[7]	[6]	
Preset reference, msb	(PRESET REF. MSB)		[6]				[8]		[6]
Freeze reference	(FREEZE REFERENCE)	[7]	<u>. [7]</u> ★		_		[9]	[7]	[7]
Freeze output	(FREEZE OUTPUT)	[8]	[8]				[10]	[8]	[8]
Speed up	(SPEED UP)	[9]					[11]	[9]	
Speed down	(SPEED DOWN)		[9]				[12]		[9]
Choice of Setup, Isb	(SETUP SELECT LSB)	[10]					[13]	[10]	
Choice of Setup, msb	(SETUP SELECT MSB)		[10]				[14]		[10
Choice of Setup, msb/spe	ed up								
	(SETUP MSB/SPEED UP)							[11]#	7
Choice of Setup, Isb/spee	d down								
	(SETUP LSB/SPEED DOWN)								[11
Catch-up	(CATCH UP)	[11]					[15]	[12]	
Slow-down	(SLOW DOWN)		[11]				[16]	-	[12
Ramp 2	(RAMP 2)	[12]	[12]				[17]	[13]	[13
Mains failure inverted	(MAINS FAILURE INVERSE)	[13]	[13]				[18]	[14]	[14
Pulse reference	(PULSE REFERENCE)		[23]				י[28]י		
Pulse feedback	(PULSE FEEDBACK)								[24
Encoder feedback input, A	(ENCODER INPUT 2A)								[25
Encoder feedback input, B	(ENCODER INPUT 2B)							[24]	

1) If this function is selected for terminal 29, the same function for terminal 17 will not be valid, even if it has been selected to be active.

300 Terminal 16, input (DIGITAL INPUT 16)

Function:

In this and the following parameters it is possible to choose between the different possible functions related to the inputs on terminals 16-33.

The function options are shown in the table on page 101.

The maximum frequency for terminal 16, 17, 18 and 19 is 5 kHz. The maximum frequency for terminals 29, 32 and 33 is 65 kHz.

Description of choice:

No function is selected if the VLT frequency converter is not to react to signals transmitted to the terminal.

Reset zeroes the VLT frequency converter after an alarm; however, not all alarms can be reset.

Coasting stop inverse is used for making the VLT frequency converter let go of the motor to make it coast freely to stop. Logic '0' leads to coasting stop and reset.

Reset and coasting stop inverse, is used for activating coasting stop at the same time as reset. Logic '0' leads to coasting stop and reset

Quick-stop inverse is used for stopping the motor in accordance with the quick-stop ramp (set in parameter 212). Logic '0' leads to a quick-stop.

DC braking inverse is used for stopping the motor by energizing it with a DC voltage for a given time, see parameters 125-127.

Please note that this function is only active if the value of parameters 126-127 is different from 0. Logic '0' leads to DC braking.

Stop inverse is activated by interrupting the voltage to the terminal. This means that if the terminal has no voltage, the motor cannot run. The stop will be effected in accordance with the selected ramp (parameters 207/208/209/210).


None of the above-mentioned stop <u>commands (start-disable) are to be used</u> as disconnection switch in connection with repairs. Cut mains instead.

NB!:

'0' = stop.

It must be noted that when the VLT frequency converter is at the torque limit and has received a stop command, it will only stop if terminal 42, 45, 01 or 04 has been connected to terminal 27. The data choice on terminal 42, 45, 01

Start, is selected if a start/stop (operating command, group 2) command is desired. Logic '1' = start, logic



or 04 must be Torque limit and stop [27].

Latched start - if a pulse is applied for min. 3 ms, the motor will start, provided no stop command (operating command, group 2). The motor stops if Stop inverse is activated briefly.

Reversing is used for changing the direction of rotation of the motor shaft. Logic "0" will not lead to reversing. Logic "1" will lead to reversing. The reversing signal only changes the direction of rotation; it does not activate the start function. Reversing requires that *Both directions* has been selected in parameter 200.

Is not active if *Process control, closed loop* or *Torque control, speed feedback* has been selected.

Start reversing, is used for start/stop (operating command, group 2) and for reversing with the same signal. No signal is allowed on terminal 18 at the same time. Acts as latch start reversing, provided latch start has been chosen for terminal 18. Is not active if *Process control, closed loop* has been selected.

Start clockwise only, on is used if the motor shaft is only to be able to rotate clockwise when starting. Should not be used with *Process control, closed loop*.

Start anti-clockwise only, is used if the motor shaft is to rotate anti-clockwise when started. Should not be used with *Process control, closed loop.*

Jog is used for overriding the output frequency to the jog frequency set in parameter 213. The ramp time can be set in parameter 211. Jog is not active if a coast command has been given via terminal 27. Jog overrides stop (operating command, group 2).



Preset reference, on is used for shifting between external reference and preset reference. It is assumed that *External/preset* [2] has been selected in parameter 214. Logic '0' = external references active; logic '1' = one of the four preset references is active in accordance with the table below.

Preset reference, lsb and *Preset reference, msb* enables a choice of one of the four preset references, in accordance with the table below.

	Preset ref_msb	<u>Preset ref. Isb</u>
Preset ref. 1	0	0
Preset ref. 2	0	1
Preset ref. 3	1	0
Preset ref. 4	1	1

Freeze reference - freezes the actual reference. The frozen reference is now the point of enable/condition for *Speed up* and *Speed down* to be used.

If speed up/down is used, the speed change always follows ramp 2 (parameters 209/210) in the range 0 - Ref_{MAX} .

Freeze output - freezes the actual motor frequency (Hz). The frozen motor frequency is now the point of enable/condition for *Speed up* and *Speed down* to be used.

If speed up/down is used, the speed change always follows ramp 2 (parameters 209/210) in the range $0 - f_{M,N}$.

NB!:

If *Freeze output* is active, the VLT frequency converter cannot be stopped via terminals 18 and 19, but only via terminal 27 (to be programmed for *Coasting stop, inverse* [0] or *Reset and coasting stop, inverse* [1]).

After Freeze output, the PID integrators are reset.

Speed up and **Speed down** are selected if digital control of the up/down speed is desired (motor potentiometer). This function is only active if *Freeze reference* or *Freeze output* has been selected. As long as there is a logic '1' on the terminal selected for speed up, the reference or the output frequency will increase.

As long as there is a logic '1' on the terminal selected for speed down, the reference or the output frequency will be reduced.

Pulses (logic '1' minimum high for 3 ms and a minimum pause of 3 ms) will lead to a change of speed of 0.1% (reference) or 0.1 Hz (output frequency).

Example:

	<u>Terminal</u>		Freeze ref./		
	(16)	(17)	Freeze output		
No speed change	0	0	1		
Speed down	0	1	1		
Speed up	1	0	1		
Speed down	1	1	1		

The speed reference frozen via the control panel can be changed even if the VLT frequency converter has stopped. The frozen reference will be remembered in case of a mains drop-out.

Selection of Setup, Isb and Selection of Setup, msb enables a choice of one of the four Setups; however, this presupposes that parameter 004 has been set at *Multi Setup*.

Selection of Setup, msb/Speed up and Selection of Setup, lsb/Speed down - together with the use of Freeze reference or Freeze output - enable up/down speed change.

The selection of Setup occurs in accordance with the below verification table:

	<u>Selection of Setup</u> (33)msb (32)lsb		<u>Freeze ref/</u> Freeze output
	_	_	_
Setup 1	0	0	0
Setup 2	0	1	0
Setup 3	1	0	0
Setup 4	1	1	0
No speed change	0	0	1
Speed down	0	1	1
Speed up	1	0	1
Speed down	1	1	1

Pantosa

Catch-up/Slow-down is selected if the reference value is to be increased or reduced by a programmable percentage value set in parameter 219.

	<u>Slow-down</u>	Catch-up	
Unchanged speed	0	0	
Reduced by %-value	1	0	
Increased by %-value	0	1	
Reduced by %-value	1	1	

Ramp 2 is selected if a change between ramp 1 (parameters 207-208) and ramp 2 (209-210) is desired. Logic '0' leads to ramp 1, while logic '1' leads to ramp 2.

Mains failure inverted is to be selected if parameter 407 *Mains failure* and/or parameter 408 *Quick discharge* is to be activated. Mains failure inverted is active in the logical '0' situation.

See also Mains fault/quick discharge on page 72, if required.

NB! The VLT frequency converter can be totally damaged by repeating the Quick discharge function on the digital input with mains voltage connected to the system.

Pulse reference is selected if a pulse sequence (frequency) of 0 Hz is used, corresponding to Ref_{MIN}, parameter 204. The frequency is set in parameter 327, corresponding to Ref_{MAX}.

Pulse feedback is selected if a pulse sequence (frequency) is selected as a feedback signal.

Select Encoder feedback, input A, if encoder feedback is to be used after choosing Speed control, closed loop or Torque control, speed feedback in parameter 100. Set Pulse/rpm in parameter 329.

Select Encoder feedback, input B, if encoder feedback is to be used with a 90° pulse to register the direction of rotation.

301 Terminal 17, input (DIGITAL INPUT 17)

Value:

See parameter 300.

Function:

This parameter allows a choice between the different options on terminal 17. The functions are shown in the table on page 102. Maximum frequency for terminal 17 is 5 kHz.

Description of choice: See parameter 300.

302 Terminal 18 Start, input (DIGITAL INPUT 18)

Value:

See parameter 300.

Function:

This parameter allows a choice between the different options on terminal 18. The enabled functions are shown in the table on page 102. Maximum frequency for terminal 18 is 5 kHz.

Description of choice: See parameter 300.

Danfoss

303 Terminal 19, input (DIGITAL INPUT 19)

Value:

See parameter 300.

Function:

This parameter allows a choice between the different options on terminal 19. The functions are shown in the table on page 102. Maximum frequency for terminal 19 is 5 kHz.

Description of choice: See parameter 300.

304 Terminal 27, input (DIGITAL INPUT 27)

Value:

See parameter 300.

Function:

This parameter allows a choice between the different options on terminal 27.

Functions are shown in the table on page 102. Maximum frequency for terminal 27 is 5 kHz.

Description of choice:

See parameter 300.

305 Terminal 29, input

(DIGITAL INPUT 29)

Value:

See parameter 300.

Function:

This parameter allows a choice between the different options on terminal 29. The functions are shown in the table on page 102. Maximum frequency for terminal 29 is 65 kHz.

Description of choice: See parameter 300.

306 Terminal 32, input (DIGITAL INPUT 32)

Value: See parameter 300.

Function:

This parameter allows a choice between the different options on terminal 32. The functions are shown in the table on page 102. Maximum frequency for terminal 32 is 65 kHz

Maximum frequency for terminal 32 is 65 kHz.

Description of choice: See parameter 300.

307 Terminal 33, input (DIGITAL INPUT 33)

Value:

See parameter 300.

Function:

This parameter allows a choice between the different options on terminal 33. The functions are shown in the table on page 102. Maximum frequency for terminal 33 is 65 kHz.

Description of choice: See parameter 300.



(AI [V] 53 FUNG	CT.)		~	
Analogue inputs	terminal no.	53(voltage)	54(voltage)	60(current)
	parameter	308	311	314
Value:				
No operation	(NO OPERATION)	[0]	[0] (★)	[0]
Reference	(REFERENCE)	[1] (★)	[1]	_[1] (*)
Feedback signal	(FEEDBACK)	[2]		[2]
Torque limit	(TORQUE LIMIT CTRL)	[3]	[2]	[3]
Thermistor	(THERMISTOR INPUT)	[4]	[3]	
Relative reference	(RELATIVE REFERENCE)		[4]	[4]
Max. torque frequency	(MAX. TORQUE FREQ.)		[5]	

Function:

This parameter allows a choice of the desired option on terminal 53.

308 Terminal 53, analogue input voltage

Scaling of the input signal is effected in parameters 309 and 310.

Description of choice:

See drawing on page 61.

No operation. Is selected if the VLT frequency converter is not to react to signals connected to the terminal.


Reference. Is selected to enable change of reference by means of an analogue reference signal.

If other inputs are connected, these are added up, taking account of their signs.

Feedback-signal. Is selected if closed loop control with an analogue signal is used.

Torque limit. Is used if the torque limit value set in parameter 221 is to be changed by means of an analogue signal.

Thermistor. Is selected if a thermistor integrated in the motor is to be able to stop the VLT frequency converter in case of motor overtemperature. The cut-out value is > 3 kohm.



If a motor features a KLIXON thermal switch instead, this can also be connected to the input. If motors run in parallel, the thermistors/thermal switches can be connected in series (total resistance < 3 kohm).

Parameter 128 must be programmed for *Thermistor* warning [1] or *Thermistor trip* [2].

Relative reference is selected if a relative adjustment of the reference sum is required.

This function is only active if *Relative* has been selected (parameter 214). The relative reference on terminal 54/60 is a percentage of the full range of the terminal in question. This will be added to the sum of the other references. If several relative references have been selected (preset reference 215-218, 311 and 314), these will be added first, following which this sum will be added to the sum of the active references.



NB!

If *Reference* or *Feedback* signal has been selected on more than one terminal, these signals will be added with signs.

Max. torque frequency. This is only used in *Torque control, open loop* (parameter 100) for limiting the output frequency. Selected if the max. output frequency is to be controlled by an analogue input signal. The frequency range goes from *Output frequency low limit* (parameter 201) to *Output frequency high limit* (parameter 202).

Danfoss

309 Terminal 53, min. scaling	
(AI 53 SCALE LOW)	
Value:	
0.0 - 10.0 Volt	🛨 0.0 Volt

Function:

This parameter is used for setting the signal value that corresponds to the minimum reference value set in parameter 204.

Description of choice: Set the desired voltage value. See drawing on page 60.

★ 10.0 Volt

Function:

This parameter is used for setting the signal value that corresponds to the maximum reference value set in parameter 205.

Description of choice: Set the desired voltage value. See drawing on page 60.

311 Terminal 54, analogue input voltage (AI [V] 54 FUNCT.)

Value:

See description of parameter 308.

★ No operation

Function:

This parameter chooses between the different functions available for the input, terminal 54.

Scaling of the input signal is effected in parameters 312 and 313.

Description of choice:

See description of parameter 308.

312 Terminal 54, min. scaling	
(AI 54 SCALE LOW)	
Value:	
0.0 - 10.0 Volt	★ 0.0 Volt

Function:

This parameter is used for setting the signal value that corresponds to the minimum reference value set in parameter 204.

Description of choice: Set the desired voltage value. See drawing on page 60.

313 Terminal 54, max. scaling	
(AI 54 SCALE HIGH)	
Value:	
0.0 - 10.0 Volt	★ 10.0 Volt

Function:

This parameter is used for setting the signal value that corresponds to the maximum reference value set in parameter 205.

Description of choice: Set the desired voltage value. See drawing on page 60.

314 Terminal 60, analogue input current (AI [mA] 60 FUNCT)

Value:

See description of parameter 308.

★ Reference

Function:

This parameter allows a choice between the different functions available for the input, terminal 60. Scaling of the input signal is effected in parameters 315 and 316.

Description of choice: See description of parameter 308.

Dantos

315	Terminal 60, min. scaling	
	(AI 60 SCALE LOW)	

Value:

0.0 - 20.0 mA

Function:

This parameter determines the value of the reference signal that is to correspond to the minimum reference value set in parameter 204.

If the Time-out function of parameter 317 is to be used, the value must be set at > 2 mA.

Description of choice:

Set the desired current value. See drawing on page 60.

316	Terminal 60, max. scaling	
	(AI 60 SCALE HIGH)	•
Valu	<u>Δ'</u>	

0.0 - 20.0 mA

★ 20.0 mA

★ 0.0 mA

Function:

This parameter sets the value of the reference signal that is to correspond to the maximum reference value set in parameter 205.

Description of choice:

Set the desired current value. See drawing on page 60.

317 Time out (LIVE ZERO TIME O)

Value:

0 - 99 sec.

★ 10 sec.

Function:

If the signal value of the reference signal connected to the input, terminal 60, falls below 50% of the value set in parameter 315 for a period longer than the time set in parameter 317, the function selected in parameter 318 will be activated.

Description of choice: Set the desired time.

VLT' 5000 Series

318 Function after time out	
(LIVE ZERO FUNCT)	
Value:	
★ Off (OFF)	[0]
Freeze output frequency	
(FREEZE OUTPUT FREQ.)	[1]
Stop (STOP)	[2]
Jog (JOGGING)	[3]
Max. speed (MAX SPEED)	[4]
Stop and trip (STOP AND TRIP)	[5]

Function:

This parameter allows a choice of the function to be activated if the input signal on terminal 60 drops below 2 mA, provided parameter 315 has been set higher than 2 mA and that the preset time for timeout (parameter 317) has been exceeded.

If more time-outs occur at the same time the VLT frequency converter will give the following priority to the time-out function:

- 1. Parameter 318 Function after time out
- 2. Parameter 346 Function after encoder loss
- 3. Parameter 514 Bus time interval function

Description of choice:

The output frequency of the VLT frequency converter can be:

- frozen at the present value
- overruled to stop
- overruled to jog frequency
- overruled to max. frequency
- overruled to stop with subsequent trip.

Inputs & Outputs

Danfoss

. -

319 Terminal 42 output, (AO 42 FUNCT.)

Outputs	terminal no.	42	45	01(relay)	04 (relay)
	parameter	319	321	323	326
Value:					
No function	(NO OPERATION)	[0]	[0]	[0]	[0]
Control ready (CONTROL READY)		[1]	[1]	[1]	[1]
Ready signal	(UNIT READY)	[2]	[2]	[2]	[2]
Ready - remote control (UNIT READY/REM CTRL)		[3]	[3]	[3]	[3] (★)
		[4]	[4]	[4]	[4]
Running	(VLT RUNNING)	[5]	[5]	[5]	[5]
Running, no warning (RUNNING/NO WARNING)		[6]	[6]]6]]6]
Running within range, no warning	(RUN IN RANGE/NO WARN)	[7]	[7]	[7]	[7]
Running at reference value, no w	varning				
	(RUN ON REF/NO WARN)	[8]	[8]	[8]	[8]
Fault	(ALARM)	[9]	[9]	[9]	[9]
Fault or warning	(ALARM OR WARNING)	[10]	[10]	[10]	[10]
Torque limit	(TORQUE LIMIT)	[11]	[11]	[11]	[11]
Out of current range	(OUT OF CURRENT RANGE)	[12]	[12]	[12]	[12]
Over I low	(ABOVE CURRENT, LOW)	[13]	[13]	[13]	[13]
Under I high	(BELOW CURRENT, HIGH)	[14]	[14]	[14]	[14]
Out of frequency range (OUT OF FREQ RANGE)		[15]	[15]	[15]	[15]
Over f low	(ABOVE FREQUENCY LOW)	[16]	[16]	[16]	[16]
Under f high	(BELOW FREQUENCY HIGH)	[17]	[17]	[17]	[17]
Out of feedback range	(OUT OF FDBK RANGE)	[18]	[18]	[18]	[18]
Over feedback low	(ABOVE FDBK, LOW)	[19]	[19]	[19]	[19]
Under feedback high	(BELOW_FDBK, HIGH)	[20]	[20]	[20]	[20]
Thermal warning	(THERMAL WARNING)	[21]	[21]	[21]	[21]
Ready - no thermal warning	(READY &NOTHERM WARN)	[22]	[22]	[22] (★)	[22]
Ready - remote control - no the	m. warn. (REM RDY&NO THERMWAR)	[23]	[23]	[23]	[23]
Ready - mains voltage within rar					
	(RDY NO OVER/UNDERVOL)	[24]	[24]	[24]	[24]
Reversing	(REVERSE)	[25]	[25]	[25]	[25]
Bus ok	(BUS OK)	[26]	[26]	[26]	[26]
Torgue limit and stop	(TORQUE LIMIT AND STOP)	[27]	[27]	[27]	[27]
Brake, no brake warning	()	[28]	[28]	[28]	[28]
Brake ready, no fault	(BRAKE RDY (NO FAULT))	[29]	[29]	[29]	[29]
Brake fault	(BRAKE FAULT (IGBT))	[30]	[30]	[30]	[30]
Relay 123	(RELAY 123)	[31]	[31]	[31]	[31]
Mechanical brake control	(MECH. BRAKE CONTROL)			[32]	[32]
Control word bit 11/12	(CTRL WORD BIT 11/12)			[33]	[33]
Extended mechanical brake co					*
	(EXT MECH. BRAKE)			[34]	[34]



Outputs	terminal no.	42	45	01(relay) 04 (relay)
	parameter	319	321	323 326
Value (cont.)	-			
$0-100 \text{ Hz} \Rightarrow 0-20 \text{ mA}$	(0-100 Hz = 0-20 mA)	[36]	[36]	
$0-100 \text{ Hz} \Rightarrow 4-20 \text{ mA}$	(0-100 Hz = 4-20 mA)	[37]	[37]	
$0-100 \text{ Hz} \Rightarrow 0-32000 \text{ p}$	(0-100 Hz = 0-32000P)	[38]	[38]	
<u>0 - f_{MAX} ⇒ 0-20 mA</u>	(0-FMAX = 0-20 mA)	[39]	[39] ★	
$0 - f_{MAX} \Rightarrow 4-20 \text{ mA}$	(0-FMAX = 4-20 mA)	[40]	[40]	
$0 - f_{MAX} \Rightarrow 0.32000 p$	(0-FMAX = 0-32000P)	[41]	[41]	
$\text{Ref}_{\text{MIN}} - \text{Ref}_{\text{MAX}} \Rightarrow 0.20 \text{ mA}$	(REF MIN-MAX = 0-20 mA)	[42]	[42]	
$Ref_{MIN} - Ref_{MAX} \Rightarrow 4-20 mA$	(REF MIN-MAX = 4-20 mA)	[43]	[43]	
Ref_{MIN} - $\text{Ref}_{MAX} \Rightarrow 0.32000 \text{ p}$	(REF MIN-MAX = 0-32000P)	[44]	[44]	
$\overline{FB}_{MIN} - FB_{MAX} \Rightarrow 0.20 \text{ mA}$	(FB MIN-MAX = 0-20 mA)	[45]	[45]	
$FB_{MIN} - FB_{MAX} \Rightarrow 4-20 \text{ mA}$	(FB MIN-MAX = 4-20 mA)	[46]	[46]	
FB _{MIN} - FB _{MAX} ⇒ 0-32000 p	(FB MIN-MAX = 0-32000P)	[47]	[47]	
0 - I _{MAX} ⇒ 0-20 mA	(0-IMAX = 0-20 mA)	[48] ★	[48]	
0 - I _{MAX} ⇒ 4-20 mA	(0-IMAX = 4-20 mA)	[49]	[49]	
0 - I _{MAX} ⇒ 0-32000 p	(0-IMAX = 0-32000P)	[50]	[50]	
0 - T _{UM} ⇒ 0-20 mA	(0-TLIM = 0-20 mA)	[51]	[51]	
0 - T _{UM} ⇒ 4-20 mA	(0-TLIM = 4-20 mA)	[52]	[52]	
0 - T _{UM} ⇒ 0-32000 p	(0-TLIM = 0-32000P)	[53]	[53]	
$0 - T_{NOM} \Rightarrow 0.20 \text{ mA}$	(0-TNOM = 0-20 mA)	[54]	[54]	
$0 - T_{NOM} \Rightarrow 4-20 \text{ mA}$	(0-TNOM = 4-20 mA)	[55]	[55]	
$0 - T_{NOM} \Rightarrow 0 - 32000 \text{ p}$	(0-TNOM = 0-32000P)	[56]	[56]	
$0 - P_{NOM} \Rightarrow 0-20 \text{ mA}$	(0-PNOM = 0-20 mA)	[57]	[57]	
$0 - P_{NOM} \Rightarrow 4-20 \text{ mA}$	(0-PNOM = 4-20 mA)	[58]	[58]	
0 - P _{NOM} ⇒ 0-32000 p	(0-PNOM = 0-32000P)	[59]	[59]	

Inputs & Outputs

★ = factory setting. () = display text [] = value for use in communication via serial communication port

٩



Function:

This output can act both as a digital and an analogue output. If used as a digital output (data value [0]-[59]), a 24 V DC signal is transmitted; if used as an analogue output either a 0-20 mA signal, a 4-20 mA signal or a pulse output is transmitted.

Description of choice:

Control ready, the VLT frequency converter is ready for use; the control card receives supply voltage.

Ready signal, the VLT frequency converter control card is receiving a supply signal and the frequency converter is ready for operation.

Ready, remote control, the VLT frequency converter control card is receiving a supply signal and parameter 002 has been set to *remote control.*

Enable, no warning, the VLT frequency converter is ready for use; no start or stop command has been given (start/disable). No warning.

Running, a start command has been given.

Running, no warning, the output frequency is higher than the frequency set in parameter 123. A start command has been given. No warning.

Runs in range, no warning, runs within the programmed current/frequency ranges set in parameters 223-226.

Runs on reference, no warning, speed according to reference. No warning.

Fault, output is activated by alarm.

Fault or warning, the output is activated by alarm or warning.

Torque limit, the torque limit in parameter 221 has been exceeded.

Out of current range, the motor current is outside the range programmed in parameters 223 and 224.

Over I low, the motor current is higher than set in parameter 223.

Under I high, the motor current is lower than set in parameter 224.

Out of frequency range, the output frequency is outside the frequency range programmed in parameters 225 and 226.

Over f low, the output frequency is higher than the value set in parameter 225.

Under f high, the output frequency is lower than the value set in parameter 226.

Out of feedback range, the feedback signal is outside the range programmed in parameters 227 and 228.

Over feedback low, the feedback signal is higher than the value set in parameter 227.

Under feedback high, the feedback signal is lower that the value set in parameter 228.

Thermal warning, above the temperature limit in either the motor, the VLT frequency converter, the brake resistor or the thermistor.

Ready - no thermal warning, the VLT frequency converter is ready for use, the control card receives supply voltage and there are no control signals on the inputs. No over-temperature.

Ready - remote control - no thermal warning, the VLT frequency converter is ready for use and set at remote control, the control card receives supply voltage. No over-temperature.

Ready - mains voltage within range, the VLT frequency converter is ready for use, the control card receives supply voltage and there are no control signals on the inputs. The mains voltage is within the permitted voltage range (see chapter 8).

Reversing. Logic '1' = relay activated, 24 V DC on the output when the direction of rotation of the motor is clockwise. Logic '0' = relay not activated, no signal on the output, when the direction of rotation of the motor is anti-clockwise.

Bus-ok, active communication (no time-out) via the serial communication port.



Torque limit and stop is used in connection with coasting stop (terminal 27), where it is possible to give a stop even if the VLT frequency converter is at the torque limit. The signal is inverted, i.e. a logic '0' when the VLT frequency converter has received a stop signal and is at the torque limit.

Brake, no brake warning, the brake is active and there are no warnings.

Brake ready, no fault, the brake is ready for operation and there are no faults.

Brake fault, the output is a logical "1" when the brake IGBT has short-circuited. This function is used to protect the VLT frequency converter if there is a fault on the brake modules. To avoid a potential fire in the brake resistor, the output/relay can be used to cut out the supply voltage from the VLT frequency converter.

Relay 123, if Profidrive [0] has been selected in parameter 512, the relay is activated. If either OFF1, OFF2 or OFF3 (bit in the control word) is logic '1'.

Mechanical brake control, enables control of an external mechanical brake, see description *Control of mechanical brake*.

Control word bits 11/12, relay controlled via bits 11/ 12 in serial control word. Bit 11 relates to relay 01 and bit 12 to relay 04. If parameter 514 *Bus time interval function* is active, relays 01 and 04 will be voltagefree.

See section on *Serial communication* in the Design Guide.

Extended mechanical brake control, enables control of an external mechanical brake, see description *Control of mechanical brake*.

0-100 Hz \Rightarrow 0-20 mA and 0-100 Hz \Rightarrow 4-20 mA and 0-100 Hz \Rightarrow 0-32000 p, a pulse output signal proportional to the output frequency in the range 0-100 Hz.

 $0-f_{MAX} \Rightarrow 0-20 \text{ mA}$ and $0-f_{MAX} \Rightarrow 4-20 \text{ mA}$ and $0-f_{MAX} \Rightarrow 0-32000 \text{ p}$, an output signal proportional to the output frequency range in the range 0 - f_{MAX} (parameter 202). $Ref_{MIN} - Ref_{MAX} \Rightarrow 0.20 \text{ mA}$ and $Ref_{MIN} - Ref_{MAX} \Rightarrow 4.20 \text{ mA}$ and $Ref_{MIN} - Ref_{MAX} \Rightarrow 0.32000 \text{ p}$, an output signal proportional to the reference value in the interval Ref_{MIN} - Ref_{MAX} (parameters 204/205) is obtained.

 FB_{MIN} - $FB_{MAX} \Rightarrow 0.20 \text{ mA}$ and FB_{MIN} - $FB_{MAX} \Rightarrow 4.20 \text{ mA}$ and

 $FB_{MIN} - FB_{MAX} \Rightarrow 0.32000 \ p$, an output signal proportional to the feedback value in the interval FB_{MIN}-FB_{MAX} (parameters 414/415) is obtained.

 $0 - I_{VLT, MAX} \Rightarrow 0-20 \text{ mA or}$

 $0 - I_{VLI. MAX} \Rightarrow 4-20 mA$ and

0 - $I_{VLT,MAX} \Rightarrow 0.32000 \ p$, an output signal proportional to the output current in the interval 0 - $I_{VLT,MAX}$ is obtained. $I_{VLT,MAX}$ depends on the settings in parameter 101 and 103 and can be seen from the *Technical data* ($I_{VLT,MAX}$ (60 s)).

- $0 T_{LIM} \Rightarrow 0-20 \text{ mA}$ and
- $0 T_{UM} \Rightarrow 4-20 \text{ mA and}$

0 - $T_{LIM} \Rightarrow 0.32000 \text{ p}$, an output proportional to the output torque in the interval 0 - T_{LIM} (parameter 221) is obtained. 20 mA corresponds to the value set in parameter 221.

- $0 T_{NOM} \Rightarrow 0-20 \text{ mA and}$
- $0 T_{NOM} \Rightarrow 4-20 \text{ mA and}$

 $0 - T_{NOM} \Rightarrow 0-32000 \, p$, an output signal proportional to the output torque of the motor. 20 mA corresponds to the rated torque for the motor.

- $0 P_{NOM} \Rightarrow 0-20 \text{ mA}$ and
- $0 P_{NOM} \Rightarrow 4-20 \text{ mA and}$

 $0 - P_{NOM} \Rightarrow 0.32000 \, p, \, 0 - P_{NOM} \Rightarrow 0.32000 \, p,$ an output signal proportional to the rated motor output is obtained. 20 mA corresponds to the value set in parameter 102.

Danfoss

320 Terminal 42, output, pulse scaling (AO 42 PULS SCALE)

Value:

1 - 32000 Hz


★ 5000 Hz

Function:

This parameter allows scaling of the pulse output signal.

Description of choice:

Set the desired value.



321 Terminal 45, output (AO 45 FUNCT.)

Value:

See description for parameter 319.

Function:

This output can function both as a digital and an analogue output. Used as a digital output (data value [0]-[35]) it generates a 24 V (max. 40 mA) signal; on the analogue outputs (data value [36]-[59]) there is a choice of 0-20 mA, 4-20 mA or a scalable pulse output.

Description of choice:

See description for parameter 319.

322 Terminal 45, output, pulse scaling (AO 45 PULS SCALE)

Value:

1 - 32000 Hz

```
★ 5000 Hz
```

Function:

This parameter allows scaling of the pulse output signal.

Description of choice: Set the desired value.

323 Relay 01, output

(RELAY 1-3 FUNCT.)

Value:

See description of parameter 319.


Function:

This output activates a relay switch.

Relay switch 01 can be used for bringing status and warnings. The relay is activated when the conditions for the relevant data values have been fulfilled. Activation/deactivation can be delayed in parameter 324/325.

Description of choice:

See description of parameter 319. Connections - see the below drawing.



324 Relay 01, ON delay	
(RELAY 1-3 ON DL)	
Value:	
0.00 - 10.00 min.	★ 0.00 sec.
Function:	
This parameter allows a delay	of the cut-in time of

relay 01 (terminals 01-02).

Description of choice:

Enter the desired value (can be set at intervals of 0.02 sec.).

325 Relay 01, OFF delay	
(RELAY 1-3 OFF DL)	
Value:	
0.00 - 10.00 min.	★ 0.00 sec.

Function:

This parameter makes it possible to delay the cutout time of relay 01 (terminals 01-03).

Description of choice:

Enter the desired value (can be set at intervals of 0.02 sec.).

Dantos

326 Relay 04, output

(RELAY 4-5 FUNCT.)

Value:

See description of parameter 319.


Function:

This output activates a relay switch.

Relay switch 04 can be used for bringing status and warnings. The relay is activated when the conditions for the relevant data values have been fulfilled.

Description of choice:

See description of parameter 319. Connections - see the below drawing.



327 Pulse reference, max. frequency (PULSE REF MAX)

Value:

100 - 65000 Hz at terminal 29	★ 5000 Hz
100 - 5000 Hz at terminal 17	

Function:

In this parameter, the signal value is set that corresponds to the maximum reference value set in parameter 205.

Description of choice: Set the desired pulse reference.

(PULSE FEEDB MAX)	
Value:	
100 - 65000 Hz at terminal 33	★ 25000 Hz
Function:	
Function: his is where to set the feedback valu correspond to the maximum feed bac	ue that is to

329 Encoder feedback pulse/rev

VLT' 5000 Series

(ENCODER PULSES)	
Value:	
128 pulses /rev. (128)	[128]
256 pulses /rev. (256)	[256]
512 pulses /rev. (512)	[512]
★ 1024 pulses /rev. (1024)	[1024]
2048 pulses /rev. (2048)	[2048]
4096 pulses /rev. (4096)	[4096]


This value can also be set between 1-4096 pulses/rev.

Function:

This is where to set the encoder pulses per revolution that correspond to the motor rpm.

This parameter is only available in *Speed control, closed loop* and *in Torque control, speed feedback* (parameter 100).

Description of choice: Read the correct value from the encoder. Pay attention to the speed limitation (rpm) for a given number of pulses/rpm, see the drawing below:



The encoder used is to be of the Open Collector PNP 0/24 V DC type (max. 20 kHz) or a Push-Pull circuit 0/24 V DC (max. 65 kHz).

330 Freeze reference/output function	
(FREEZE REF/OUTP.)	
Settings:	in destant of the
★ No operation (NO OPERATION)	[0]
Freeze reference (FREEZE REFERENCE	:) [1]
Freeze output (FREEZE OUTPUT)	[2]
Function: In this parameter it is possible to freeze eithreference or the output.	and the second

★ = factory setting. () = display text [] = value for use in communication via serial communication port

Set the desired feedback value.



Description of choice:

Freeze reference [1] freezes the actual reference. The frozen reference is now the basis for *Speed up* and *Speed down*.

Freeze output [2] freezes the actual motor frequency (Hz). The frozen frequency is now the basis for *Speed up* and *Speed down*.

NBI:

If *Freeze output* is active, the frequency converter cannot be stopped via terminals 18 and 19, but only via terminal 27 (to be programmed for *Coasting stop, inverse* [0] or *Reset and coasting stop, inverse* [1]).

After Freeze output, the PID integrators are reset.

345 Encoder loss timeout (ENC LOSS TIMEOUT)

Value:

0 - 60 sec.

★ 0 sec.

Function:

If the encoder signal is interrupted from terminal 32 or 33 the function selected in parameter 346 will be activated.

If the encoder feedback signal is different from the output frequency $+/-3 \times 10^{-1}$ x nominal motor slip the encoder loss function will be activated.

An encoder loss timeout can occur even if the encoder works all right. Check the motor parameter in group 100 if no error can be found on the encoder.

The Encoder loss function is only active in *Speed* control, closed loop [1] and *Torque control, speed* feedback [5], see parameter 100 Configuration.

Description of choice: Set the required time.

346 Encoder loss function (ENC. LOSS FUNC) Value:

\star	Off (OFF)	[0]
	Freeze output frequency (FREEZE OUTPUT FREQ.)	[1]
	Jog (JOGGING)	[3]
	Max. speed (MAX SPEED)	[4]
	Stop and trip (STOP AND TRIP)	[5]
	Select Setup 4 (SELECT SETUP 4)	[7]

Function:

In this parameter the function can be activated if the encoder signal is disconnected from terminal 32 or 33.

If more time-outs occur at the same time the VLT frequency converter will give the following priority to the time-out function:

- 1. Parameter 318 Function after time out
- 2. Parameter 346 Function after encoder loss
- 3. Parameter 514 Bus time interval function.

Description of choice:

The output frequency of the VLT frequency converter can be:

- frozen at the present value
- overruled to jog frequency
- overruled to max. frequency
- overruled to stop with subsequent trip.
- overruled to Setup 4

400 Brake function/overvoltage control (BRAKE FUNCTION)

V	alue:	
×	Off (OFF)	[0]
	Resistor brake (RESISTOR)	[1]
	Overvoltage control	
	(OVERVOLTAGE CONTROL)	[2]
	Overvoltage control and stop	
	(OVERVOLT CTRL. & STOP)	[3]

Function:

The factory setting is *Off* [0] for VLT 5001-5052 380-500 V and 5001-5027 200-240 V. For VLT 5060-5250 380-500 V and 5032-5052 200-240 V the factory setting is *Overvoltage control* [2]. *Resistor brake* [1] is used for programming the VLT frequency converter for connection of a brake resistor.

The connection of a brake resistor allows a higher intermediate circuit voltage during braking (generating operation).

The *Resistor brake* [1] function is only active in units with an integral dynamic brake (SB and EB units).

Overvoltage control (excl. brake resistor) can be selected as an alternative. This function is active for all units (ST, SB and EB).



The function ensures that a trip can be avoided if the intermediate circuit voltage increases. This is done by increasing the output frequency so as to use the energy from the intermediate circuit. This is a very useful function, e.g. if the ramp-down time is too short, since tripping of the VLT frequency converter is avoided. In this situation, the rampdown time is extended.

NB! Please note

Please note that the ramp-down time is extended in the case of overvoltage control, which in some applications may not be appropriate.

Description of choice:

Select *Resistor brake* [1] if a brake resistor is part of the system.

Select *Overvoltage control* [2] if the overvoltage control function is required in all cases - also if stop is pressed. The VLT frequency converter will <u>not</u> stop in the case of a stop command when the overvoltage control is active.

Select *Overvoltage control and stop* [3] if the overvoltage control function is not required during ramp-down after stop has been pressed.

Warning: If Overvoltage control [2] is used
at the same time as the supply voltage to
the VLT frequency converter is close to or
above the maximum limit, there is a risk
that the motor frequency will increase and that,
consequently, the VLT frequency converter will not
stop the motor when stop is pressed. If the supply
voltage is higher than 264 V for 200-240 V units or
higher than 550 V for 380-500 V units, Overvoltage
control and stop [3] should be selected so that the
motor can be stopped.

401 Brake resistor, ohm (BRAKE RES. (OHM))

Value:

Depends on the unit

★ Depends on the unit.

Function:

This parameter gives the ohmic value of the brake resistor. This value is used for monitoring the power to the brake resistor provided this function has been selected in parameter 403.

Description of choice: Set the present resistor value.

402	Brake	power	limit,	kV

(BR.POWER. LIM.KW)

Value:

Depends on the unit

Function:

This parameter gives the monitoring limit of the power transmitted to the brake resistor.

Description of choice:

The monitoring limit is determined as a product of the maximum duty cycle (120 sec.) that will occur and the maximum power of the brake resistor at that duty cycle according to the following formula.

For 200 - 240 V units:	Р	=	<u>397² x t</u>
			R x 120
For 380 - 500 V units:	Р	=	822² x t
			R x 120

4	103 Power monitoring	
	(POWER MONITORING)	
٧	/alue:	
	Off (OFF)	[0]
★	Warning (WARNING)	[1]
	Trip (TRIP)	[2]

Function:

This parameter allows monitoring of the power transmitted to the brake resistor. The power is calculated on the basis of the resistor ohm value (parameter 401), the intermediate circuit voltage and the resistor running time. If the power transmitted over 120 sec. exceeds 100% of the monitoring limit (parameter 402) and Warning [1] has been selected, a warning will come up on the display. The warning will disappear if the power goes below 80%. If the calculated power exceeds 100% of the monitoring limit and Trip [2] has been selected in parameter 403 Power monitoring, the VLT frequency converter will cut out while giving an alarm. If power monitoring has been selected as Off [0] or Warning [1], the brake function will remain active, even if the monitoring limit has been exceeded. This may lead to thermal overload of the resistor. It is also possible to have a warning via the relay/digital outputs.

The typical measuring accuracy of the power monitoring depends on the accuracy of the resistor ohmic value (better than \pm 20%).

Depends on the unit
 itoring limit of the



[0] [1] [2]

VLT' 5000 Series

NB!

The power dissipation during quick discharge does not form part of the power monitoring function.

Description of choice:

Select whether this function is to be active (*Warning/Alarm*) or inactive (*Off*).

4	04	Brake check (BRAKE TEST)
ĪV	alu	e:
\star	Of	f (OFF)
	Wa	arning (WARNING)
	Trip	o (TRIP)

Function:

In this parameter a testing and monitoring function can be integrated which will give a warning or an alarm. On power-up it will be tested whether the brake resistor is disconnected. The test of whether the brake resistor is disconnected is carried out during braking, while the test of whether the IGBT is disconnected is carried out when there is no braking. A warning or trip disconnects the brake function.

The testing sequence is as follows:

- If the intermediate circuit voltage is higher than the brake starting voltage, discontinue the brake check.
- If the intermediate circuit voltage is unstable, discontinue the brake check.
- 3. Carry out a brake test.
- 4. If the intermediate circuit voltage is lower than the starting voltage, discontinue the brake check.
- 5. If the intermediate circuit voltage is unstable, discontinue the brake check.
- If the braking power is higher than 100%, discontinue the brake check.
- If the intermediate circuit voltage is higher than the intermediate circuit voltage -2% before the brake test, discontinue the brake check and give off a warning or alarm.
- 8. Brake check OK.

Description of choice:

If *Off*[0] is selected, this function will still monitor whether the brake resistor and the brake IGBT short-circuit during operation, in which case it will give off a warning. If *Warning* [1] is selected, the brake resistor and brake IGBT will be monitored with respect to short-circuiting. In addition, on power-up it will be checked whether the brake resistor has been disconnected.

NB!:

A warning in connection with *Off* [0] or *Warning* [1] can only be removed by disconnecting the mains supply and turning it back on, provided the fault has been corrected. Please note that in connection with *Off* [0] or *Warning* [1] the VLT frequency converter will continue even if a fault has been found.

In the case of *Trip* [2], the VLT frequency converter will cut out while giving an alarm (trip locked) if the brake resistor has short-circuited or been disconnected or if the brake IGBT has short-circuited.

405	Reset	function	(RESET	MODE)
Value	9:			

*	Manual reset (MANUAL RESET)	[0]
	Automatic reset x 1 (AUTOMATIC X 1)	[1]
	Automatic reset x 2 (AUTOMATIC X 2)	[2]
	Automatic reset x 3 (AUTOMATIC X 3)	[3]
	Automatic reset x 4 (AUTOMATIC X 4)	[4]
	Automatic reset x 5 (AUTOMATIC X 5)	[5]
	Automatic reset x 6 (AUTOMATIC X 6)	[6]
	Automatic reset x 7 (AUTOMATIC X 7)	[7]
	Automatic reset x 8 (AUTOMATIC X 8)	[8]
	Automatic reset x 9 (AUTOMATIC X 9)	[9]
	Automatic reset x 10 (AUTOMATIC X 10)	[10]

Function:

This parameter makes it possible to select the reset function desired after tripping.

After reset, the VLT frequency converter can be restarted.

Description of choice:

If *Manual reset* [0] is selected, reset must be effected via the [RESET] key or via the digital inputs.

If the VLT frequency converter is to carry out an automatic reset (1-10 times) after tripping, select data value [1]-[10].



NB! The internal AUTOMATIC RESET counter is reset 10 minutes after the first AUTOMATIC RESET has occurred.

Warning: The motor may start without warning.

Function:

0 - 10 sec.

Value:

This parameter allows setting of the time from tripping until the automatic reset function begins.

It is assumed that automatic reset has been selected in parameter 405.

Description of choice:

406 Automatic restart time (AUT RESTART TIME)

Set the desired time.

407 Mains failure (MAINS FAILURE)	
Value:	
★ No function (NO FUNCTION)	[0]
Controlled ramp-down	
(CONTROL RAMP DOWN)	[1]
Controlled ramp-down and trip	
(CTRL: RAMP DOWN-TRIP)	[2]
Coasting (COASTING)	[3]
Kinetic back-up (KINETIC BACKUP)	[4]

Function:

Using the mains failure function, it is possible to ramp down the load to 0 Hz if the mains supply to the VLT frequency converter fails.

In parameter 450 Mains voltage during mains fault, the voltage limit must be set at which the Mains fault function is to be active.

This function can also be activated by selecting Mains failure inverted on a digital input.

When Kinetic backup [4] is selected, the ramp function in parameter 206-212 is deactivated.

Description of choice:

Select No function [0] if this function is not required. If Controlled ramp-down [1] is selected, the motor will ramp via the quick-stop ramp set in parameter 212. If the supply voltage is re-established during rampdown, the VLT frequency converter will start up again. If Controlled ramp-down and trip [2] is selected, the motor will ramp via the quick-stop ramp set in parameter 212.

At 0 Hz the VLT frequency converter will trip (ALARM 36, mains failure). If the supply voltage is reestablished during ramp-down, the VLT frequency converter will continue the guick-stop ramp and trip. If Coasting [3] is selected, the VLT frequency converter will turn off the inverters and the motor will start coasting.

Parameter 445 Flying motor must be active, so that if the supply voltage is re-established, the VLT frequency converter will be able to catch the motor and start up again.

If Kinetic back-up [4] is selected, the VLT frequency converter will try to utilise the energy from the load to maintain a constant intermediate circuit voltage. If the supply voltage is re-established, the VLT frequency converter will start up again.

408	Quick discharge	
	(QUICK DISCHARGE)	
Valu	ie:	
r No	ot possible (DISABLE)	[0]
Po	ssible (ENABLE)	[1]

Function:

The option is given of quickly discharging the intermediate circuit capacitors by means of an external resistor.

Description of choice:

This function is only active in extended units, since it requires the connection of external 24 V DC and a brake resistor or discharge resistor; otherwise, the data selection is limited to Disable [0]. This function can be activated by selecting a digital input signal for Mains failure inverted. Select Disable if this function is not required. Select Enable and connect 24 V DC external supply and a brake/discharge resistor. See description on page 71.

409 Trip delay torque	
(TRIP DELAY TORQ.)	
Value:	
0 - 60 sec. (OFF)	★ OFF

Function:

When the VLT frequency converter registers that the output torque has increased up to the torque limits (parameters 221 and 222) in the set time, cutting out is effected when that time has passed.

Description of choice:

Select how long the VLT frequency converter is to be able to run at the torque limit before cutting out. 60 sec. = OFF means that the time is infinite; however, the thermal VLT monitoring will still be active.

Dantosa

410 Trip delay-inverter (INV.FAULT DELAY)

Value:

0 - 35 sec.

★ Depends on type of unit

Function:

When the VLT frequency converter registers an overvoltage in the set time, cutting out is effected after that time has passed.

Description of choice:

Select how long the VLT frequency converter is to be able to run at overvoltage before cutting out.



NB!

If this value is reduced from the factory setting, the unit may report a fault when the mains voltage is turned on.

411 Switching frequency (SWITCH FREQ.)

Value:

★ Depends on the unit output.

Function:

The set value determines the switching frequency of the inverter. If the switching frequency is changed, this may help to minimize possible acoustic noise from the motor.



NB!

The output frequency of the VLT frequency converter can never assume a value higher than 1/10 of the switching frequency.

Description of choice:

When the motor is running, the switching frequency is adjusted in parameter 411 until the frequency has been obtained at which the motor is as low-noise as possible.

See also parameter 446 - switching pattern. See derating in the Design Guide.



NB!

Switching frequencies higher than 3.0 kHz (4.5 kHz for 60° AVM) lead to automatic derating of the maximum output of the VLT frequency converter.

412 Output frequency dependent switching

frequency	
(VAR CARRIER FREQ)	
Value:	
 Not possible (DISABLE) 	[0]
Possible (ENABLE)	[1]

Function:

This function makes it possible to increase the switching frequency at a falling output frequency. Used in applications with square torque characteristics (centrifugal pumps and fans) in which the load declines depending on the output frequency. However, the maximum switching frequency is determined by the value set in parameter 411.

Description of choice:

Select Not possible [0] if a permanent switching frequency is desired.

Set the switching frequency in parameter 411. If Possible [1] is selected the switching frequency will decline at an increasing output frequency.

[0]
[1]

Function:

This parameter allows connection of the overmodulation function for the output voltage.

Description of choice:

Off means that there is no overmodulation of the output voltage, which means that torque ripple on the motor shaft is avoided. This can be a good feature, e.g. on grinding machines.

On means that an output voltage can be obtained which is greater than the mains voltage (up to 15%).

^{★ =} factory setting. () = display text [] = value for use in communication via serial communication port

Dantos

414 Minimum feedback	
(MIN. FEEDBACK)	
Value:	
-100,000.000 - Max. feedback	★ 0.000

Function:

Parameters 414 and 415 are used to scale the display text to make it show the feedback signal as the actual unit proportional to the signal on the input. This value should be 10% higher than, par. 205 *Maximum reference*, to keep the VLT frequency converter from integrating as a response to a possible offset fault.

This value will be displayed if *Feedback [unit]* [3] has been selected in one of parameters 009-012 and in the display mode. Choose the feedback signal unit in parameter 416.

Used together with Speed control, closed loop; Process control, closed loop and Torque control, speed feedback (parameter 100).

Description of choice:

Is only active when parameter 203 has been set to *Min-Max* [0].

Set the value to be shown on the display when *Mini*mum feedback is obtained on the selected feedback input (parameter 308 or 314).

The minimum value can be limited by the choice of configuration (parameter 100) and reference/feedback range (parameter 203).

If *Speed control, closed loop* [1] has been selected in parameter 100, minimum feedback cannot be set under 0.

415 Maximum feedback	
(MAX. FEEDBACK)	
Value:	
Min. feedback - 100.000.000	★ 1,500,000

Function:

See description of parameter 414.

Description of choice:

Set the value to be shown on the display when Maximum feedback is obtained on the selected feedback input (parameter 308 or 314).

The maximum value can be limited by the choice of configuration (parameter 100).

416 Reference/feedback unit				
	· (REF/FE	DB. U	NIT)	
٧	/alue:			
	NO UNIT	[0]	t/min	[21]
★	%	[1]	t/h	[22]
	PPM	[2]	m	[23]
	RPM	[3]	Nm	[24]
	bar	[4]	m/s	[25]
	CYCLE/min	[5]	m/min	[26]
	PULSE/s	[6]	°F	[27]
	UNITS/s	[7]	in wg	[28]
	UNITS/min	(8)	gal/s	[29]
	UNITS/h	[9]	ft³/s	[30]
	°C	[10]	gal/min	[31]
	Pa	[1 1]	ft³/min	[32]
	l/s	[12]	gal/h	[33]
	m³/s	[13]	ft³/h	[34]
	l/min	[14]	lb/s	[35]
	m³/min	[15]	lb/min	[36]
	l/h	[16]	lb/h	[37]
	m³/h	[17]	lb ft	[38]
	kg/s	[18]	ft/s	[39]
	kg/min	[19]	ft/min	[40]
	kg/h	[20]		

Function:

Choose among different units to be shown on the display.

This unit is also used directly in *Process control,* closed loop as a unit for *Minimum/Maximum refe*rence (parameters 204/205) and *Minimum/Maximum* feedback (parameters 414/415).

The possibility of choosing a unit in parameter 416 will depend on the choices made in the following parameters:

Par. 002 Local/remote control.

Par. 013 Local control/config. as par. 100. Par. 100 Configuration.

Select parameter 002 as Remote control

If parameter 100 is selected as *Speed control, open loop* or *Torque control, open loop*, the unit selected in parameter 416 can be used in displays (par. 009-12 *Feedback [unit]*) of process parameters. The process parameter to be displayed can be connected in the form of an external analogue signal to terminal 53 (par. 308: *Feedback signal*) or terminal 60 (par. 314: *Feedback signal*), as well as in the form of a pulse signal on terminal 33 (par 307: *Pulse feedback*). Note: The reference can only be shown in Hz (*Speed control, open loop*) or Nm (*Torque control, open loop*).

[21]

Special functions

Dantoss

Function, cont.:

If par. 100 is selected as *Speed control, closed loop,* parameter 416 is not active, since both reference and feedback are always shown as RPM.

If parameter 100 is selected as *Process control*, *closed loop*, the unit selected in parameter 416 will be used when displaying both reference (par. 009-12: *Reference [unit]*) and feedback (par 009-12: *Feedback [unit]*).

Scaling of the display indication as a function of the selected range (par. 309/310, 312/313, 315/316, 327 and 328) for a connected, external signal is effected for a reference in parameters 204 and 205 and for feedback in parameters 414 and 415.

Select parameter 002 as Local control

If parameter 013 is chosen as *LCP control and open loop* or *LCP digital control and open loop*, the reference will be given in Hz, regardless of the choice made in parameter 416. A feedback or process signal connected to terminal 53, 60 or 33 (pulse), will, however, be displayed in the form of the unit selected in parameter 416. If parameter 013 is chosen as *LCP control/as par. 100* or *LCP digital control/as par. 100*, the unit will be as described above under parameter 002, Remote-control.

NB! The above applies to display of *Reference [unit]* and *Feedback [unit]*. If *Reference [%]* or *Feedback [%]* is selected, the value displayed will be in the form of a percentage of the selected range.

Description of choice:

Select the desired unit for the reference/feedback signal.

417 Speed PID proportional gain (SPEED PROP GAIN) Value:

- 0.000 (OFF) 0.150

Function:

Proportional gain indicates how many times the fault (deviation between the feedback signal and the setpoint) is to be amplified. Used together with *Speed control, closed loop* (parameter 100).

★ 0.015

Description of choice:

Quick control is obtained at high amplification, but if the amplification is too high, the process may become unstable in the case of overshooting.

418 Speed PID integral time (SPEED INT. TIME)

Value:

2.00 - 999.99 ms (1000 = OFF) ★ 8 ms

Function:

The integral time determines how long the PID regulator takes to correct the error. The greater the error, the quicker the gain increases. The integral time results in a delay of the signal and thus has a dampening effect. Used together with *Speed control, closed loop* (parameter 100).

Description of choice:

Quick control is obtained through a short integral time.

However, if this time is too short, it can make the process unstable.

If the integral time is long, major deviations from the required reference may occur, since the process regulator will take long to regulate if an error has occurred.

Dantos

419 Speed PID differential time	
(SPEED DIFF. TIME)	
Value:	
0.00 (OFF) - 200.00 ms	★ 30 ms

Function:

The differentiator does not react to a constant error. It only provides a gain if the error changes. The quicker the error changes, the stronger the gain from the differentiator will be.

The gain is proportional to the speed at which errors change.

Used together with Speed control, closed loop (parameter 100).

Description of choice:

Quick control is obtained by a long differential time. However, if this time is too long, it can make the process unstable.

When the differential time is 0 ms, the D-function is not active (OFF).

420 Speed PID D-gai	n limit
(SPEED D-GAIN	LIMIT)
Value:	
5.0 - 50.0	★ 5.0

Function:


It is possible to set a limit for the gain provided by the differentiator. Since the D-gain increases at higher frequencies, limiting the gain may be useful. This enables obtaining a pure D-link at low frequencies and a constant D-link at higher frequencies. Used together with Speed control, closed loop (parameter 100).

Description of choice: Select the desired gain limit.

421 Speed PID lowpass filter time (SPEED FILT. TIME) Value: ~ ~ ~ ★ 10 ms

Function:

Oscillations on the feedback signal are dampened by a lowpass filter so as to reduce their influence on control. This might be an advantage, e.g. if there is a great amount on noise on the system. See drawing. Used together with Speed control, closed loop and Torque control, speed feedback (parameter 100).



Description of choice:

If a time constant (r) e.g. of 100 ms is programmed, the cut-off frequency for the lowpass filter will be 1/0.1 = 10 RAD/sec., corresponding to $(10/2 \times \pi) =$ 1.6 Hz. This means that the PID regulator will only regulate a feedback signal that varies by a frequency of less than 1.6 Hz. If the feedback signal varies by a higher frequency than 1.6 Hz, the PID regulator will not react.

Danfoss

422 U 0 voltage at 0 Hz (U0 VOLTAGE (0HZ)) Value:

★ 20.0 volt


0.0 - parameter 103

Function:

Parameters 422-432 can be used together with Special motor characteristics (par. 101). It is possible to make a U/f characteristic on the basis of six definable voltages and frequencies.

Description of choice:

Set the desired voltage at 0 Hz. See the below drawing.



423 U 1 voltage

(U1 VOLTAGE)

Value:

0.0 - U_{VLT.MAX}

parameter 103

Function:

This parameter sets the Y-value of the 1st break point.

Description of choice:

Set the voltage desired at the F1 frequency set in parameter 424.

See drawing for parameter 422.

424 F 1 frequency (F1 FREQUENCY)

Value:

★ parameter 104

Function:

0.0 - parameter 426

This parameter sets the X-value of the 1st break point.

Description of choice: Set the frequency desired at the U1 voltage set in parameter 423. See drawing for parameter 422.

425 U 2 voltage (U2 VOLTAGE)

Value:

0.0 - U_{VLT,MAX}

★ parameter 103

Function:

This parameter sets the Y-value of the 2nd break point.

Description of choice:

Set the voltage desired at the F2 frequency set in parameter 426. See drawing for parameter 422.

426 E 2 frequency (F2 FREQUENCY)

Value:

parameter 424 - parameter 428★ parameter 104

Function:

This parameter sets the X-value of the 2nd break point.

Description of choice:

Set the frequency desired at the U2 voltage set in parameter 425.

See drawing for parameter 422.

427 U 3 voltage (U3 VOLTAGE)

Value:

0.0 - U_{VLT,MAX}

★ parameter 103

Function:

This parameter sets the Y-value of the 3rd break point.

Description of choice:

Set the voltage desired at the F3 frequency set in parameter 428. See drawing for parameter 422.

Dantos

Value:

parameter 426 - parameter 430 * parameter 104

Function:

This parameter sets the X-value of the 3rd break point.

Description of choice:

Set the frequency desired at the U3 voltage set in parameter 427.

See drawing for parameter 422.

429 U 4 voltage (U4 VOLTAGE)

Value:

Function: This parameter sets the Y-value of the 4th break point.

Description of choice: Set the voltage desired at the F4 frequency set in parameter 430. See drawing for parameter 422.

430 F 4 frequency (F4 FREQUENCY)

Value: parameter 428 - parameter 432★ parameter 104

Function: This parameter sets the X-value of the 4th break point

Description of choice: Set the frequency desired at the U4 voltage set in parameter 429. See drawing for parameter 422.

431 U 5 voltage (U5 VOLTAGE)

Value:

Function:

This parameter sets the Y-value of the 5th break point.

Description of choice:

Set the voltage desired at the F5 frequency set in parameter 432.

432 F 5 frequency (F5 FREQUENCY) Value:
parameter 430 - 1000 Hz * parameter 104
Function: This parameter sets the X-value of the 5th break point. This parameter is not limited by parameter 200.
Description of choice: Set the frequency desired at the U5 voltage set in pa- rameter 431. See drawing for parameter 422.

433 Torque control, ope	n loop
proportional gain	.
(TOR-OL PROP GA	IN)
Value:	
0 (Off) - 500%	★ 100%

Function: The proportional gain indicates how many times the error (the deviation between feedback signal and set point) is to be applied.

Used together with *Torque control, open loop* (parameter 100).

Description of choice: Fast control is obtained with a high gain, but if the gain is too high, the process may become unstable.

Dantoss

434 Torque control, ope	n loop
Integration time	
(TOR-OL INT.TIME)	
Value:	
0.002 - 2.000 sec.	★ 0.02 sec.

Function:

The integrator provides an increasing gain if there is a constant error between reference and current measuring signal. The greater the error, the quicker the gain increases. The integral time is the time required by the integrator to reach the same gain as the proportional gain.

Used together with Torque control, open loop (parameter 100).

Description of choice:

Fast control is obtained if the integral time is short. However, this time may become too short, in which case the process may become unstable.

4	37 Process PID Normal/inverse control	
	(PROC NO/INV CTRL)	
V	/alue:	
×	Normal (NORMAL)	[0]
	Inverse (INVERSE)	[1]

Function:

It is possible to choose whether the process regulator is to increase/reduce the output frequency. This is done by having a difference between the reference signal and the feedback signal. Used together with Process control, closed loop (parameter 100).

Description of choice:

If the VLT frequency converter is to reduce the output frequency in case the feedback signal increases, select Normal [0].

If the VLT frequency converter is to increase the output frequency in case the feedback signal increases, select Inverse [1].

438 Process PID anti windup	
(PROC ANTI WINDUP)	
Value:	
Off (DISABLE)	[0]
★ On (ENABLE)	[1]

Function:

It is possible to select whether the process regulator is to continue regulating on an error even if it is not possible to increase/reduce the output frequency. Used together with Process control, closed loop (parameter 100).

Description of choice:

The factory setting is *Enable* [1], which means that the integration link is adjusted in relation to the actual output frequency if either the current limit or the max./ min. frequency has been reached. The process regulator will not engage again until either the error is zero or its sign has changed.

Select Disable [0] if the integrator is to continue integrating on an error, even if it is not possible to remove the fault by such control.



NB!

If Disable [0] is selected, it will mean that when the error changes its sign, the integrator will first have to integrate down from the level obtained as a result of the former error, before any change to the output frequency occurs.

439 Process PID start frequency (PROC START VALUE)

Value:

f_{MIN}-f_{MAX} (parameter 201 and 202) ★parameter 201

Function:

When the start signal comes, the VLT frequency converter will react in the form of Speed control, open loop following the ramp. Only when the programmed start frequency has been obtained, will it change over to Process control, closed loop. In addition, it is possible to set a frequency that corresponds to the speed at which the process normally runs, which will enable the required process conditions to be reached sooner. Used together with Process control, closed loop (parameter 100).

Description of choice:

Set the required start frequency.

NB!

If the VLT frequency converter is running at the current limit before the desired start frequency is obtained, the process regulator will not be activated. For the regulator to be activated anyway, the start frequency must be lowered to the required output frequency. This can be done during operation.

Dantos

440 Process PID proportional gain	
(PROC. PROP. GAIN)	
Value:	
0.00 - 10.00	★ 0.01

Function:

The proportional gain indicates the number of times the error between the set point and the feedback signal is to be applied.

Used together with *Process control, closed loop* (parameter 100).

Description of choice:

Quick control is obtained by a high gain, but if the gain is too high, the process may become unstable.

441 Process PID integral time	
(PROC. INTEGR. T.)	
Value: 0.01 - 9999.99 sec. (OFF)	★ OFF

Function:

The integrator provides an increasing gain at a constant error between the set point and the feedback signal. The greater the error, the quicker the gain will increase. The integral time is the time needed by the integrator to reach the same gain as the proportional gain.

Used together with *Process control, closed loop* (parameter 100).

Description of choice:

Quick control is obtained at a short integral time. However, this time may become too short, which can make the process unstable.

If the integral time is long, major deviations from the required set point may occur, since the process regulator will take a long time to regulate in relation to a given error.

442 Process PID differentiation time (PROC. DIFF. TIME) Value:

0.00 (OFF) - 10.00 sec. ***** 0.00 sec.

Funktion:

The differentiator does not react to a constant error. It only provides a gain when the error changes. The quicker the error changes, the stronger the gain from the differentiator.

The gain is proportional to the speed at which the error changes.

Used together with *Process control, closed loop* (parameter 100).

Description of choice:

Quick control is obtained with a long differentiation time. However, this time may become too long, which can make the process unstable.

443 Process PID diff. gain limit	_
(PROC. DIFF. GAIN)	
Value:	
5.0 - 50.0	★ 5.0

Function:

It is possible to set a limit for the differentiator gain. The differentiator gain will increase if there are fast changes, which is why it can be beneficial to limit this gain, thereby obtaining a pure differentiator gain at slow changes and a constant differentiator gain where quick changes to the error occur.

Used together with *Process control, closed loop* (parameter 100).

Description of choice: Select a limit to differentiator gain as required.

Dantos

444	Process PID lowpass filter time	
	(PROC FILTER TIME)	

Value:

★ 0.01 sec.

0.01 - 10.00

Function:

Oscillations on the feedback signal are dampened by the lowpass filter in order to reduce their impact on the process control. This can be an advantage e.g. if there is a lot of noise on the signal. Used together with Process control, closed loop (parameter 100).

Description of choice:

Select the desired time constant (τ). If a time constant (τ) of 100 ms is programmed, the break frequency for the lowpass filter will be 1/0.1 = 10 RAD/sec., corresponding to $(10/2 \times \pi) = 1.6$ Hz. The process regulator will thus only regulate a feedback signal that varies by a frequency lower than 1.6 Hz. If the feedback signal varies by a higher frequency than 1.6 Hz, the Process regulator will not react.

445 Flying start (FLYING START) Value: [0] ★ Off (DISABLE) [1] On (ENABLE)

Function:

This function makes it possible to 'catch' a motor, which is spinning freely because of a mains drop-out .

Description of choice:

Select Disable if this function is not required. Select Enable if the VLT frequency converter is to be able to 'catch' and catch and control a spinning motor. See also the explanation of this function offered on page 73.

446 Switching pattern	
(SWITCH PATTERN)	
Value:	
60° AVM (60° AVM)	[0]
★ SFAVM (SFAVM)	[1]

Function:

Choose between two different switching patterns: 60° AVM and SFAVM.

Description of choice

Select 60° AVM if the option of using a switching frequency up to 14/10 kHz is required. Derating of the rated output current l_{VLLN} is effected from a switching frequency of 4.5 kHz.

Select SFAVM if the option of using a switching frequency up to 5/10 kHz is required. Derating of the rated output current IVLIN is effected from a switching frequency of 3.0 kHz.

447 Torque, speed feedback	
Torque compensation	
(TOR-SF COMP.)	
Value:	
-100 - 100%	★ 0%

Function:

This parameter is only used if Torque control, speed feedback [5] has been selected in parameter 100. Torque compensation is used in connection with calibration of the VLT frequency converter. By adjusting parameter 447, Torque compensation, the output torque can be calibrated.

See procedure for torque calibration on page 57.

Description of choice:

Set the required value.

448 Torque, speed feedback	
Gear ratio with encoder	
(TOR-SF GEARRATIO)	
Value:	
0.001 - 100.000	★ 1.000

Function:

This parameter is only used if Torque control, speed feedback [5] has been selected in parameter 100. If an encoder has been fitted to the gearshaft, a gear ratio must be set - otherwise the VLT frequency converter will not be able to calculate the output frequency correctly.

For a gear ratio of 1:10 (gearing down of motor rpm), set the parameter value to 10.

If the encoder has been fitted directly on the motor shaft, set the gear ratio to 1.00.

Description of choice: Set the required value.

449 Torque, speed feedback Friction loss (TOR-SF FRIC. LOSS)

Value:

0.00 - 50.00% of rated motor torque **★**0.00%

Function:

This parameter is only used if Torque control, speed feedback [5] has been selected in parameter 100.

Set the friction loss as a fixed percentage loss of rated torque. In motor operation, the friction loss will be added to the torque, while in generating operation it will be deducted from the torque.

See procedure for torque calibration on page 57.

Description of choice: Set the required value.

450 Mains voltage at mains fault	
(MAINS FAIL VOLT.)	
Value:	
180-240 V for 200-240 V units	* 180
342-500 V for 380-500 V units	★ 342

Function:

This is where to set the voltage level at which parameter 407 Mains fault is to be activated. The voltage level for activating the mains fault functions must be lower than the rated mains voltage supplied to the VLT frequency converter. As a rule of thumb, parameter 450 can be set to 10% below the rated mains voltage.

Description of choice:

Set the level for activating mains fault functions.



NB!:

If this value is set at too high a level, the mains fault function set in parameter 407 can be activated, even if the mains voltage is present.

Danfoss

453	Speed closed loop gear ratio	
	(SPEED GEARRATIO)	

Value: 0.01 - 100.00

★ 1.00

Function:

This parameter is only used if *Speed control, closed loop* [1] has been selected in parameter 100 *Configuration.*

If the feedback has been fitted to the gearshaft, a gear ratio must be set - otherwise the VLT frequency converter will not be able to detect an encoder loss.

For a gear ratio of 1:10 (gearing down of motor rpm), set the parameter value to 10.

If the encoder has been fitted directly on the motor shaft, set the gear ratio to 1.00.

Description of choice: Set the required value.

454 Dead time compensation	
(DEADTIME COMP.)	
Value:	
Off (OFF)	[0]
★ On (ON)	[1]

Function:

The active inverter dead time compensation which is part of the VLT 5000 control algorithm (VCC+) is causing instability at standstill when working in closed loop control. The purpose of this parameter is switching off the active dead time compensation to avoid instability.

Description of choice:

Select Off [0] to inactivate the dead time compensation.

Select On [1] to activate the dead time compensation.

Dantos

5	02	Coasting (COASIING SELECT)	
5	03	Quick-stop (Q STOP SELECT)	
5	04	DC-brake (DC BRAKE SELECT)	
5	05	Start (START SELECT)	
5	06	Reversing (REVERSING SELECT)	
5	07	Selection of Setup (SETUP SELECT)	
5	08	Selection of speed (PRES.REF. SELECT)
٧	'alu	e:	
	Dig	gital input (DIGITAL INPUT)	[0]
	Βı	IS (SERIAL PORT)	[1]
		gic and (LOGIC AND)	[2]

Function:

Parameters 502-508 allow a choice between controlling the VLT frequency converter via the terminals (digital input) and/or via the bus.

If Logic and or Bus is selected, the command in question can only be activated if transmitted via the serial communication port. In the case of Logic and, the command must additionally be activated via one of the digital inputs.

Description of choice:

Digital input [0] is selected if the control command in question is only to be activated via a digital input. Bus [1] is selected if the control command in question is only to be activated via a bit in the control word (serial communication).

Logic and [2] is selected if the control command in question is only to be activated when a signal is transmitted (active signal = 1) via both a control word and a digital input.

500 Address (BUS ADDRESS)

Value:

1 - 126

Function:

This parameter allows specification of the address of each VLT frequency converter. This feature is used in connection with PLC/PC connection.

* 1

Description of choice:

The individual VLT frequency converters can be given an address between 1 and 126. The address 0 is used if a master (PLC or PC) wishes to send a telegram that is to be received by all VLT frequency converters connected to the serial communication port at the same time. In this case, the VLT frequency converter will not acknowledge receipt. If the number of units connected (VLT frequency converters + master) exceeds 31, a repeater is required. Parameter 500 cannot be selected via the serial communication port.

5	01 Baudrate (BAUDRATE)	
Ī	/alue:	
	300 Baud (300 BAUD)	[O]
	600 Baud (600 BAUD)	[1]
	1200 Baud (1200 BAUD)	[2]
	2400 Baud (2400 BAUD)	[3]
	4800 Baud (4800 BAUD)	[4]
\star	9600 Baud (9600 BAUD)	[5]

Function:

This parameter is for programming the speed at which data is to be transmitted via the serial connection. Baud rate is defined as the number of bits transferred per second.

Description of choice:

The transmission speed of the VLT frequency converter is to be set at a value that corresponds to the transmission speed of the PLC/PC. Parameter 501 cannot be selected via the serial port, RS 485. The data transmission time proper, which is determined by the set baud rate, is only part of the total communication time.

Danfoss

Digital input		1
505-508	Bus	Control command
0	0	0
0	1	0
1	0	0
1	1	1

Logic or [3] is selected if the control command in question is to be activated when a signal is given (active signal = 1) either via a control word or via a digital input.

Digital input

505-508	Bus	Control command
0	0	0
0	1	1
1	0	1
1	1	1

NB!

Parameters 502-504 deal with stop functions see examples regarding 502 (coasting) below. Active stop command "0".

Parameter 502 = Logic and

Digital input	Bus	Control command
0	0	1 Coasting
0	1	0 Motor running
1	0	0 Motor running
1	1	0 Motor running

Parameter 502 = Logic or

Digital input	Bus	Control command
0	0	1 Coasting
0	1	1 Coasting
1	0	1 Coasting
1	1	0 Motor running

503 Quick-stop (Q STOP SELECT) Value: Digital input (DIGITAL INPUT) Bus (SERIAL PORT) Logic and (LOGIC AND) ★ Logic or (LOGIC OR)

Function:

See description under parameter 502.

Description of choice:

See description under parameter 502.

504 DC-brake (DC BRAKE SELECT)	
Value:	
Digital input (DIGITAL INPUT)	[0]
Bus (SERIAL PORT)	[1]
Logic and (LOGIC AND)	[2]
★ Logic or (LOGIC OR)	[3]

Function:

See description under parameter 502.

Description of choice:

See description under parameter 502.

505 Start (START SELECT)Value:Digital input (DIGITAL INPUT)Bus (SERIAL PORT)Logic and (LOGIC AND)★ Logic or (LOGIC OR)

Function:

See description under parameter 502.

Description of choice: See description under parameter 502.

Danfoss

	VLT' 5000 Series
506 Dovorcing (DEI/EDSING SELECT)	500 Rus ing 1 (RUS 10C 1 EDEO)
506 Reversing (REVERSING SELECT) Value:	509 Bus jog 1 (BUS JOG 1 FREQ.) Value:
★ Digital input (DIGITAL INPUT) [0]	0.0 - parameter 202 + 10.0
Bus (SERIAL PORT) [1]	
Logic and (LOGIC AND) [2]	a company a subject of the second statement of the second statement of the second statement of the second state
Logic or (LOGIC OR) [2]	Function:
	This is where to set a fixed speed (jog) that is acti-
in an searchair a searchanairtean an searchairtean an searchairtean an searchairtean a searchairtean a searchai Tha searchairtean an searchairtean an searchairtean an searchairtean an searchairtean an searchairtean an search	vated via the serial communication port.
Function:	This function is the same as in parameter 213.
See description under parameter 502.	•
	Description of choice:
Description of choice:	The jog frequency fJog can be selected in the range
See description under parameter 502.	between fmin (parameter 201) and fmax (parameter 20
· · · · · · · · · · · · · · · · · · ·	
· ·	
507 Selection of Setup (SETUP SELECT)	510 Bus jog 2 (BUS JOG 2 FREQ.)
Value:	Value:
Digital input (DIGITAL INPUT) [0]	0.0 - parameter 202 * 10.0
Bus (SERIAL PORT) [1]	
Logic and (LOGIC AND) [2]	Eunction:
★ Logic or (LOGIC OR) [3]	This is where to set a fixed speed (jog) that is acti-
	vated via the serial communication port.
Function:	This function is the same as in parameter 213.
See description under parameter 502.	
	Description of choice:
Description of choice:	The jog frequency f_{JOG} can be selected in the range
See description under parameter 502	between f _{MIN} (parameter 201) and f _{MAX} (parameter 202)
· · · · · · · · · · · · · · · · · · ·	· · · · ·
508 Selection of speed (PRES.REF. SELECT)	512 Telegram profile (TELEGRAM PROFILE)
Value:	Value:
Digital input (DIGITAL INPUT)	Profidrive (PROFIDRIVE)
Bus (SERIAL PORT) [1]	★ FC Drive (FC DRIVE)
Logic and (LOGIC AND) [2]	
★ Logic or (LOGIC OR) [3]	Cupction
	Function:
a	There is a choice of two different control word
Function:	profiles.
See description under parameter 502.	Sela Maerooren (ana Sanandan Mari Kons), antar (ana sanandossonosonosonosonosonosonosonosonosonana ana ana ana
i. Funkungana funku, manayaan kuna funa funa ya mangadi kungani ingi kati kati kati kati kati kati kati kat	Description of choice:
Description of choice	Select the desired control word profile.
See description under parameter 502.	See Serial communication, in the Design Guide for
· · · · · ·	further information about the control word profiles.
•	
	· · · · · · · · · · · · · · · · · · ·

★ = factory setting. () = display text [] = value for use in communication via serial communication port →

ÿ

. .

Serial communication

133

Dantoss

513 Bus time interval (BUS TIMEOUT TIME)

Value:

1 - 99 sec.

Function:

This parameter sets the maximum time expected to pass between the receipt of two consecutive telegrams. If this time is exceeded, the serial communication is assumed to have stopped and the desired reaction is set in parameter 514.

★ 1 sec.

Description of choice:

Set the desired time.

514 Bus time interval function (BUS TIMEOUT FUNC)

Value:

10.00	
★ Off (OFF)	[0]
Freeze output (FREEZE OUTPUT)	[1]
Stop (STOP)	[2]
Jogging (JOGGING)	[3]
Max. speed (MAX SPEED)	[4]
Stop and trip (STOP AND TRIP)	[5]

Function:

This parameter selects the desired reaction of the VLT frequency converter when the set time for bus timeout (parameter 513) has been exceeded.

If choices [1] to [5] are activated, relay 01 and relay 04 will be de-activated.

If more time-outs occur at the same time the VLT frequency converter will give the following priority to the time-out function:

- 1. Parameter 318 Function after time out
- 2. Parameter 346 Function after encoder loss
- 3. Parameter 514 Bus time interval function.

Description of choice:

The output frequency of the VLT frequency converter can: be frozen at the present value, be frozen at the reference, go to stop, go to jogging frequency (parameter 213), go to max. output frequency (parameter 202) or stop and activate a trip.

515 Data read-out: Reference % (REFERENCE)

Value:

Unit: %

Function:

This parameter can be read out via the serial communication port and via the display in Display mode, see also parameters 009-012.

Description of choice:

The value shown corresponds to the total reference (sum of digital/analogue/preset/bus/freeze ref./catchup and slow-down).

This value is updated every 80 ms.

516 Data read-out: Reference unit (REFERENCE [UNIT])

Value:

Unit: Hz, Nm or rpm.

Function:

This parameter can be read out via the serial communication port and via the display in Display mode, see also parameters 009-012. See also parameters 205 and 416, if required.

Description of choice:

Gives the present value of terminals 17/29/53/54/60 in the unit resulting from the choice of configuration in parameter 100 (Hz, Nm or rpm) or in parameter 416. This value is updated every 80 ms.

^{★ =} factory setting. () = display text [] = value for use in communication via serial communication port

Dantos

517 Data read-out: Feedback (FEEDBACK [UNIT])

Value:

Unit: to be selected via parameter 416.

Function:

This parameter can be read out via the serial communication port and via the display in Display mode, see also parameters 009-012.

Description of choice:

Indicates the status value of terminals 33/53/60 at the unit/scale selected in parameters 414, 415 and 416.

This value is updated every 80 ms.

518 Data read-out: Frequency

(FREQUENCY)

Value:

Unit: Hz

Function:

This parameter can be read out via the serial communication port and via the display in Display mode, see also parameters 009-012.

Description of choice:

The value shown corresponds to the actual motor frequency f_M (without resonance dampening). This value is updated every 80 ms.

519 Data read-out: Frequency x Scaling (FREQUENCY x SCALE)

Value:

Unit: (Hz x Scale)

Function:

This parameter can be read out via the serial communication port and via the display in Display mode, see also parameters 009-012.

Description of choice:

The value shown corresponds to the actual motor frequency f_M (without resonance dampening) multiplied by a factor (scaling) set in parameter 008. This value is updated every 80 ms.

520 Data read-out: Current (MOTOR CURRENT)

Value:

Unit: (Amp x 100)

Function:

This parameter can be read out via the serial communication port and via the display in Display mode, see also parameters 009-012.

Description of choice:

The value shown corresponds to the given motor current measured as a mean value I_{RMS} . The value is filtered, which means that approx. 1.3 seconds may pass from an input value changes until the data read-out changes values. This value is updated every 80 ms.

521 Data read-out: Torque

(TORQUE) Value:

Unit: %

Function:

This parameter can be read out via the serial communication port and via the display in Display mode, see also parameters 009-012.

Description of choice:

The value shown is the torque, with sign, supplied to the motor shaft. The value is given as a percentage of the rated torque.

There is not exact linearity between 160% motor current and torque in relation to the rated torque. Some motors supply more torque than that. Consequently, the min. value and the max. value will depend on the max. motor current as well as the motor used.

The value is filtered, which means that approx. 1.3 seconds may pass from an input changes value until the data read-out changes values. This value is updated every 80 ms.

NB!

If the setting of the motor parameters does not match the motor applied, the read-out values will be inaccurate and may become negative, even if the motor is not running or is producing a positive torque.

Dantoss

522 Data read-out: Power, kW (POWER (kW))

Value:

Unit: kW

Function:

This parameter can be read out via the serial communication port and via the display in Display mode, see also parameters 009-012.

Description of choice:

The value shown is calculated on the basis of the actual motor voltage and motor current. The value is filtered, which means that it may take approx. 1.3 seconds from an input value changes until the data read-out changes values. This value is updated every 80 ms.

523 Data read-out: Power, HP

(POWER (hp))

Value:

Unit: HP (US)

Function:

This parameter can be read out via the serial communication port and the display in Display mode, see also parameters 009-012.

Description of choice:

The value shown is calculated on the basis of the actual motor voltage and motor current. The value is indicated in the form of HP. The value is filtered, which means that approx. 1.3 seconds may pass from an input value changes until the data read-out changes values. This value is updated every 80 ms.

524 Data read-out: Motor voltage (MOTOR VOLTAGE)

Value:

Unit: V

Function:

This parameter can be read out via the serial communication port and via the display in Display mode, see also parameters 009-012.

Description of choice:

The value shown is a calculated value used for controlling the motor. This value is updated every 80 ms.

525 Data read-out: DC link voltage (DC LINK VOLTAGE)

Value:

Unit: V

Function:

This parameter can be read out via the serial communication port and via the display in Display mode, see also parameters 009-012.

Description of choice:

The value shown is a measured value. The value is filtered, which means that approx. 1.3 seconds may pass from an input value changes until the data read-out changes values. This value is updated every 80 ms.

526 Data read-out: Motor temp. (MOTOR THERMAL)

Value: 0 - 100%

Function:

This parameter can be read out via the serial communication port and via the display (Display mode).

Description of choice: This value is updated every 80 ms.

Dantos

527 Data read-out: VLT temp. (VLT THERMAL)

Value:

0 - 100%

Function:

This parameter can be read out via the serial communication port and via the display in Display mode, see also parameters 009-012.

Description of choice:

Only whole numbers are displayed. This value is updated every 80 ms.

528 Data read-out: Digital input (DIGITAL INPUT)

Value:

Unit: binary code

Function:

This parameter can be read out via the serial communication port and via the display in Display mode, see also parameters 009-012.

Description of choice:

The value shown indicates the signal status from the 8 digital terminals (16, 17, 18, 19, 27, 29, 32 and 33). The read-out is binary and the digit at the extreme left gives the status of terminal 16, while the digit at the extreme right gives the status of terminal 33. This value is updated every 2 ms.

529 Data read-out: Terminal 53, analogue input (ANALOG INPUT 53)

Value: Unit: V

Function:

This parameter can be read out via the serial communication port and via the display in Display mode, see also parameters 009-012.

Description of choice:

The value shown indicates the signal value on terminal 53.

The scaling (parameters 309 and 310) does not influence the read-out. Min. and max. are determined by the offset and gain adjustment of the AD-converter.

This value is updated every 20 ms.

Dantoss

530 Data read-out: Terminal 54, analogue input (ANALOG INPUT 54)

Value:

Unit: V

Function:

This parameter can be read out via the serial communication port and via the display in Display mode, see also parameters 009-012.

Description of choice:

The value shown indicates the signal value on terminal 54.

The scaling (parameters 312 and 313) does not influence the read-out. Min. and max. are determined by the offset and gain adjustment of the AD-converter. This value is updated every 20 ms.

531 Data read-out: Terminal 60, analogue input (ANALOG INPUT 60)

Value:

Unit: mA

Function:

This parameter can be read out via the serial communication port and via the display in Display mode, see also parameters 009-012.

Description of choice:

The value shown indicates the signal value on terminal 60.

The scaling (parameters 315 and 316) does not influence the read-out. Min. and max. are determined by the offset and gain adjustment of the AD-converter.

This value is updated every 20 ms.

532 Data read-out: Pulse reference (PULSE REFERENCE)

Value:

Unit: Hz

Function:

This parameter can be read out via the serial communication port and via the display in Display mode, see also parameters 009-012.

Description of choice:

The value shown indicates any pulse reference in Hz connected to one of the digital inputs. This value is updated every 20 ms.

533 Data read-out: External reference % (EXT. REFERENCE)

Value:

-200 - +200 %

Function:

This parameter can be read out via the serial communication port and via the display in Display mode, see also parameters 009-012.

Description of choice:

The value stated gives, as a percentage, the sum of external references (sum of analogue/bus/pulse). This value is updated every 20 ms.

Dantos

534 Data read-out: Status word, (STATUS WORD [HEX])

Value:

Unit: Hex code

Function:

This parameter can be read out via the serial communication port and via the display in Display mode, see also parameters 009-012.

Description of choice:

Indicates the status word transmitted via the serial communication port in Hex code from the VLT frequency converter. See the Design Guide.

535 Data read-out: Brake power/2 min. (BR. ENERGY/2min) Value:

Unit: kW

Function: This parameter can be read out via the serial communication port and via the display in Display mode, see also parameter 009-012.

Description of choice: Indicates the brake power transmitted to an external brake resistor. The mean power is calculated on an ongoing basis for the latest 120 sec.

536 Data read-out: Brake power/sec. (BRAKE ENERGY/s)

Value:

Unit: kW

Function

This parameter can be read out via the serial communication port and via the display in Display mode, see also parameters 009-012.

Description of choice:

Indicates the given brake power transmitted to an external brake resistor. Stated as an instantaneous value.

537 Data read-out: Heat s	sink
temperature	
(HEATSINK TEMP.)	
Value:	· · · · · · · · · · · · · · · · · · ·
Unit: °C	***************************************

Function: This parameter can be read out via the serial communication port and via the display in Display mode, see also parameters 009-012.

Description of choice: States the given heat sink temperature of the VLT frequency converter. The cut-out limit is $90 \pm 5^{\circ}$ C, while the unit cuts back in at $60 \pm 5^{\circ}$ C.

538 Data read-out: Alarm word, (ALARM WORD [HEX])

Value: Unit: Hex code

Function: This parameter can be read out via the serial communication port and via the display in Display mode, see also parameters 009-012.

Description of choice: States in Hex format whether there is an alarm on the VLT frequency converter. See page 160 for further information.

Dantos

539 Data read-out: VLT control word, (CONTROLWORD[HEX])

Value:

Unit: Hex code

Function:

This parameter can be read out via the serial communication port and via the display in Display mode, see also parameters 009-012.

Description of choice:

Gives the control word sent via the serial communication port in Hex code to the VLT frequency converter. See the Design Guide.

540 Data read-out: Warning word, 1

(WARN. WORD 1)

Value:

Unit: Hex code

Function:

This parameter can be read out via the serial communication port and via the display in Display mode, see also parameters 009-012.

Description of choice:

States in Hex format whether there is a warning on the VLT frequency converter. See page 160 for further information.

541 Data read-out: Extended status word Hex (EXT. STATUS WORD)

Value:

Unit: Hex code

Function:

This parameter can be read out via the serial communication port and via the display in Display mode, see also parameters 009-012.

Description of choice:

States in Hex format whether there is a warning on the VLT frequency converter. See page 160 for further information.

600 Operating data: Operating hours (OPERATING HOURS)

Value:

Unit: hours

0.0 - 130,000.0

0.0 - 130,000.0

Function:

This parameter can be read out via the serial communication port or via the display. The value cannot be reset.

Description of choice:

Indicates the number of hours in which the VLT frequency converter has been in operation. The value is updated in the VLT frequency converter every hour and saved when the unit is turned off.

601 Operating data: Hours run (RUNNING HOURS)

Value:

Unit: hours

Function:

This parameter can be read out via the serial communication port or via the display. The value can be reset via parameter 619.

Description of choice:

Indicates the number of hours in which the VLT frequency converter has been in operation since reset in parameter 619.

The value is updated in the VLT frequency converter every hour and saved when the unit is turned off.

602 Operating data: kWh	counter
(KWh COUNTER)	
Value:	
Unit: kWh	0 - depends on
the unit	

Function:

This parameter can be read out via the serial communication port or via the display. The value can be reset via parameter 618.

Description of choice:

States the kW consumption of the motor as a mean value over one hour, since the reset in parameter 618.

Dantos

603 Operating data: Number of power-up's (POWER UP'S)

Value:

Unit: number 0 - 9999

Function:

This parameter can be read out via the serial communication port or via the display.

Description of choice:

States the number of power-ups of the supply voltage to the VLT frequency converter.

604 Operating data: Number of overtemperatures (OVER TEMP'S)

Value:

Unit: number 0 - 9999

Function:

This parameter can be read out via the serial communication port or via the display.

Description of choice:

States the number of temperature faults there has been on the VLT frequency converter.

605 Operating data: Number of overvoltages (OVER VOLT'S)

Value:

Unit: number 0 - 9999

Function:

This parameter can be read out via the serial communication port or via the display.

Description of choice:

States the number of overvoltages there has been on the VLT frequency converter

606 Data log: Digital inputs (LOG: DIGITAL INP)

Value:

Unit: Decimal


Function:

Via this parameter it is possible to see up to 20 datalogs, where [0] is the latest log and [19] the oldest. Each data-log is made every 160 ms as long as a start signal has been given. If a stop signal is given, the latest 20 data-logs will be saved and the values will be available on the display. This is useful, e.g. when carrying out service after a trip. This parameter can be read out via the serial communication port or via the display.

Description of choice:

The value for the digital inputs is given as a decimal figure within the range of 0-255.

The data-log number is stated in square brackets: [1]



Free a data-log if there is a trip and release it when resetting the VLT frequency converter. Data-logging is active when the motor is running.

607 Data log: Control word (LOG: CONTROL WORD)

Value:

Unit: Decimal

Function:

See parameter 606.

Description of choice:

The value for the control word is given as a decimal figure within the range of 0-65535.

The data-log number is stated in square brackets: [1]. Data-logs are frozen if there is a trip and released when the VLT frequency converter is subsequently reset.

Data-logging is active while the motor is running.

Danfoss

608 Data log: Bus status word (LOG: BUS STAT.WD)

Value:

Unit: Decimal

Function:

See parameter 606.

Description of choice:

The value for the bus status word is given as a decimal figure within the range of 0-65535. The data-log number is stated in square brackets: [1]. Data-logs are frozen if there is a trip and released when the VLT frequency converter is subsequently reset.

Data-logging is active while the motor is running.

609 Data log: Reference (LOG: REFERENCE) Value: Unit: %

Office PC

Function:

See parameter 606.

Description of choice:

The value of the reference is stated as a % in the interval 0 - 100%.

The data-log number is stated in square brackets: [1]. Data-logs are frozen if there is a trip and released when the VLT frequency converter is subsequently reset.

Data-logging is active while the motor is running.

610 Data log: Feedback (LOG: FEEDBACK)

(LOG: FEEDBA

Value:

Depends on the choice in parameter 416.

Function:

See parameter 606.

Description of choice:

The data-log number is stated in square brackets: [1]. Data-logs are frozen if there is a trip and released when the VLT frequency converter is subsequently reset.

Data-logging is active while the motor is running.

611 Data log: Motor frequency (LOG: MOTOR FREQ)

Value:

Unit: Hz

Function: See parameter 606.

Description of choice:

The value of the motor frequency is stated as a frequency in the interval 0.0 - 999.9 Hz. The data-log number is stated in square brackets: [1]. Data-logs are frozen if there is a trip and released when the VLT frequency converter is subsequently reset.

Data-logging is active while the motor is running.

612 Data log: Motor voltage

(LOG: MOTOR VOLT) Value:

Unit: V

Function: See parameter 606.

Description of choice:

The value of the motor voltage is stated as Volts in the interval 50 - 1000 V.

The data-log number is stated in square brackets: [1]. Data-logs are frozen if there is a trip and released when the VLT frequency converter is subsequently reset.

Data-logging is active while the motor is running.

Dantos

613 Data log: Motor current

(LOG: MOTOR CURR)

Value:

Unit: Amp.

Function: See parameter 606.

Description of choice:

The value for the motor current is stated as Amps in the interval 0.0 - 999.9 A.

The data-log number is stated in square brackets: [1]. Data-logs are frozen if there is a trip and released when the VLT frequency converter is subsequently reset.

Data-logging is active while the motor is running.

614 Data log: DC link voltage (LOG: DCLINK VOLT)

Value:

Unit: Volt

Function:

See parameter 606.

Description of choice:

The value of the DC link voltage is stated as Volts in the interval 0.0 - 999.9 V.

The data-log number is stated in square brackets: [1]. Data-logs are frozen if there is a trip and released when the VLT frequency converter is subsequently reset.

Data-logging is active while the motor is running.

615 Fault log: Error code

(F.LOG: ERROR COD)

Value:

[Index 0-36]

Function:

This parameter makes it possible to see the reason why a trip occurs.

10 (0-9) log values are stored.

The lowest log number (0) contains the latest/most recently saved data value; the highest log number (9) contains the oldest data value.

Description of choice:

Given as a number code, in which the trip number refers to an alarm code that can be seen from the table on page 154.

Reset the fault log after manual initialisation.

616 Fault log: Time (F.LOG: TIME)

Value:

[Indication range 0.0 - 9999.9] Unit Hours

Function:

This parameter makes it possible to see the total number of operating hours before the trip occurred. 10 (0-9) log values are stored.

The lowest log number (0) contains the latest/most recently saved data value, while the highest log number (9) contains the oldest data value.

Description of choice: Read out as an option. Indication range: 0.0 - 9999.9. Reset the fault log after manual initialisation.

617 Fault log: Value (F.LOG: VALUE)

Value:

[Index 0.0 - 999.9]

Function:

This parameter makes it possible to see at what current or voltage a given trip occurred.

Description of choice: Read out as one value. Indication range: 0.0 - 999.9. Reset the fault log after manual initialisation.

Dantoss

618 Reset of kWh counter	
(RESET KWH COUNT)	
Value:	
A Ne react (DO NOT DESET)	10

*	No reset (DO NOT RESET)	[O]
	Reset (RESET COUNTER)	[1]

Function:

Reset to zero of kWh hour counter (parameter 602).

Description of choice:

If *Reset* [1] has been selected and when the [OK] key is pressed, the kWh counter of the VLT frequency converter is reset. This parameter cannot be selected via the serial port, RS 485.



NB! When the [OK] key has been activated, the reset has been carried out.

619 Reset of hours-run counter	
(RESET RUN. HOUR)	
Value:	
★ No reset (DO NOT RESET)	[0]
Reset (RESET COUNTER)	[1]

Function:

Reset to zero of hours-run counter (parameter 601).

Description of choice:

If *Reset* [1] has been selected and when the [OK] key is pressed, the hours-run counter of the VLT frequency converter is reset. This parameter cannot be selected via the serial port, RS 485.



NB!

When the [OK] key has been activated, the reset has been carried out.

620 Operating mode (OPERATION MODE)

Value:

Normal function (NORMAL OPERATION)	[0]
Function with de-activated inverter	
(OPER. W/INVERT DISAB)	[1]
Control card test (CONTROL CARD TEST)	[2]
Initialisation (INITIALIZE)	[3]
	Function with de-activated inverter (OPER. W/INVERT DISAB) Control card test (CONTROL CARD TEST)

Function:

In addition to its normal function, this parameter can be used for two different tests.

Also, all parameters (except parameters 603-605) can be initialised.

This function will not become active until the mains supply to the VLT frequency converter has been turned off and then turned on again.

Description of choice:

Normal function [0] is selected for normal operation with the motor in the selected application. Function with deactivated inverter [1] is selected if control is desired over the influence of the control signal over the control card and its functions - without the inverter driving the motor.

Control card test [2] is selected if control of the analogue and digital inputs, as well as the analogue, digital relay outputs and the +10 V control voltage is desired. A test connector with internal connections is required for this test.

Use the following procedure for the control card test:

- 1) Select Control card test.
- 2) Cut off the mains supply and wait for the light in the display to go out.
- 3) Insert the test plug (see below).
- 4) Connect to mains.
- 5) The VLT frequency converter expects the [OK] key to be pressed (if no LCP, set to *Normal operation*, when the VLT frequency converter will start up as usual).
- 6) Carry out various tests.
- 7) Press the [OK] key.
- 8) Parameter 620 is automatically set to *Normal operation*.


If a test fails, the VLT frequency converter will move into an infinite loop. Replace control card.

Dantos

Test plugs (connect the following terminals to each other):

- 4 16 17 18 19 27 29 32 33 5 - 12 39 - 20 - 55
- 42 60

45 - 53 - 54



Initialisation [3] is selected if the factory setting of the unit is desired without resetting parameters 500, 501 + 600 - 605 + 615 - 617.



NB!

The motor must be stopped before initialisation can be carried out.

Procedure for initializing:

- 1) Select Initialisation.
- 2) Press the [OK] key.
- 3) Cut off the mains supply and wait for the light in the display to go out.
- 4) Connect to mains.

Manual initialisation can be carried out by holding down three keys at the same time as the mains voltage is connected. Manual initialisation sets all parameters to the factory setting, except 600-605. The procedure for manual initialisation is as follows:

- 1) Disconnect the mains voltage and wait for the light in the display to disappear.
- Hold down [DISPLAY/STATUS]+[MENU]+[OK] while at the same time connecting the mains supply. The display will now read MANUAL INITIALIZE.
- When the display reads UNIT READY, the VLT frequency converter has been initialized.

621 Nameplate: VLT type (VLT TYPE)

Value:

Depends on unit

Function:

The key data of the unit can be read out via the display or the serial communication port.

Description of choice:

Type indicates the unit size and basic function concerned. For example: VLT 5008 380-500 V.

622 Nameplate: Power section (POWER SECTION)

Value:

Depends on unit

Function:

The key data of the unit can be read out via the display or the serial communication port.

Description of choice:

The power section states the given power section being used.

For example: Extended with brake.

623 Nameplate: VLT ordering number (VLT ORDERING NO)

Value:

Depends on unit

Function:

The key data of the unit can be read out via the display or the serial communication port.

Description of choice:

Ordering number gives the ordering number of the VLT type in question. For example: 175Z0072.

^{★ =} factory setting. () = display text [] = value for use in communication via serial communication port

Dantoss

624 Nameplate: Software version no. (SOFTWARE VERSION)

Value:

Depends on unit

Function:

The key data of the unit can be read out via the display or the serial communication port.

Description of choice:

Software version gives the version number. For example: V 3,10.

625 Nameplate: LCP identification no. (LCP ID no.)

Value:

Depends on unit

Function:

The key data of the unit can be read out via the display or the serial communication port. For example: ID 1,42 2 kB.

626 Nameplate: Database identification no. (PARAM DB ID)

Value:

Depends on unit

Function:

The key data of the unit can be read out via the display or the serial communication port. For example: ID 1.14.

627 Nameplate: Power section identification no. (POWER UNIT DB ID)

Value:

Depends on unit

Function:

The key data of the unit can be read out via the display or the serial communication port. For example: ID 1,15.

628 Nameplate: Application option type

(APP. OPTION) Value:

Function:

The key data of the unit can be read out via the display or the serial communication port.

629 Nameplate: Application option

ordering no. (APP. ORDER NO)

Value:

Function:

The key data of the unit can be read out via the display or the serial communication port.

630 Nameplate: Communication option type (COM. OPTION)

Value:

Function:

The key data of the unit can be read out via the display or the serial communication port.

631 Nameplate: Communication option

ordering no. (COM. ORDER NO)

Value:

Function:

The key data of the unit can be read out via the display or the serial communication port.

^{★ =} factory setting. () = display text [] = value for use in communication via serial communication port

Dantos

NB!

Parameters 700-711 for the relay card are only activated if a relay option card is installed in the VLT 5000.

700	Relay 6, function (RELAY6 FUNCTION)
703	Relay 7, function (RELAY7 FUNCTION)
706	Relay 8, function (RELAY8 FUNCTION)
709	Relay 9, function (RELAY9 FUNCTION)
Fund	tion:

This output activates a relay switch.

Relay outputs 6/7/8/9 can be used for showing status and warnings. The relay is activated when the conditions for the relevant data values have been fulfilled.

Activation/deactivation can be programmed in parameters 701/704/707/710 Relay 6/7/8/9, ON delay and parameters 702/705/708/711 Relay 6/7/8/ 9, OFF delay.

Description of choice:

For data choice and connections see parameter 319 - 326.

701	Relay 6, ON delay (RELAY6 ON DELAY)
704	Relay 7, ON delay (RELAY7 ON DELAY)
707	Relay 8, ON delay (RELAY8 ON DELAY)
710	Relay 9, ON delay (RELAY9 ON DELAY)
Valu	e:

0 - 600 sec.

Function:

This parameter allows a delay of the cut-in time of relays 6/7/8/9 (terminals 1-2).

Description of choice: Enter the required value.

702 Relay 6, OFF delay (RELAY6 OFF DELAY) 705 Relay 7, OFF delay (RELAY7 OFF DELAY) 708 Relay 8, OFF delay (RELAY8 OFF DELAY) 711 Relay 9, OFF delay (RELAY9 OFF DELAY)

Value:


0 - 600 sec.


Function:

This parameter is used to delay the cut-out time of relays 6/7/8/9 (terminals 1-2).


Description of choice: Enter the required value. Electrical installation of the relay card The relays are connected as shown below.

Relay 6-9: A-B make, A-C break Max. 240 V AC, 2 Amp.





To achieve double isolation, the plastic foil must be mounted as shown in the drawing below.



DANFOSS 175HA475.10

★ 0 sec.

★ 0 sec.

Danfoss

Outputs	terminal no.	Relay 06	Relay 07	Relay 08	Relay 09
	parameter	700	703	706	709
Value:					
No function	(NO OPERATION)	[0]	[0]	[0]	[0]
Control ready	(CONTROL READY)	[1]	[1]	[1]	[1]
Ready signal	(UNIT READY)	[2](★)	[2]	[2]	[2]
Ready - remote control	(UNIT READY/REM CTRL)	[3]	[3]	[3]	[3]
Enable, no warning	(ENABLE/NO WARNING)	[4]	[4]	[4]	[4]
Running	(VLT RUNNING)	[5]	[5]	[5]	[5]
Running, no warning	(RUNNING/NO WARNING)	[6]	[6]	[6]	[6]
Running within range, no warning	(RUN IN RANGE/NO WARN)	[7]	[7]	[7]	[7]
Running at reference value, no					
5	(RUN ON REF/NO WARN)	[8]	[8]	[8]	[8]
Fault	(ALARM)	[9]	[9]	[9]	[9] (★)
Fault or warning	(ALARM OR WARNING)	[10]	[10]	[10]	[10]
Torque limit	(TORQUE LIMIT)	[11]	[11]	[11]	[11]
Out of current range	(OUT OF CURRENT RANGE)	[12]	[12]	[12]	[12]
Over I low	(ABOVE CURRENT,LOW)	[13]	[13]	[13]	[13]
Under I high	(BELOW CURRENT, HIGH)	[14]	[14]	[14]	[14]
Out of frequency range	(OUT OF FREQ RANGE)	[15]	[15]	[15]	[15]
Over f low	(ABOVE FREQUENCY LOW)	[16]	[16]	[16]	[16]
Under f high	(BELOW FREQUENCY HIGH)		[17]	[17]	[17]
Out of feedback range	(OUT OF FDBK RANGE)	[18]	[18]	[18]	[18]
Over feedback low	(ABOVE FDBK, LOW)	[19]	[19]	[19]	[19]
Under feedback high	(BELOW FDBK, HIGH)	[20]	[20]	[20]	[20]
Thermal warning	(THERMAL WARNING)	[21[[21]	[21]	[21]
Ready - no thermal warning	(READY &NOTHERM WARN)	[22]	[22]	[22]	[22]
Ready - remote control - no the					
	(REM RDY&NO THERMWAR) [23]	[23]	[23]	[23]
Ready - mains voltage within ra	· · · · · · · · · · · · · · · · · · ·				
	(RDY NO OVER/UNDERVOL)	[24]	[24]	[24]	[24]
Reversing	(REVERSE)	[25]	[25]	[25]	[25]
Bus ok	(BUS OK)	[26]	[26]	[26]	[26]
Torque limit and stop	(TORQUE LIMIT AND STOP)	[27]	[27]	[27]	[27]
Brake, no brake warning	()	[28]	[28]	[28]	[28]
Brake ready, no fault	(BRAKE RDY (NO FAULT))	[29]	[29]	[29]	[29]
Brake fault	(BRAKE FAULT (IGBT))	[30]	[30]	[30]	[30]
Relay 123	(RELAY 123)	[31]	[31]	[31]	[31]
Mechanical brake control	(MECH. BRAKE CONTROL)	[32]	[32]	[32]	[32]
Control word bit 11/12	(CTRL WORD BIT 11/12)	[33]	[33]	[33]	[33]
Mains ON	(MAINS ON)	[50]	[50]	[50](★)	[50]
Motor running	(MOTOR RUNNING)	[51]	[51](★)	[51]	[51]
		<u>13.1</u>	<u>(~)[יין יין</u>	<u>191</u>	


Description of choice:

For description of choice please see parameter 319.

Mains ON [50], has the same logical function as *Running* [5].

Motor running [51], has the same logical function as *Mechanical brake control* [32].






1

. مود






ę




Danfoss



Dantoss

Status messages

Status messages appear in the 4th line of the display, see the below example. The status message will be on the display for approx. 3 seconds.



Start clockwise/anti-clockwise (START FORW./REV):

Input on digital inputs and parameter data are in conflict.

Slow-down (SLOW DOWN):

The output frequency of the VLT frequency converter is reduced by the percentage value chosen in parameter 219.

Catch-up (CATCH UP):

The output frequency of the VLT frequency converter is increased by the percentage value chosen in para- meter 219.

Feedback high (FEEDBACK HIGH):

The FB value is higher than the value set in parameter 228. This message is only shown when the motor is running.

Feedback low (FEEDBACK LOW):

The FB value is lower than the value set in parameter 227. This message is only shown when the motor is running.

Output frequency high (FREQUENCY HIGH):

The output frequency is higher than the value set in parameter 226. This message is only shown when the motor is running.

Output frequency low (FREQUENCY LOW):

The output frequency is lower than the value set in parameter 225. This message is only shown when the motor is running.

Output current high (CURRENT HIGH):

The output current is higher than the value set in parameter 224. This message is only shown when the motor is running.

Output current low (CURRENT LOW):

The output current is lower than the value set in parameter 223. This message is only shown when the motor is running.

Braking max. (BRAKING MAX):

The brake is functioning. Optimum braking is effected when the value in parameter 402 *Braking power limit, KW* is exceeded.

Braking (BRAKING):

The brake is functioning.

Ramp operation (REM/ RAMPING):

Remote has been selected in parameter 002 and the output frequency is changed in accordance with the ramps set.

Ramp operation (LOCAL/ RAMPING):

Local has been selected in parameter 002 and the output frequency is changed in accordance with the ramps set.



Status messages - cont.

VLT ready, remote control (REM/UNIT READY)

Remote control has been selected in parameter 002 and *Coasting stop* inverse in parameter 304, and there is 0 V on terminal 27.

VLT ready, local control (LOCAL/ UNIT READY)

Local has been selected in parameter 002 and *Coasting inverse* in parameter 304, and there is 0 V on terminal 27.

Quick-stop, remote control (REM/QSTOP)

Remote control has been selected in parameter 002 and the VLT frequency converter has stopped via a quick-stop signal on terminal 27 (or possibly via the serial communication port).

Quick-stop, local (LOCAL/QSTOP)

Local has been selected in parameter 002 and the VLT frequency converter has stopped via a quick-stop signal on terminal 27 (or possibly via the serial communication port).

DC stop, remote control (REM/DC STOP)

Remote control has been selected in parameter 002 and the VLT frequency converter has stopped via a DC stop signal on a digital input (or possibly via the serial communication port).

DC braking, local (LOCAL/ DC STOP)

Local has been selected in parameter 002 and the VLT frequency converter has stopped via a DC braking signal on terminal 27 (or possibly via the serial communication port).

Stop, remote controlled (REM/STOP)

Remote control has been selected in parameter 002 and the VLT frequency converter has stopped via the control panel or a digital input (or possibly via the serial communication port).

Stop, local (LOCAL/ STOP)

Local has been selected in parameter 002 and the VLT frequency converter has stopped via the control panel or the digital input (or possibly via the serial communication port).

LCP stop, local (LOCAL/LCP STOP)

Local has been selected in parameter 002 and the VLT frequency converter has stopped via the control panel. The coast signal on terminal 27 is high.

Stand by (STAND BY)

Remote control has been selected in parameter 002. The frequency converter will start when it receives a start signal via a digital input (or the serial communication port).

Freeze output (FREEZE OUTPUT)

Remote control has been selected in parameter 002 together with *Freeze reference* in parameter 300, 301, 305, 306 or 307, and the terminal in question (16, 17, 29, 32 or 33) has been activated (or possibly via the serial communication port).

Jog operation, remote controlled (REM/RUN JOG)

Remote control has been selected in parameter 002 and *Jog* in parameter 300, 301, 305, 306 or 307, and the terminal in question (16, 17, 29, 32 or 33) has been activated (or possibly via the serial communication port).

Jog operation, local (LOCAL/ RUN JOG)

Local has been selected in parameter 002 and *Jog* in parameter 300, 301, 305, 306 or 307, and the terminal in question (16, 17, 29, 32 or 33) has been activated (or possibly via the serial communication port).

Overvoltage control (OVER VOLTAGE CONTROL)

The intermediate circuit voltage of the VLT frequency converter is too high. The frequency converter is trying to avoid a trip by increasing the output frequency.

This function is activated in parameter 400.

Exceptions XXXX (EXCEPTIONS XXXX)

The microprocessor of the control card has stopped and the VLT frequency converter is out of operation. The cause may be noise on the mains, motor or control cables, leading to a stop of the control card microprocessor.

Check for EMC-correct connection of these cables.



List of warnings and alarms

The table gives the different warnings and alarms and indicates whether the fault locks the VLT frequency converter. After Trip locked, the mains supply must be cut and the fault must be corrected. Reconnect the mains supply and reset the VLT frequency converter before being ready. Wherever a cross is placed under both Warning and Alarm, this can mean that a warning precedes the alarm. It can also mean that it is possible to program whether a given fault is to result in a warning or an alarm. This is possible, e.g. in parameter 404 *Brake check*. After a trip, alarm and warning will flash, but if the fault is removed, only alarm will flash. After a reset, the VLT frequency converter will be ready to start operation again.

No.	Description	Warning	Alarm	Trip locked	Help
1	10 Volts low (10 VOLT LOW)	Χ			Page 155
2	Live zero fault (LIVE ZERO ERROR)	Х	Х		Page 155
3	No motor (NO MOTOR)	X			Page 155
4	Phase fault (MAINS PHASE LOSS)	Χ	Х	х	Page 155
5	Voltage warning high (DC LINK VOLTAGE HIGH)	X			Page 155
6	Voltage warning low (DC LINK VOLTAGE LOW)	X			Page 155
7	Overvoltage (DC LINK OVERVOLT)	Х	X		Page 155
8	Undervoltage (DC LINK UNDERVOLT)	<u>X</u>	Х		Page 156
9	Inverter overladed (INVERTER TIME)	Х	Х		Page 156
10	Motor overloaded (MOTOR TIME)	X	X		Page 156
11	Motor thermistor (MOTOR THERMISTOR)	Χ	<u>X</u>		Page 156
12	Torque limit (TORQUE LIMIT)	Х	<u>X</u>		Page 156
13	Overcurrent (OVERCURRENT)		X	Х	Page 156
14	Earth fault (EARTH FAULT)		Χ	Х	Page 156
15	Switch mode fault (SWITCH MODE FAULT)		X	X	Page 156
16	Short-circuit (CURR.SHORT CIRCUIT)		Х	X	Page 156
17	Standard bus timeout (STD BUS TIMEOUT)	Х	Х		Page 156
18	HPFB bus timeout (HPFB TIMEOUT)	Х	<u>X</u>		Page 157
19	Fault in EEprom on power card				
	(EE ERROR POWER CARD)	X			Page 157
20	Fault in EEprom on conrol card				
	(EE_ERROR_CTRL_CARD)	X			Page 157
21	Auto-optimisation OK (AUTO MOTOR ADAPT OK)		X		Page 157
22	Auto-optimisation not OK (AUTO MOT ADAPT FAIL)		X		Page 157
_23	Brake test failed (BRAKE TEST FAILED)	Х			Page 158
25	Brake resistor short-circuited (BRAKE RESISTOR FAUL	<u>T) X</u>			Page 158
26	Brake resistor power 100% (BRAKE POWER 100%)	Х	<u>X</u>		Page 158
27	Brake transistor short-circuited ()	X		. .	Page 158
29	Heat-sink temperature too high (HEAT SINK OVER_TE	<u>MP.)</u>	Х	Х	Page 158
30	Motor phase U missing (MISSING MOT.PHASE U)		Х		Page 158
31	Motor phase V missing (MISSING MOT.PHASE V)		<u> </u>		Page 158
32	Motor phase W missing (MISSING MOTPHASE W)		<u>X</u>	<u> </u>	Page 158
<u>33</u>	Quick discharge not OK (QUICK DISCHARGE FAIL)		X	X	Page 158
_34	Profibus communication fault (PROFIBUS COMM. FAU	LT) X	Х		Page 159
35	Out of frequency range (OUT FREQ RNG/ROT LIM)	X			Page 159
_36	Mains failure (MAINS FAILURE)	Х	<u> </u>		Page 159
_37	Inverter fault (INVERTER FAULT)		Х	X	Page 159
_39	Check parameters 104 and 106 (CHECK P.104 & P10			<u></u> .	Page 159
40	Check parameters 103 and 105 (CHECK P103 & P10				Page 159
_41	Motor too big (MOTOR TOO BIG)	X		<u>.</u>	Page 159
42	Motor too small (MOTOR TOO SMALL)	Х			Page 159
43	Brake fault (BRAKE FAULT)		X	Χ	Page 159
	Encoder loss (ENCODER FAULT)	<u> </u>	X		Page 159

Warnings

The display flashes between normal state and warning. A warning comes up on the first and second line of the display. See examples below:



WARN. 1

Under 10 Volts (10 VOLT LOW):

The 10 Volts voltage from terminal 50 on the control card is below 10 Volts.

Remove some of the load from terminal 50, as the 10 Volts supply is overloaded. Max. 17 mA/min. 590 Ω .

WARNING/ALARM 2

Live zero fault (LIVE ZERO ERROR):

The current signal on terminal 60 is less than 50% of the value set in parameter 315 *Terminal 60, min. scaling.*

WARNING/ALARM 3 No motor (NO MOTOR):

The motor check function (see parameter 122) indicates that no motor has been connected to the output of the VLT frequency converter.

WARNING/ALARM 4

Phase fault (MAINS PHASE LOSS):

Phase missing on the supply side or mains voltage imbalance too high.

Check the supply voltage to the VLT frequency converter.

Alarm messages

The alarm comes up in the 2. and 3. line of the display, see example below:



WARNING 5

Voltage warning high (DC LINK VOLTAGE HIGH):

The intermediate circuit voltage (DC) is higher than the overvoltage limit of the control system, see table on this page. The VLT frequency converter is still active.

WARNING 6

Voltage warning low (DC LINK VOLTAGE LOW):

The intermediate circuit voltage (DC) is below the undervoltage limit of the control system, see table below. The VLT frequency converter is still active.

WARNING/ALARM 7 Overvoltage (DC LINK OVERVOLT):

If the intermediate circuit voltage (DC) exceeds the inverter overvoltage limit (see table), the VLT frequency converter will trip after the time set in parameter 410 has passed.

Furthermore, the voltage will be stated in the display. The fault can be eliminated by connecting a brake resistor (if the VLT frequency converter has an integral brake chopper, EB or SB) or by extending the time chosen in parameter 410. In addition, *Brake function/ overvoltage control* can be activated in parameter 400.

Alarm/warning_limits:			
VLT 5000 Series	3 x 200 - 240 V	3 x 380 - 500 V	-
	[VDC]	[VDC]	
Undervoltage	211	402	
Voltage warning low	222	423	_
Voltage warning high	384/405	801/840	(w/o brake - w/brake)
Overvoltage	425	855	• · ·

The voltages stated are the intermediate circuit voltage of the VLT frequency converter with a tolerance of \pm 5 %. The corresponding mains voltage is the intermediate circuit voltage divided by $\sqrt{2}$.

Danfoss

Warnings and alarms, cont.

WARNING/ALARM 8 Undervoltage (DC LINK UNDERVOLT):

If the intermediate circuit voltage (DC) drops below the inverter lower voltage limit (see table on previous page), it will be checked whether 24 V power supply is connected.

If no 24 V power supply is connected, the VLT frequency converter will trip after a given time that depends on the unit.

Furthermore, the voltage will be stated in the display. Check whether the supply voltage matches the VLT frequency converter, see technical data.

WARNING/ALARM 9

Inverter overload (INVERTER TIME):

The electronic, thermal inverter protection reports that the frequency converter is about to cut out because of an overload (too high current for too long). The counter for electronic, thermal inverter protection gives a warning at 98% and trips at 100%, while giving an alarm. The VLT frequency converter <u>cannot</u> be reset until the counter is below 90%. The fault is that the VLT frequency converter is overloaded by more than 100% for too long.

WARNING/ALARM 10

Motor overtemperature (MOTOR TIME):

According to the electronic thermal protection (ETR), the motor is too hot. Parameter 128 allows a choice of whether the VLT frequency converter is to give a warning or an alarm when the counter reaches 100%. The fault is that the motor is overloaded by more than 100% for too long. Check that motor parameters 102-106 have been set correctly.

WARNING/ALARM 11

Motor thermistor (MOTOR THERMISTOR):

The thermistor or the thermistor connection has been disconnected. Parameter 128 allows a choice of whether the VLT frequency converter is to give a warning or an alarm. Check that the thermistor has been correctly connected between terminal 53 or 54 (analogue voltage input) and terminal 50 (+ 10 Volts supply).

VLT' 5000 Series

WARNING/ALARM 12 Torque limit (TORQUE LIMIT):

The torque is higher than the value in parameter 221 (in motor operation) or the torque is higher than the value in parameter 222 (in regenerative operation).

WARNING/ALARM 13 Overcurrent (OVERCURRENT):

The inverter peak current limit (approx. 200% of the rated current) has been exceeded. The warning will last approx. 1-2 seconds, following which the VLT frequency converter will trip, while giving an alarm. Turn off the VLT frequency converter and check whether the motor shaft can be turned and whether the motor size matches the VLT frequency converter.

ALARM: 14

Earth fault (EARTH FAULT):

There is a discharge from the output phases to earth, either in the cable between the frequency converter and the motor or in the motor itself.

Turn off the VLT frequency converter and remove the earth fault.

ALARM: 15

Switch mode fault (SWITCH MODE FAULT):

Fault in the switch mode power supply (internal ± 15 V supply).

Contact your Danfoss supplier.

ALARM: 16

Short-circuiting (CURR.SHORT CIRCUIT):

There is short-circuiting on the motor terminals or in the motor itself.

Turn off the VLT frequency converter and remove the short-circuit.

WARNING/ALARM 17

Standard bus timeout (STD BUSTIMEOUT)

There is no communication to the VLT frequency converter.

The warning will only be active when parameter 514 has been set to another value than *OFF*.

If parameter 514 has been set to *stop and trip*, it will first give a warning and then ramp down until it trips, while giving an alarm.

Parameter 513 *Bus time interval* could possibly be increased.

Pantosa

Warnings and alarms, cont.

WARNING/ALARM 18

HPFB bus timeout (HPFB BUS TIMEOUT)

There is no communication with the VLT frequency converter.

The warning will only be active when parameter 804 has been set to another value than OFF.

If parameter 804 has been set to Stop and trip, it will first give a warning and then ramp down until it trips, while giving an alarm.

Parameter 803 Bus time interval could possibly be increased.

WARNING 19

Fault in the EEprom on the power card (EE ERROR POWER CARD)

There is a fault on the power card EEPROM. The VLT frequency converter will continue to function, but is likely to fail at the next power-up. Contact your Danfoss supplier.

WARNING 20

Fault in the EEprom on the control card (EE ERROR CTRL CARD)

There is a fault in the EEPROM on the control card. The VLT frequency converter will continue to function, but is likely to fail at the next power-up. Contact your Danfoss supplier.

ALARM 21

Auto-optimisation OK (AUTO MOTOR ADAPT OK)

The automatic motor tuning is OK and the VLT frequency converter is now ready for operation.

ALARM: 22

Auto-optimisation not OK (AUTO MOT ADAPT FAIL)

A fault has been found during automatic motor adaptation. The text shown in the display indicates a fault message. The figure after the text is the error code, which can be seen in the fault log in parameter 615.

[0]

[1]

CHECK P.103,105

Parameter 102, 103 or 105 has a wrong setting. Correct the setting and start AMA all over.

LOW P 105

The motor is too small for AMA to be carried out. If AMA is to be enabled, the rated motor current (parameter 105) must be higher than 35% of the rated output current of the VLT frequency converter.

ASYMMETRICAL IMPEDANCE [2]

AMA has detected an asymmetrical impedance in the motor connected to the system. The motor could be defective.

MOTOR TOO BIG

The motor connected to the system is too big for AMA to be carried out. The setting in parameter 102 does not match the motor used.

[3]

[4]

[5]

MOTOR TOO SMALL

The motor connected to the system is too small for AMA to be carried out. The setting in parameter 102 does not match the motor used.

TIME OUT

AMA fails because of noisy measuring signals. Try to start AMA all over a number of times, until AMA is carried out. Please note that repeated AMA runs may heat the motor to a level where the stator resistance Rs is increased. In most cases, however, this is not critical.

INTERRUPTED BY USER [6]

AMA has been interrupted by the user.

INTERNAL FAULT

[7]

[8]

An internal fault has occurred in the VLT frequency converter. Contact your Danfoss supplier.

LIMIT VALUE FAULT

The parameter values found for the motor are outside the acceptable range within which the VLT frequency converter is able to work.

MOTOR ROTATES

[9] The motor shaft rotates. Make sure that the load is not able to make the motor shaft rotate. Then start AMA all over.



NB!

AMA can only be carried out if there are no alarms during tuning.

Dantoss

Warnings and alarms, cont.

WARNING/ALARM 23

Fault during brake test (BRAKE TEST FAILED):

The brake test is only run after power-up. If *Warning* has been selected in parameter 404, the warning will come when the brake test finds a fault.

If *Trip* has been selected in parameter 404, the VLT frequency converter will trip when the brake test finds a fault.

The brake test may fail for the following reasons: No brake resistor connected or fault in the connections; defective brake resistor or defective brake transistor. A warning or alarm will mean that the brake function is still active.

WARNING 25 Brake resistor fault (BRAKE RESISTOR FAULT):

The brake resistor is monitored during operation and if it short-circuits, the brake function is disconnected and the warning comes up. The VLT frequency converter will still be able to work, although without the brake function. Turn off the VLT frequency converter and replace the brake resistor

WARNING 26

Brake resistor power 100% (BRAKE PWR WARN 100%):

The power transmitted to the brake resistor is calculated as a percentage, as a mean value over the last 120 sec., on the basis of the resistance value of the brake resistor (parameter 401) and the intermediate circuit voltage. The warning is active when the dissipated braking power is higher than 100%. If *Trip* [2] has been selected in parameter 403, the VLT frequency converter will cut out while giving this alarm.

WARNING 27 Brake transistor fault (BRAKE IGBT FAULT):

The brake transistor is monitored during operation and if it short-circuits, the brake function is disconnected and the warning comes up. The VLT frequency converter will still be able to run, but since the brake transistor has short-circuited, substantial power will be transmitted to the brake resistor, even if it is inactive.

Turn off the VLT frequency converter and remove the brake resistor.



Warning: There is a risk of substantial power being transmitted to the brake resistor if the brake transistor has short-circuited.

WARNING 29

Heat sink temperature too high (HEAT SINK OVER TEMP.):

If the enclosure is IP 00 or IP 20, the cut-out temperature of the heat-sink is 90°C. If IP 54 is used, the cut-out temperature is 80°C.

The tolerance is \pm 5°C. The temperature fault <u>cannot</u> be reset, until the temperature of the heat-sink is below 60°C.

The fault could be the following:

- Ambient temperature too high
- Too long motor cable
- Too high switching frequency.

ALARM: 30

Motor phase U missing (MISSING MOT.PHASE U):

Motor phase U between VLT frequency converter and motor is missing.

Turn off the VLT frequency converter and check motor phase U.

ALARM: 31

Motor phase V missing (MISSING MOT.PHASE V):

Motor phase V between VLT frequency converter and motor is missing.

Turn off the VLT frequency converter and check motor phase $\ensuremath{\mathsf{V}}$

ALARM: 32 Motor phase W missing (MISSING MOT.PHASE W):

Motor phase W between VLT frequency converter and motor is missing.

Turn off the VLT frequency converter and check motor phase W.

ALARM: 33

Quick discharge not OK (QUICK DISCHARGE NOT OK):

Check whether a 24 Volt external DC supply has been connected and that an external brake/discharge resistor has been fitted.

MG.50.A9.02 - VLT is a registered Danfoss trademark

VLT' 5000 Series

Dantos

Warnings and alarms, cont.

WARNING/ALARM: 34 Profibus communication fault (PROFIBUS COMMUNICATION FAULT):

The profibus on the communication option card is not working.

WARNING: 35 Out of frequency range (OUT OF FREQUENCY RANGE):

This warning is active if the output frequency has reached its *Output frequency low limit* (parameter 201) or *Output frequency high limit* (parameter 202). If the VLT frequency converter is in *Process control, closed loop* (parameter 100), the warning will be active in the display. If the VLT frequency converter is in another mode than *Process control, closed loop*, bit 008000 *Out of frequency range* in warning word 2 will be active, while there will be no warning in the display.

WARNING/ALARM: 36 Mains failure (MAINS FAILURE):

This warning/alarm is only active if the supply voltage to the VLT frequency converter is lost and if parameter 407 *Mains fault* has been set to another value than *OFF*.

If parameter 407 has been set to *Contr. ramp-down trip* [2], the VLT frequency converter will first give a warning and then ramp down and trip, while giving an alarm. Check the fuses to the VLT frequency converter.

ALARM: 37

Inverter fault (INVERTER FAULT):

IGBT or the power card is defective. Contact your Danfoss supplier.

Auto-optimisation warnings

Automatic motor adaptation has stopped, since some parameters have probably been set wrongly, or the motor used in too big/small for AMA to be carried out. A choice must thus be made by pressing [CHANGE DATA] and choosing 'Continue' + [OK] or 'Stop' + [OK].

If parameters need to be changed, select 'Stop'; start up AMA all over.

WARNING: 39 CHECK P.104,106

The setting of parameter 102, 104 or 106 is probably wrong. Check the setting and choose 'Continue' or 'Stop'.

WARNING: 40 CHECK P.103,105

The setting of parameter 102, 103 or 105 is probably wrong. Check the setting and choose 'Continue' or 'Stop'.

WARNING: 41 MOTOR TOO BIG

The motor used is probably too big for AMA to be carried out. The setting in parameter 102 may not match the motor. Check the motor and choose 'Continue' or 'Stop'.

WARNING: 42

MOTOR TOO SMALL

The motor used is probably too small for AMA to be carried out. The setting in parameter 102 may not match the motor. Check the motor and choose 'Continue' or 'Stop'.

ALARM: 43

Brake fault (BRAKE FAULT)

A fault has arisen on the brake. The text shown in the display indicates a fault message. The figure after the text is the fault code that can be seen in the fault log, parameter 615.

Brake check failed (BRAKE CHECK FAILED) [0]

The brake check carried out during power-up indicates that the brake has been disconnected. Check whether the brake has been connected correctly and that it has not been disconnected.

Brake resistor short-circuited (BRAKE RESISTOR FAULT)

The brake output has short-circuited. Replace the brake resistor.

Brake IGBT short-circuited (BRAKE IGBT FAULT)

[2]

[1]

The brake IGBT has short-circuited. This fault means that the unit is not able to stop the brake and that, consequently, the resistor is constant being energized.

WARNING/ALARM: 44 Encoder loss (ENCODER FAULT)

The encoder signal is interrupted from terminal 32 or 33. Check the connections.

<u>Danfoss</u>

■ Warning word 1, Extended status word and Alarm word

Warning word 1, extended status word and alarm word are shown on the display in Hex format. If there are more than one warning or alarm, a sum of all warnings or alarms will be shown.

Warning word 1, extended status word and alarm word can also be displayed using the serial bus in parameter 540, 541 and 538.

<u>Bit (Hex)</u>	Warning word 1
000001	Fault during brake test
000002	EE-prom power card fault
000004	EE-prom control card
800000	HPFP bus timeout
000010	Standard bus timeout
000020	Overcurrent
000040	Torque limit
080000	Motor thermistor
000100	Motor overload
000200	Inverter overload
000400	Undervoltage
00800	Overvoltage
001000	Voltage warning low
002000	Voltage warning high
004000	Phase fault
008000	No motor
010000	4-20 mA current signal low
020000	10 Volts low
040000	
080000	Brake resistor power 100%
100000	Brake resistor fault
200000	Brake transistor fault
400000	Out of frequency range
800000	Profibus communication fault
1000000	
2000000	Mains failure
4000000	Encoder loss

Bit (Hex)	Extended status word
000001	Ramping
000002	Automatic motor tuning
000004	Start clockwise/anti-clockwise
800000	Slow down
000010	Catch-up
000020	Feedback high
000040	Feedback low
000080	Output current high
. 000100	Output current low
000200	Output freguency high
000400	Output frequency low
00800	Brake test ok
001000	Braking max.
002000	Braking
004000	Quick discharge OK
008000	Out of frequency range

Bit (Hex)	Alarm word 1
000001	Brake test failed
000002	Trip locked
000004	AMA tuning not OK
000008	AMA tuning OK
000010	Power-up fault
000020	ASIC fault
000040	HPFP bus timeout
080000	Standard bus timeout
000100	Short-circuiting
000200	Switchmode fault
000400	Earth fault
008000	Overcurrent
001000	Torque limit
002000	Motor thermistor
004000	Motor overload
008000	Inverter overload
010000	Undervoltage
020000	Overvoltage
040000	Phase fault
080000	Live zero fault
100000	Heat sink temperature too high
200000	Motor phase W missing
400000	Motor phase V missing
800000	Motor phase U missing
1000000	Quick discharge not ok
2000000	Profibus communication fault
4000000	Mains failure
8000000	Inverter fault
10000000	Encoder loss

Pantos

Definitions

VLT:

<u>Ivit,мах</u> The maximum output current.

<u>Ivan</u> The rated output current supplied by the VLT frequency converter.

 $\frac{U_{\text{VLT MAX}}}{\text{The maximum output voltage.}}$

Output:

 $\underline{I}_{\underline{M}}$ The current transmitted to the motor.

 $\underline{U}_{\underline{M}}$ The voltage transmitted to the motor.

fм

The frequency transmitted to the motor.

<u>fjog</u>

The frequency transmitted to the motor when the jog function is activated (via digital terminals or the keypad).


f_{min}

The minimum frequency transmitted to the motor.

f_{MAX}

The maximum frequency transmitted to the motor

Break-away torque:



η_{VLI}

The efficiency of the VLT frequency converter is defined as the ratio between the power output and the power input.

Input:

<u>Control command:</u> By means of LCP and the digital inputs, it is possible to start and stop the connected motor. Functions are divided into two groups, with the following priorities:

Group 1 Reset, Coasting stop, Reset and Coasting stop, Quick-stop, DC braking, Stop and the "Stop" key. Group 2 Start, Pulse start, Reversing, Start reversing, Jog and Freeze output

Group 1 functions are called Start-disable commands. The difference between group 1 and group 2 is that in group 1 all stop signals must be cancelled for the motor to start. The motor can then be started by means of a single start signal in group 2. A stop command given as a group 1 command results in the display indication STOP. A missing stop command given as a group 2 command results in the display indication STAND BY.

Start-disable command:

A stop command that belongs to group 1 of the control commands - see this group.

Stop command: See Control commands.

Motor:

Iмм The rated motor current (nameplate data).

f_{MN} The rated motor frequency (nameplate data).

<u>U_{M.N} The rated motor voltage (nameplate data).</u>

P_{M.N} The rated or

The rated power delivered by the motor (nameplate data).

\underline{n}_{MN} The rated motor speed (nameplate data).

T_{M.N}

The rated torque (motor).

Definitions



preset ref.

A firmly defined reference which can be set from -100% to +100% of the reference range. There are four preset references, which can be selected via the digital terminals.

analogue ref.

A signal transmitted to input 53, 54 or 60. Can be voltage or current.

pulse ref.

A signal transmitted to the digital inputs (terminal 17 or 29).

<u>binary ref.</u>

A signal transmitted to the serial communication port.

<u>Ref_{MIN}</u>

The smallest value which the reference signal may have. Set in parameter 204.

Ref_{MAX}

The maximum value which the reference signal may have. Set in parameter 205.

Miscellaneous:

ELCB: Earth Leakage Circuit Breaker.

<u>lsb:</u>

Least significant bit. Used in serial communication.

<u>msb</u>

Most significant bit. Used in serial communication.

<u>PID:</u>

The PID regulator maintains the desired speed (pressure, temperature, etc.) by adjusting the output frequency to match the varying load.

<u>Trip:</u>

A state which occurs in different situations, e.g. if the VLT frequency converter is subjected to an overtemperature. A trip can be cancelled by pressing reset or, in some cases, automatically.

Trip locked:

A state which occurs in different situations, e.g. if the VLT frequency converter is subject to an overtemperature. A locked trip can be cancelled by cutting off mains and restarting the VLT frequency converter.

Initializing:

If initializing is carried out (see page 144), the VLT frequency converter returns to the factory setting.

Setup:

There are four Setups, in which it is possible to save parameter settings. It is possible to change between the four parameter Setups and to edit one Setup, while another Setup is active.

<u>LCP:</u>

The control panel, which makes up a complete interface for control and programming of VLT 5000 Series. The control panel is detachable and may, as an alternative, be installed up to 3 metres away from the VLT frequency converter, i.e. in a front panel, by means of the installation kit option.

<u>VVC</u> plus

If compared with standard voltage/frequency ratio control, VVC^{pus} improves the dynamics and the stability, both when the speed reference is changed and in relation to the load torque.

Slip compensation:

Normally, the motor speed will be affected by the load, but this load dependence is unwanted. The VLT frequency converter compensates for the slip by giving the frequency a supplement that follows the measured effective current.

Thermistor:

A temperature-dependent resistor placed where the temperature is to be monitored (VLT or motor).

Analogue inputs:

The analogue inputs can be used for controlling various functions of the VLT frequency converter. There are two types of analogue inputs: Current input, 0-20 mA Voltage input, 0-10 V DC.

Analogue outputs:

There are two analogue outputs, which are able to supply a signal of 0-20 mA, 4-20 mA or a digital signal.



Digital inputs:

The digital inputs can be used for controlling various functions of the VLT frequency converter.

Digital outputs:

There are four digital outputs, two of which activate a relay switch. The outputs are able to supply a 24 V DC (max. 40 mA) signal.

Brake resistor:

The brake resistor is a module capable of absorbing the brake power that is generated in regenerative braking. This regenerative braking power increases the intermediate circuit voltage and a brake chopper ensures that the power is transmitted to the brake resistor.

Pulse encoder:

An external, digital pulse transmitter used for feeding back information on motor speed. The encoder is used in applications where great accuracy in speed control is required.

AWG:

Means American Wire Gauge, i.e. the American measuring unit for cable cross-section.

Manual initialisation:

Press the [CHANGE DATA] + [MENU] + [OK] keys at the same time to carry out manual initialisation. See also page 144.

<u>60° AVM</u>

Switching pattern called 60° <u>A</u>synchronous <u>V</u>ector <u>M</u>odulation.

<u>SFAVM</u>

Switching pattern called <u>Stator Flux</u> oriented <u>A</u>synchronous <u>Vector Modulation</u>.

Automatic motor adjustment, AMA:

Automatic motor adjustment algorithm, which determines the electrical parameters for the connected motor, at standstill.

On-line/off-line parameters:

On-line parameters are activated immediately after the data value is changed. Off-line parameters are not activated until OK has been entered on the control unit.

VT characteristics:

Variable torque characteristics, used for pumps and fans.

CT characteristics:

Constant torque characteristics, used for all applications, such as conveyor belts and cranes. CT characteristics are not used for pumps and fans.

<u>MCM:</u>

Stands for Mille Circular Mil, an American measuring unit for cable cross-section. 1 MCM \cong 0.5067 mm².



•

÷

ŝ
0
Έ.
÷
e a
ົທ
•••
-
ž
S I I
tory
ctory :
actory :
ictory

PNU	Parameter	Factory setting	Range	Changes	4-Setup	Conversion	Data
#	description		du	ring operat		index	type
001	Language	English		Yes	No	0	5
002	Local/remote control	Remote control		Yes	Yes	0	5
003	Local reference	000.000		Yes	Yes	-3	4
004	Active setup	Setup 1		Yes	No	0	5
005	Programming setup	Active setup		Yes	No	0	5
006	Copying of setups	No copying		No	No	0	5
007	LCP copy	No copying		No	No	0	5
008	Display scaling of motor frequency	1	0.01 - 100.00) Yes	Yes	-2	6
009	Display linie 2	Frequency [Hz]	·	Yes	Yes	<u>0</u>	5
010	Display line 1.1	Reference [%]		Yes	Yes	0	5
011	Display line 1.2	Motor current [A]		Yes	Yes	0	5
012	Display line 1.3	Power [kW]		Yes	Yes	0	5
013	Local control/configura	LCP digital control/as par.100		Yes	Yes	0	5
014	Local stop	Possible		Yes	Yes	0	5
015	Local jog	Not possible		Yes	Yes	0	5
016	Local reversing	Not possible		Yes	Yes	0	5
017	Local reset of trip	Possible		Yes	Yes	0	5
018	Lock for data change	Not locked		Yes	Yes	0	5
019	Operating state at	Forced stop, use saved ref.		Yes	Yes	0	5
	power-up, local control	•					
100	Configuration	Speed control, open loop		No	Yes	0	5
101	Torque characteristics	High - constant torque		Yes	Yes	0	5
102	Motor power	Depends on the unit	0.18-500 kW	/ No	Yes	1	6
102	Motor voltage	Depends on the unit	200 - 500 V	No	Yes	0	6
104	Motor frequency	50 Hz / 60 Hz		No	Yes	0	6
105	Motor current	Depends on the unit	0.01-INITMAX	No	Yes	-2	7
105	Rated motor speed	Depends on the unit	100-60000 rj		Yes	0	6
107	Automatic motor adaptation, AMA	Adaptation off		No	No	0	5
108	Stator resistor	Depends on the unit		No	Yes	-4	7
109	Stator reactance	Depends on the unit		No	Yes	-2	7
110	Motor magnetizing, 0 rpm	100 %	0 - 300 %	Yes	Yes	0	6
111	Min. frequency normal magnetizing	1.0 Hz	0.1 - 10.0 Hz		Yes	-1	6
112	Min. nequency normal magnetizing		0.1 10.0 11				
113	Load compensation at low speed	100 %	0 - 300 %	Yes	Yes	0	6
114	Load compensation at high speed	100 %	0 - 300 %	Yes	Yes	0	6
115	Slip compensation	100 %	-500 - 500 %		Yes	0	3
116	Slip compensation time constant	0.50 s	0.05 - 1.00 s		Yes	-2	6
117	Resonance dampening	100 %	0 - 500 %	Yes	Yes	0	6
118	Resonance dampening time constant	5 ms	5 - 50 ms	Yes	Yes	-3	6
119	High starting torque	0.0 sec.	0.0 - 0.5 s	Yes	Yes	-1	5
120	Start delay	0.0 sec.	0.0 - 10.0 s	Yes	Yes	-1	5
120	Start function	Coasting in start delay time	0.0 10.00	Yes	Yes	0	5
122	Function at stop	Coasting		Yes	Yes	0	5
123	Min. frequency for activating	0.0 Hz	0.0 - 10.0 Hz		Yes	-1	5
120		0.0112	0.0 - 10.0112	. 165	163	-1	5
174	function at stop DC holding current	50 %	0 - 100 %	Yes	Yes	0	6
<u>124</u> 125		50 %	0 - 100 %	Yes	Yes	0	6
<u>125</u> 126	DC braking current	10.0 sec.	0.0 - 60.0 se		Yes	-1	6
126	DC braking time					-1 -1	6
<u>127</u>	DC brake cut-in frequency	Off	0.0-par. 202	Yes	Yes		
128	Motor thermal protection	No protection		Yes	Yes	0	5 5
<u>129</u>	External motor fan	No	0.0 10.0 U-	Yes	Yes	0	<u>5</u>
<u>130</u>	Start frequency	0.0 Hz	0.0-10.0 Hz	Yes	Yes	<u>·1</u>	
<u>131</u>	Initial voltage	0.0 V	0.0-par. 103	Yes	Yes	-1	6

MG.50.A9.02 - VLT is a registered Danfoss trademark



PNU	Parameter	Factory setting	Range	Changes	4-Setup	Conversion	Data
#	description		duri	ng operat	tion	index	type
200	Output frequency	Only clockwise,		No	Yes	0	5
	range/direction	0-132 Hz					
201	Output frequency low limit	0.0 Hz	0.0 - f _{max}	Yes	Yes	-1	6
202	Output frequency high limit	66 / 132 Hz	f _{мін} - par. 200	Yes	Yes	-1	6
203	Reference/feedback area	Min - m ax		Yes	Yes	0	5
204	Minimum reference	0.000	-100,000.000-Ref _{MAX}	Yes	Yes	-3	4
20 <u>5</u>	Maximum reference	50.000	Ref _{MIN} -100,000.000	Yes	Yes	-3	4
206	Ramp type	Linear		Yes	Yes	0	5
207	Ramp-up time 1	Depends on unit	0.05 - 3600	Yes	Yes	-2	7
208	Ramp-down time 1	Depends on unit	0.05 - 3600	Yes	Yes	-2	7
209	Ramp-up time 2	Depends on unit	0.05 - 3600	Yes	Yes	-2	7
210	Ramp-down time 2	Depends on unit	0.05 - 3600	Yes	Yes	-2	7
211	Jog ramp time	Depends on unit	0.05 - 3600	Yes	Yes	-2	7
212	Quick stop ramp-down time	Depends on unit	0.05 - 3600	Yes	Yes	-2	7
213	Jog frequency	10.0 Hz	0.0 - par. 202	Yes	Yes	-1	6
214	Reference function	Sum		Yes	Yes	0	5
215	Preset reference 1	0.00 %	- 100.00 - 100.00 %	Yes	Yes	-2	З
216	Preset reference 2	0.00 %	- 100.00 - 100.00 %	Yes	Yes	-2	3
217	Preset reference 3	0.00 %	- 100.00 - 100.00 %	Yes	Yes	-2	3
218	Preset reference 4	0.00 %	- 100.00 - 100.00 %	Yes	Yes	-2	3
219	Catch up/slow down value	0.00 %	0.00 - 100 %	Yes	Yes	-2	6
220	•						
221	Torque limit for motor mode	160 %	0.0 % - xxx %	Yes	Yes	-1	6
222	Torque limit for regenerative operation	160 %	0.0 % - xxx %	Yes	Yes	-1	6
223	Warning: Low current	0.0 A	0.0 - par. 224	Yes	Yes	-1	6
224	Warning: High current	IVLT,MAX	Par. 223 - IVLT.MAX	Yes	Yes	-1	6
225	Warning: Low frequency	0.0 Hz	0.0 - par. 226	Yes	Yes	-1 .	6
226	Warning: High frequency	132.0 Hz	Par. 225 - par. 202	Yes	Yes	-1 ·	6
227	Warning: Low feedback	-4000.000	-100,000.000 - par. 228			-3	4
228	Warning: High feedback	4000.000	Par. 227 - 100,000.000	Yes		-3	4
229	Frequency bypass, bandwidth	OFF	0 - 100 %	Yes	Yes	0	6
230	Frequency bypass 1	0.0 Hz	0.0 - par. 200	Yes	Yes	-1	6
231	Frequency bypass 2	0.0 Hz	0.0 - par. 200	Yes	Yes	-1	6
232	Frequency bypass 3	0.0 Hz	0.0 - par. 200	Yes	Yes	-1	6
233	Frequency bypass 4	0.0 Hz	0.0 - par. 200	Yes	Yes	•1	6
	Motor phase monitor	Enable		Yes	Yes	0	5

Factory settings



PNU	Parameter	Factory setting	Range	Changes	4-Setup	Conversion	Data
#	description		đuri	ing opera	tion	index	type
300	Terminal 16, input	Reset		Yes	Yes	0	5
301	Terminal 17, input	Freeze reference		Yes	Yes	0	5
302	Terminal 18 Start, input	Start		Yes	Yes	0	5
303	Terminal 19, input	Reversing		Yes	Yes	0	5
304	Terminal 27, input	Coasting stop, inverse		Yes	Yes	0	5
305	Terminal 29, input	pol	<u> </u>	Yes	Yes	0	5
306	Terminal 32, input	Choice of setup, msb/speed up		Yes	Yes	0	
307	Terminal 33, input	Choice of setup, isb/speed down		Yes	Yes	0	5
308	Terminal 53, analogue input voltage	Reference		Yes	Yes	0	5
309	Terminal 53, min. scaling	0.0 V	0.0 - 10.0 V	Yes	Yes	1	5
310	Terminal 53, max. scaling	10.0 V	0.0 - 10.0 V	Yes	Yes	-1	5
311	Terminal 54, analogue input voltage	No operation		Yes	Yes	0	5
312	Terminal 54, min. scaling	0.0 V	0.0 - 10.0 V	Yes	Yes	-1	_5
313	Terminal 54, max. scaling	10.0 V	0.0 - 10.0 V	Yes	Yes	-1	5
314	Terminal 60, analogue input current	Reference		Yes	Yes	0	5
315	Terminal 60, min. scaling	0.0 mA	0.0 - 20.0 m A	Yes	Yes	-4	5
316	Terminal 60, max. scaling	20.0 mA	0.0 - 20.0 mA	Yes	Yes	-4	5
317	Time out	10 sec.	1 - 99 sec.	Yes	Yes	0	5
318	Function after time out	Off		Yes	Yes	0	5
319	Terminal 42, output	0 - I _{MAX} ⇒ 0- <u>20 mA</u>		Yes	Yes	0	5
320	Terminal 42, output, pulse scaling	5000 Hz	1 - 32000 Hz	Yes	Yes	0	6
321	Terminal 45, output	0 - f _{MAX} ⇒ 0-20 mA		Yes	Yes	0	5
322	Terminal 45, output, pulse scaling	5000 Hz	1 - 32000 Hz	Yes	Yes	0	6
323	Relay 01, output	Ready - no thermal warning		Yes	Yes	0	5.
324	Relay 01, ON delay	0.00 sec.	0.00 - 600 sec.	Yes	Yes	-2	6
325	Relay 01, OFF delay	0.00 sec.	0.00 - 600 sec.	Yes	Yes	-2	6
326	Relay 04, output	Ready - remote control		Yes	Yes	0	5
327	Pulse reference, max. frequency	5000 Hz		Yes	Yes	0	6
328	Pulse feedback, max. frequency	25000 Hz		Yes	Yes	0	6
329	Encoder feedback pulse/rev.	1024 pulses/rev.	1 - 4096 pulses/r	ev. Yes	Yes	0	6
330	Freeze reference/output function	No operation		Yes	No	0	5
345	Encoder loss timeout	0 sec.	0 - 60 sec	No	Yes	-1	6
346	Encoder loss function	OFF		Yes	Yes	0	5

Factory settings

Changes during operation:

"Yes" means that the parameter can be changed, while the VLT frequency converter is in operation. "No" means that the VLT frequency converter must be stopped before a change can be made.

4-Setup:

"Yes" means that the parameter can be programmed individually in each of the four setups, i.e. the same parameter can have four different data values. "No" means that the data value will be the same in all four setups.

Conversion index:

This number refers to a conversion figure to be used when writing or reading by means of a VLT frequency converter.

Conversion index	Conversion factor
74	0.1
2	100
1	10
0	1
-1	0.1
-2	0.01
-3	0.001
-4	0.0001

Data type:

Data type shows the type and length of the telegram.

Data type	Description
3	Integer 16
4	Integer 32
5	Unsigned 8
6	Unsigned 16
7	Unsigned 32
9	Text string



PNU	Parameter	Factory setting	Range	-	4-Setup	Conversion	Data
#	description		d	uring opera		index	type
400	Brake function/overvoltage control			Yes	No	0	5
401	Brake resistor, ohm	Depends on the unit		Yes	No	-1	6
402	Brake power limit, kW	Depends on the unit		Yes	No	2	6
403	Power monitoring	On		Yes	No	0	5
404	Brake check	Off		Yes	No	0	5
405	Reset function	Manual reset	<u> </u>	Yes	Yes	0	5
<u>406</u>	Automatic restart time	5 sec.	0 - 10 sec.	Yes	Yes	0	5
407	Mains Failure	No function		Yes	Yes	0	5
408	Quick discharge	Not possible		Yes	Yes	0	5
409	Trip delay torque	Off	0 - 60 sec.	Yes	Yes	0	5
410	Trip delay-inverter	Depends on type of unit	0 - 35 sec.	Yes	Yes	0	5
<u>411</u>	Switching frequency	Depends on type of unit	3 - 14 kHz	Yes	Yes	2	6
412	Output frequency dependent	Not possible		Yes	Yes	0	5
	switching frequency						
413	Overmodulation function	On		Yes	Yes	-1	5
414	Minimum feedback	0.000	-100,000.000 - FB _H	_{IGH} Yes	Yes	-3	4
415	Maximum feedback	1500.000	FB _{LOW} - 100,000.00	0 Yes	Yes	-3	4
416	Process unit	%		Yes	Yes	0	5
417	Speed PID proportional gain	0.015	0.000 - 0.150	Yes	Yes	-3	6
418	Speed PID integration time	8 ms	2.00 - 999.99 ms	Yes	Yes	-4	7
419	Speed PID differentiation time	30 ms	0.00 - 200.00 ms	Yes	Yes	-4	6
420	Speed PID diff. gain ratio	5.0	5.0 - 50.0	Yes	Yes	-1	6
421	Speed PID low-pass filter	10 ms	5 - 200 ms	Yes	Yes	-4	6
422	U 0 voltage at 0 Hz	20.0 V	0.0 - parameter 103	3 Yes	Yes	-1	6
423	U 1 voltage	parameter 103	0.0 - Uvet, max	Yes	Yes	-1	6
424	F 1 frequency	parameter 104	0.0 - parameter 426	6 Yes	Yes	-1	6
425	U 2 voltage	parameter 103	0.0 - Uvlt, max	Yes	Yes	-1	6
426	F 2 frequency	parameter 104	par.424-par.428	Yes	Yes	-1	6
427	U 3 voltage	parameter 103	0.0 - U _{VLT, MAX}	Yes	Yes	•1	6
428	F 3 frequency	parameter 104	par.426 -par.430	Yes	Yes	-1	6
429	U 4 voltage	parameter 103	0.0 - U _{VLT, MAX}	Yes	Yes	-1	6
430	F 4 frequency	parameter 104	par.426-par.432	Yes	Yes	-1	6
431	U 5 voltage	parameter 103	0.0 - U _{VLT, MAX}	Yes	Yes	-1	6
432	F 5 frequency	parameter 104	par.426 - 1000 Hz	Yes	Yes	-1	6
433	Torque proportional gain	100%	0 (OFF) - 500%	Yes	Yes	0	6
434	Torque integral time	0.02 sec.	0.002 - 2.000 sec.	Yes	Yes	-3	7
437	Process PID Normal/inverse contro		0.002 - 2.000 300.	Yes	Yes	0	5
438	Process PID anti windup	On		Yes	Yes	0	5
439	Process PID start frequency	parameter 201	f _{unn} - f _{ana}	Yes	Yes	•1	6
440	Process PID proportional gain	0.01	0.00 - 10.00	Yes	Yes	-2	6
		9999.99 sec. (OFF)	0.01 - 9999.99 sec.			-2	7
441	Process PID integral time Process PID differentiation time	0.00 sec. (OFF)	0.00 - 10.00 sec.		Yes Yes	-2	6
442		5.0	5.0 - 50.0	Yes		-1	6
443	Process PID diff. gain limit			Yes	Yes	-2	6
444	Process PID lowpass filter time	0.01	0.01 - 10.00	Yes	Yes		5
445	Flying start	Disable		Yes	Yes	0	5
446	Switching pattern	SFAVM	100 1004	Yes	Yes	0	3
447	Torque compensation	100%	-100 - +100%	Yes	Yes	-2	
448	Gear ratio	1	0.001 - 100.000	No	Yes		4
449	Friction loss	0%	0 - 50%	No	Yes	-2	6
450	Mains voltage at mains fault	Depends on unit	Depends on unit	Yes	Yes	0	6
<u>453</u>	Speed closed loop gear ratio		<u>0.01-100</u>	No	Yes	0	4
454	Dead time compensation	On		No	No	0	5



ŝ
D
Ξ'
. <u>–</u>
÷
<u>.</u>
Ψ
ý.
5
Š
Š
iory s
story s
ictory s
actory s
Factory s

PNU	Parameter	Factory setting	Range	Changes	4-Setup	Conversion	Data
#	description		đu	uring opera	tion	index	type
<u>-</u> 500	Address	1	0 - 126	Yes	No	0	6
501	Baudrate	9600 Baud	· · · · · · · ·	Yes	No	0	5
502	Coasting	Logic or		Yes	Yes	0	5
503	Quick-stop	Logic or		Yes	Yes	0	5
504	DC-brake	Logic or		Yes	Yes	0	5
505	Start	Logic or		Yes	Yes	0	5
506	Reversing	Logic or		Yes	Yes	0	5
507	Selection of setup	Logic or		Yes	Yes	0	5
508	Selection of speed	Logic or		Yes	Yes	0	5
509	Bus jog 1	10.0 Hz	0.0 - parameter 20)2 Yes	Yes	-1	6
510	Bus jog 2	10.0 Hz	0.0 - parameter 20		Yes	•1	6
511							
512	Telegram profile	FC Drive		No	Yes	0	5
513	Bus time interval	1 sec.	1-99s	Yes	Yes	0	5
514	Bus time interval function	Off		Yes	Yes	0	5
515	Data read-out: Reference %		AN	Ņo	No	-1	3
516	Data read-out: Reference unit			No	No	-3	4
517	Data read-out: Feedback			No	No	-3	4
518	Data read-out: Frequency			No	No	-1	6
519	Data read-out: Frequency x Scaling	¥		No	No	-2	7
520	Data read-out: Current			No	No	-2	7
521	Data read-out: Torque			No	No	-1	3
522	Data read-out: Power, kW			No	No	-1	7
523	Data read-out: Power, HP			No	No	-2	7
524	Data read-out: Motor voltage			No	No	•1	6
525	Data read-out: DC link voltage			No	No	0	6
526	Data read-out: Motor temp.			No	No	0	5
527	Data read-out; VLT temp.			No	No	0	5
528	Data read-out: Digital input			No	No	0	5
529	Data read-out: Terminal 53, analogue input			No	No	-2	3 ·
530	Data read-out: Terminal 54, analogue input			No	No	-2	3
531	Data read-out: Terminal 60, analogue input			No	No	-5	3
532	Data read-out: Pulse reference	• 4000 •		No	No	-1	7
533	Data read-out: External reference %			No	No	-1	3
<u>534</u>	Data read-out: Status word, binary			No	NO	0	6
535	Data read-out: Brake power/2 min.			No	No	2	6
536	Data read-out: Brake power/sec.			No	No	2	6
537	Data read-out: Heat sink temperature			No	No	0	5
538	Data read-out: Alarm word, binary			No	No	0	7
539	Data read-out: VLT control word, binary	· · · · · · · ·		No	No	0	6
540	Data read-out: Warning word, 1	·	• •	No	No	0	7
541	Data read-out: Warning word, 2			No	No	0	7
571	and the out the starting training to						

Danfoss

VLT' 5000 Series

PNU ¥	Parameter Facto description	ry setting	Range	Changes during opera	4-Setup	Conversion index	Data type		
, 500	Operating data: Operating hours			No	No	74	7		
50 <u>0</u> 501	Operating data: Hours run			No	No	74	7		
502	Operating data: kWh counter			No	No	2	7		
502 503	Operating data: Number of power-up's			No	No	0	6		
604	Operating data: Number of overtemperatures			No	No	0	6		
				No	No	0			
505 505	Operating data: Number of overvoltages					0	5		
506	Data log: Digital input			No	No	0	6		
<u>507</u>	Data log: Bus commands			No	No	0	6		
<u> </u>	Data log: Bus status word			<u>No</u>	No		3		
<u>609</u>	Data log: Reference			No	No	-1	4		
<u>510</u>	Data log: Feedback			No	No	-3			
511	Data log: Motor frequency			No	No	-1	3		
512	Data log: Motor voltage			No	No	1	6		
513	Data log: Motor current			No	No	-2	3		
514	Data log: DC link voltage			No	No	0	6		
515_	Fault log: Error code			No	No	0	5		
51 <u>6</u>	Fault log: Time			No	No	-1	7		
517	Fault log: Value			No	No	0	3		
518	Reset of kWh counter No re	set		Yes	No	0	5		
519	Reset of hours-run counter No re	set		Yes	No	0	5		
520	Operating mode Normal function Norm	al function		No	No	0	5		
52 <u>1</u>	Nameplate: VLT type			No	No	0	9		
22	Nameplate: Power section			No	No	0	9		
23	Nameplate: VLT ordering number			No	No	0	9		
524	Nameplate: Software version no.			No	No	0	9		
625	Nameplate: LCP identification no.			No	No	0	9		
526	Nameplate: Database identification no.			No	No	-2	9		
527	Nameplate: Power section identification no.			No	No	0	9		
528	Nameplate: Application option type			No	No	0	9		
529	Nameplate: Application option ordering no.			No	No	0	9		
530	Nameplate: Communication option type			No	No	0	9		
53 <u>1</u>	Nameplate: Communication option ordering no.			No	No	0	9		
Chan	ges during operation:	Cor	version in	dex	Сопу	ersion facto	ЭГ		
'Yes"	means that the parameter can be changed,		74			0.1			
while	the VLT frequency converter is in operation.		2			100			
'No"	means that the VLT frequency converter must be	è	1			10			
stopp	bed before a change can be made.		0	·		1			
,	-		-1			0.1			
I-Set			-2			0.01			
	means that the parameter can be programmed		-3		0.001				
	dually in each of the four setups, i.e. the same		-4	· <u>·</u> · · · ·		0.0001			
	neter can have four different data values. "No"				-				
	is that the data value will be the same in all four		type:						
setup	9S.			vs the type a	-		gram		
Conv	ersion index:	Data	type		Descripti	ion			
	number refers to a conversion figure to be used	3			Integer 1	6			
	writing or reading by means of a VLT frequency	4			Integer 3				
	• • • •								
converter.		_5		<u>.</u>	Unsigned				
					Unsigned 16				
		6				Unsigned 32			
		7			Unsigned	d 32			



PNU	Parameter	Factory setting	Range	Changes	4-Setup	Conversion	Data
#	description			luring opera	tion	index	type
700	Relay 6, function	Ready signal		Yes	Yes	0	5
701	Relay 6, ON delay	0 sec.	0.00-600	sec. Yes	Yes	-2	6
702	Relay 6, OFF delay	0 sec.	0.00-600	sec. Yes	Yes	-2	6
703	Relay 7, function	Motor running		Yes	Yes	0	5
704	Relay 7, ON delay	0 sec.	0.00-600	sec. Yes	Yes	-2	6
705	Relay 7, OFF delay	0 sec.	0.00-600	sec. Yes	Yes	-2	6
706	Relay 8, function	Mains ON		Yes	Yes	0	5
707	Relay B, ON delay	0 sec.	0.00-600	sec. Yes	Yes	-2	6
708	Relay B, OFF delay	0 sec.	0.00-600	sec. Yes	Yes	-2	6
709	Relay 9, function	Fault		Yes	Yes	0	5
710	Relay 9, ON delay	0 sec.	0.00-600	sec. Yes	Yes	-2	6
711	Relay 9, OFF delay	0 sec.	0.00-600	sec. Yes	Yes	-2	6



A

Active Setup	
Alarm word	
alarms	154
anti windup	126
Application configuration	
Automatic Motor Adaptation, AMA	
Automatic motor adaptation, AMA	
AWG	163

В

Baudrate	13 1
Brake check	
Brake function	
brake function	59
brake resistor	59
Busjog	133

С

cable clamp
Coasting stop
Compact IP 20 and IP 54 14
Connection examples 45
2-wire start/stop 45
4-20 mA reference with speed feedback
Digital speed up/down 46
Encoder connection 46
Potentiometer reference 46
Pulse start/stop 45
Setup change 46
Control command
Control keys 49
Control panel 48

D

•

	140
Data log	
Data read-out	
Database identification no.	
DC braking	
DC holding current	
Definitions	-
differential time	
differentiation time	
Digital inputs	
Display	
Display line 2	
Display mode	50
3	

Ε

Earth fault15	56
Electrical installation	
control cables	44
Earthing of braided screened/armoured control	
cabl	39
EMC-correct cables 3	38
power cables	32
screened/armoured motor cables	37
EMC-correct electrical installation	37
Enclosure protection	25
Encoder feedback pulse/rev11	15
Extra protection	40

F

Η

High starting torque	90
high torque characteristic	
High voltage test	40

I

Initializing Installation	
24 Volt external DC supply	
brake cable	42
Bus connection	
control cables	44
loadsharing	
motor cables	41
relay terminals	43
integral time	122,127
Integration time	
J	
Jog frequency	97

Index



Language	
Latched start	
LCP (Local Control Panel)	48
LEDs	48
local control	58
Local reference	
Low current	
lowpass filter time	123,128

Μ

L

The fact the second T	2
mains fault inverse	
Mains fault inverted10	15
Measurements, dimensions 2	21
Bookstyle IP 20 2	
Compact IP 00 2	
Compact IP 20 2	.3
Compact IP 54 2	24
Manual initialisation 5	
	6
Mechanical installation 2	
Cooling 2	25
Side-by-side 2	25
Motor	
	37
	41
	41
	•••
Motor frequency 8	
Motor power 8	34
	34
	42
T drailer coupiirig	
Kaleu mului speeu	
Motor phase monitor It	ונ
Parallel coupling	42 36

Ν

Nameplate	.145
Normal/inverse control	

0

Operating data14	0
Output frequency 9	

Ρ

PID	68
Power monitoring	117
Power section	
Power sectionidentification no.	146
Preset reference	
Process regulation	68
Process regulation, closed loop (Process	PID) 56
Process unit	
Proportional gain	122,125,127
Pulse feedback	
Pulse reference	
pulse scaling	113

Q

Quick discharge	71
Quick menu	
Quick-stop1	03

R

Ramp type rated torque characteristic		
Reference function		
Reference/feedback area		
references		
Relay 01	1	14
Relay 04	1	14
remote control		
Reset function	1	18
Resonance dampening		89
Reversing		
RFI switch		

S

Safety	40 40 105 131 163
Start clockwise	
Stator reactance Stator resistor Status messages Switches 1-4 Switching frequency Switching pattern	87 147,152 44 120



Т

Technical data	
Bookstyle IP 20	
Brake resistor terminals	
Cable lengths and cross-sections	10
Compact Ip 00, IP 20 and IP 54 16,17,	19,20
Compact IP 20 and IP 54	
Control card, 24 V DC supply	10
Control card, analogue inputs	9
Control card, digital inputs	8
Control card, digital/pulse and analogue output	uts.9
Control card, pulse/encoder input	9
 Control card, RS 485 serial communication 	10
Control characteristics	11
External 24 Volt DC supply	10
Externals	
Mains supply (L1, L2, L3)	
Relay outputs	10
Torque characteristics	
VLT 5000 Series protection	
VLT output data (U, V, W)	8
Tightening-up torque	
Torque characteristics	
Torque compensation	
Torque control, open loop	56,82
Torque control, speed feedback	
Torque limit	
Trip delay torque	
Trip delay-inverter	
Trip locked	162

V

VLT ordering number1	45
VLT type	
WC ^{PLUS}	62

W

Warning	
Feedback	
Frequency	
Low current	99
Warning words	
Warnings	

Parameter		Settings				
No.	1	2	3	4		
				·		
	r					
	• • •					
			·			
				1		
				<u> </u>		
]		<u>_</u>		
				·		
				· · ·		
	· · · · · · · · · · · · · · · · · · ·					
	· · · · · · · · · · · · · · · · · · ·					
				*		
			1			
			· · · · · · · · · · · · · · · · · · ·			
				·		
		l	L			

.

Parameter	Settings			
No.	1	2	3	4
1100				
		·		
				· · · · · · · · · · · · · · · · · · ·
,				
	·			
	· · · · · · · · · · · · · · · · · · ·			
<u> </u>	<u> </u>			· .
				· · · ·
	· · · · · · · · · · · · · · · · · · ·			
				_
<u> </u>	· · · · · · · · · · · · · · · · · · ·			
	· · · · · · · · · · · · · · · · · · ·			
· · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·			
				·······
L		<u></u>		
`				
<u> </u>				
· · ·				
		·		
		······		······································
	<u> </u>	· · · · · · · · · · · · · · · · · · ·		
		<u> </u>		
	+			
_		l	L	1

a.

Parameter		Setti	ngs	
No.	1	2	3	4
				· · · · · · · · · · · · · · · · · · ·
		<u> </u>	<u>,,, – .</u>	· · · · · · · · · · · · · · · · · · ·
· · · · · · · · · · · · · · · · · · ·				
		-		
			·	
·	, ·			
	_			
				· · · · · · · · · · · · · · · · · · ·
· · · · · · · · · · · · · · · · · · ·				
	<u> </u>			
3		<u>-</u>		
·	t			
· .	•	•		· · · · · · · · · · · · · · · · · · ·
	· · · · · · · · · · · · · · · · · · ·			
· •				
		<i>"</i>		
				· · · ·
	·			
	<u> </u>			
		101		
			. · · · · · · · · · · · · · · · · · · ·	<u> </u>
·	· · · · · · · · · · · · · · · · · · ·	<u> </u>		<u> </u>
		· · · · · · · · · · · · · · · · · · ·	·	
	<u> </u>		, , <u>, , , , , , , , , , , , , , , , , </u>	
	,			

Parameter	Settings			
No.	1	2	3	4
	·			
,				
······································				· · ·
	· · · · · · · · · · · · · · · · · · ·			
<u>.</u>				
•				
				1
·				
·				
	<u> </u>	<u> </u>		
—				
	ļ			
— — —	+			
<u>}</u>		· · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·	
L	·			
		ļ		

Parameter	Settings			
No.	1	2	3	4
			·	
			······································	
		· ·		
	<u> </u>			
				· · · · ·
				·••
				·
		<u>.</u>		ļ
		· · ····		
				·
				:
				· · · · ·
		· · · · · · · · · · · · · · · · · · ·		
		1		· · · · · · · · · · · · · · · · · · ·
			1	
· · · · · · · · · · · · · · · · · ·				
				
				·
			· ·	
			· ·	
		· ·		
			······································	
	-			
		1		
· · · · · · · · · · · · · · · · · · ·		1		
			· · · · · · · · · · · · · · · · · · ·	
			· ·	

Parameter	Settings			
No.	1	2	3	4
110.			· ·	
}				
			<i>;</i>	
				· · · · · · · · · · · · · · · · · · ·
		· ·		
				· _ ·
·······				
· · · · · · · · · · · · · · · · · · ·				
			· · · · ·	
	·			
				•
├─────	· · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·		
		l	· · · · · · · · · · · · · · · · · · ·	
└──────────			·	
	<u> </u>		·	
	L	· · · · · · · · · · · · · · · · · · ·		······································
		· · · · · · · · · · · · · · · · · · ·		
		<u> </u>	· · · · · · · · · · · · · · · · · · ·	
L	· · · · · · · · · · · · · · · · · · ·	ļ	· · · · · · · · · · · · · · · · · · ·	



4. Parameters for VLT

MM2.2100016en2_with A2.tm

Doc. No. 00016en2

4. Parameters for VLT

This page intentionally left blank



Electrical installation

The voltage on the frequency converter is dangerous when the unit is connected to mains. Incorrect installation of the motor or VLT frequency converter may lead to material damage or serious injury or it may be fatal. Consequently, the instructions in this manual as well as national and local rules and safety regulations must be complied with.

Touching the electrical parts may be fatal, even after the mains supply has been disconnected. Wait at least 4 minutes if using VLT 5001-5006 and at least 15 minutes if using VLT 5008-5500.

	Action	Value	Remark
1	Power off the VLT		Wait until the display on the Dan- foss VLT is off
2	Check that the motor cables are connected to delta		
3	Power on the VLT		
4	Press stop button on Danfoss VLT		Display is flashing
5	Select 'Initialize' in Parameter P 620	'Initialize'	This will reset all parameters in the VLT
6	Power off the Danfoss VLT		Wait until the display on the Dan- foss VLT is off
7	Power on the Danfoss VLT		The parameters in the Danfoss VLT are reset to factory setting
8	Press stop button on Danfoss VLT		Display is flashing
9	Feed in values from the motor plate to Parameter P 102, P 103, P 104, P 105, P 106		Values from the motor plate
10	Bridge terminal 12 and 27 in the Danfoss VLT		
11	Set Parameter 107	Full motor tuning Enable (Rs, Xs)	
12	Press start button on the VLT		The tuning takes 5 to 10 minutes. Shows "working" or "Auto motor tuning" while motor tuning is made. When alarm 21 appears, the tuning is ready.
13	Press STOP button on the VLT		Display is flashing
14	Remove bridge in the VLT between terminals 12 and 27		
15	New values will apeear in the parameters P 108 and P 109 from the mutor tuning.		Values automatically set by the motor tuning
16	Set parameter P 115	0%	Slip compensation
		• • • • • • • • • • • • • • • • • • • •	•

MM2.2100016en2_with A2.fm

4. Parameters for VLT

Action	Value	Remark
Set parameter P 128	'Termistor trip'	Motors for frequenzy drive shall have termistors in windings
Set parameter P 202	See table 1	Out freq. High limit
Set parameter P 204	See table 1	Min. freq.
Set parameter P 205	See table 1	Max. Ref.
Set parameter P 207	800 sec.	Ramp up time
Set parameter P 208	900 sec.	Ramp down time
Set parameter P 211	600 sec.	Jog ramp time
Set parameter P 213	See table 1	Jog frequenzy
Set parameter P 308	Termistor input	Terminal 53, Termistor input
Set parameter P 319	0-I max 4-20 mA (Current signal)	Terminal 42 output, current signa
Set parameter P 323	VLT running	Relay 01, Output
Set parameter P 324	5 sec.	Relay 01, Delay
Set parameter P 326	Alarm	Relay 04, Output
Set parameter P 400	Overvoltage control	Brake function (necessary for 2-speed)
Set parameter P 445	Enable	(Flying start)
Press 'START' on VLT		Display goes steady (not flash- ing). The programming of the Danfoss VLT is now ready
Press "Display/Status" push- button on the Danfoss VLT to get wanted display		
	Set parameter P 128 Set parameter P 202 Set parameter P 204 Set parameter P 205 Set parameter P 207 Set parameter P 208 Set parameter P 211 Set parameter P 213 Set parameter P 213 Set parameter P 308 Set parameter P 308 Set parameter P 323 Set parameter P 324 Set parameter P 326 Set parameter P 326 Set parameter P 400 Set parameter P 445 Press 'START' on VLT Press "Display/Status" push- button on the Danfoss VLT to get	Set parameter P 128'Termistor trip'Set parameter P 202See table 1Set parameter P 204See table 1Set parameter P 205See table 1Set parameter P 207800 sec.Set parameter P 208900 sec.Set parameter P 211600 sec.Set parameter P 213See table 1Set parameter P 308Termistor inputSet parameter P 3190-I max 4-20 mA (Current signal)Set parameter P 323VLT runningSet parameter P 3245 sec.Set parameter P 326AlarmSet parameter P 445EnablePress 'START' on VLTPress "Display/Status" push- button on the Danfoss VLT to get

	Parameter list for 50 Hz					
Separator Tetra Centri	Motor [kW]	VLT type Danfoss	Parameter P202 gear	Parameter P204 gear	Parameter P205 gear	Paramete P213 gear
610	18,5	5032	50	^{·.} 50	50	50
614	18,5	5032	50	50	50	50
714	22	5032	50	50	50	50
518	22	5052	50	50	50	50
618	25/37	5052	50	50	50	50
718	25	5052	50	50	50	50
			•	•		
617 *	37	5052	50	50	50	50
617 *	45	5060	50	50	50	50
	<u> </u>		•	•	•	
818	37	5052	55	55	55	55

 Different m 	otor alternatives
---------------------------------	-------------------

MM2.2100016en2_with A2.fm

Parameter list for 60 Hz						
Separator Tetra Centri	Motor [kW]	VLT type Danfoss	Parameter P202 gear	Parameter P204 gear	Parameter P205 gear	Parameter P213 gear
610	18,5	5032	60	60	60	60
614	18,5	5032	60	60	60	60
714	22	5032	60	60	60	60
518	22	5052	60	60	60	60
618	25/37	5052	60	60	60	60
718	25	5052	60	60	60	60
617 *	37	5052	60	60	60	60
617 *	45	5060	60	60	60	60
818	37	5052	66	66	66	66

4. Parameters for VLT

This page intentionally left blank

۸. .


·

.

MM2.2100016en2_wth A2.tm

-4

•



.



